




# Heracles224G\_AT Command Manual\_V1.00



<b>Document Title</b>	<b>Heracles224G AT Command Manual</b>
<b>Version</b>	<b>1.00</b>
<b>Date</b>	<b>2018-09-12</b>
<b>Status</b>	<b>Release</b>
<b>Document Control ID</b>	<b>Heracles224G_AT Command Manual_V1.00</b>

### **General Notes**

SIMCom offers this information as a service to its customers, to support application and engineering efforts that use the products designed by SIMCom. The information provided is based upon requirements specifically provided to SIMCom by the customers. SIMCom has not undertaken any independent search for additional relevant information, including any information that may be in the customer's possession. Furthermore, system validation of this product designed by SIMCom within a larger electronic system remains the responsibility of the customer or the customer's system integrator. All specifications supplied herein are subject to change.

### **Copyright**

This document contains proprietary technical information which is the property of Shanghai SIMCom Wireless Solutions Ltd, copying of this document and giving it to others and the using or communication of the contents thereof, are forbidden without express authority. Offenders are liable to the payment of damages. All rights reserved in the event of grant of a patent or the registration of a utility model or design. All specification supplied herein are subject to change without notice at any time.

***Copyright © Shanghai SIMCom Wireless Solutions Ltd. 2018***

## Contents

Version History .....	11
1 Introduction.....	12
1.1 Scope of the document .....	12
1.2 Related documents .....	12
1.3 Conventions and abbreviations .....	12
1.4 AT Command syntax.....	12
1.4.1 Basic syntax .....	13
1.4.2 S Parameter syntax .....	13
1.4.3 Extended Syntax.....	13
1.4.4 Combining AT commands on the same Command line.....	13
1.4.5 Entering successive AT commands on separate lines.....	14
1.5 Supported character sets .....	14
1.6 Flow control .....	14
1.6.1 Software flow control (XON/XOFF flow control).....	14
1.6.2 Hardware flow control (RTS/CTS flow control).....	15
1.7 Definitions.....	15
1.7.1 Parameter Saving Mode .....	15
1.7.2 Max Response Time .....	15
2 AT Commands According to V.25TER .....	16
2.1 Overview of AT Commands According to V.25TER .....	16
2.2 Detailed Description of AT Commands According to V.25TER.....	17
2.2.1 A/ Re-issues the Last Command Given .....	17
2.2.2 ATD Mobile Originated Call to Dial A Number .....	17
2.2.3 ATE Set Command Echo Mode .....	18
2.2.4 ATH Disconnect Existing Connection .....	19
2.2.5 ATI Display Product Identification Information .....	19
2.2.6 ATL Set Monitor speaker loudness .....	20
2.2.7 ATM Set Monitor Speaker Mode .....	20
2.2.8 +++ Switch from Data Mode or PPP Online Mode to Command Mode.....	20
2.2.9 ATO Switch from Command Mode to Data Mode .....	21
2.2.10 ATQ Set Result Code Presentation Mode .....	21
2.2.11 ATS0 Set Number of Rings before Automatically Answering the Call.....	22
2.2.12 ATS3 Set Command Line Termination Character.....	22
2.2.13 ATS4 Set Response Formatting Character .....	23
2.2.14 ATS5 Set Command Line Editing Character .....	24
2.2.15 ATS6 Pause Before Blind Dialling.....	24
2.2.16 ATS7 Set Number of Seconds to Wait for Connection Completion.....	25
2.2.17 ATS8 Set Number of Seconds to Wait for Comma Dial Modifier Encountered in Dial String of D Command .....	25

2.2.18	ATS10	Set Disconnect Delay after Indicating the Absence of Data Carrier .....	26
2.2.19	ATV	TA Response Format .....	26
2.2.20	ATX	Set CONNECT Result Code Format and Monitor Call Progress .....	28
2.2.21	AT&C	Set DCD Function Mode .....	28
2.2.22	AT&D	Set DTR Function Mode .....	29
2.2.23	AT&E	Set CONNECT Result Code Format About Speed .....	29
2.2.24	AT+GCAP	Request Complete TA Capabilities List .....	30
2.2.25	AT+GMI	Request Manufacturer Identification .....	30
2.2.26	AT+GMM	Request TA Model Identification .....	30
2.2.27	AT+GMR	Request TA Revision Identification of Software Release .....	31
2.2.28	AT+GOI	Request Global Object Identification .....	31
2.2.29	AT+GSN	Request TA Serial Number Identification (IMEI) .....	32
2.2.30	AT+ICF	Set TE-TA Control Character Framing .....	33
2.2.31	AT+IFC	Set TE-TA Local Data Flow Control .....	33
2.2.32	AT+IPR	Set TE-TA Fixed Local Rate .....	34
3	AT Commands According to 3GPP TS 27.007.....		36
3.1	Overview of AT Command According to 3GPP TS 27.007.....		36
3.2	Detailed Descriptions of AT Command According to 3GPP TS 27.007.....		36
3.2.1	AT+CGMI	Request Manufacturer Identification .....	36
3.2.2	AT+CGMM	Request Model Identification .....	37
3.2.3	AT+CGMR	Request TA Revision Identification of Software Release.....	37
3.2.4	AT+CGSN	Request Product Serial Number Identification .....	38
3.2.5	AT+CSCS	Select TE Character Set.....	38
3.2.6	AT+CIMI	Request International Mobile Subscriber Identity.....	39
3.2.7	AT+CLCK	Facility Lock.....	40
3.2.8	AT+CMEE	Report Mobile Equipment Error .....	41
3.2.9	AT+COPS	Operator Selection.....	42
3.2.10	AT+CPAS	Phone Activity Status.....	44
3.2.11	AT+CPIN	Enter PIN .....	44
3.2.12	AT+CPWD	Change Password.....	45
3.2.13	AT+CRC	Set Cellular Result Codes for Incoming Call Indication .....	47
3.2.14	AT+CREG	Network Registration.....	48
3.2.15	AT+CRSM	Restricted SIM Access .....	49
3.2.16	AT+CSQ	Signal Quality Report.....	50
3.2.17	AT+CPOL	Preferred Operator List .....	51
3.2.18	AT+COPN	Read Operator Names.....	52
3.2.19	AT+CFUN	Set Phone Functionality.....	53
3.2.20	AT+CCLK	Clock .....	54
3.2.21	AT+CSIM	Generic SIM Access .....	54
3.2.22	AT+CBC	Battery Charge .....	55
3.2.23	AT+CUSD	Unstructured Supplementary Service Data.....	56
3.2.24	AT+CNUM	Subscriber Number.....	57
4	AT Commands According to 3GPP TS 27.005.....		58

4.1	Overview of AT Commands According to 3GPP TS 27.005 .....	58
4.2	Detailed Descriptions of AT Commands According to 3GPP TS 27.005 .....	58
4.2.1	AT+CMGD Delete SMS Message .....	58
4.2.2	AT+CMGF Select SMS Message Format .....	59
4.2.3	AT+CMGL List SMS Messages from Preferred Store.....	60
4.2.4	AT+CMGR Read SMS Message.....	63
4.2.5	AT+CMGS Send SMS Message .....	66
4.2.6	AT+CMGW Write SMS Message to Memory .....	67
4.2.7	AT+CMSS Send SMS Message from Storage .....	69
4.2.8	AT+CNMI New SMS Message Indications .....	70
4.2.9	AT+CPMS Preferred SMS Message Storage .....	72
4.2.10	AT+CRES Restore SMS Settings.....	73
4.2.11	AT+CSAS Save SMS Settings .....	74
4.2.12	AT+CSCA SMS Service Center Address .....	75
4.2.13	AT+CSDH Show SMS Text Mode Parameters .....	76
4.2.14	AT+CSMP Set SMS Text Mode Parameters .....	76
4.2.15	AT+CSMS Select Message Service .....	77
5	AT Commands Special for SIMCom .....	79
5.1	Overview .....	79
5.2	Detailed Descriptions of Commands .....	80
5.2.1	AT+CPOWD Power off.....	80
5.2.2	AT+CADC Read ADC .....	80
5.2.3	AT+CFGRI Indicate RI When Using URC .....	81
5.2.4	AT+CLTS Get Local Timestamp.....	81
5.2.5	AT+CBAND Get and Set Mobile Operation Band .....	83
5.2.6	AT+CNBP Set the state of the band preference .....	84
5.2.7	AT+CNSMOD Show network system mode.....	86
5.2.8	AT+CSCLK Configure Slow Clock.....	87
5.2.9	AT+CCID Show ICCID .....	87
5.2.10	AT+CDEVICE View Current Flash Device Type .....	88
5.2.11	AT+GSV Display Product Identification Information.....	88
5.2.12	AT+SGPIO Control the GPIO.....	89
5.2.13	AT+SLEDS Set the Timer Period of Net Light.....	89
5.2.14	AT+CNETLIGHT Close the Net Light or Open It to Shining .....	90
5.2.15	AT+CSGS Netlight Indication of GPRS Status .....	91
5.2.16	AT+CGPIO Control the GPIO by PIN Index.....	92
5.2.17	AT+CBATCHK Set VBAT Checking Feature ON/OFF.....	93
5.2.18	AT+CNMP Preferred mode selection .....	93
5.2.19	AT+CMNB Preferred selection between CAT-M and NB-IoT .....	94
5.2.20	AT+CPSMS Power Saving Mode Setting.....	95
5.2.21	AT+CEDRXS Entended-DRX Setting .....	96
5.2.22	AT+CPSI Inquiring UE system information.....	97
5.2.23	AT+CGNAPN Get Network APN in CAT-M Or NB-IOT.....	98

5.2.24	AT+CSDP	Service Domain Preference .....	99
5.2.25	AT+MCELLLOCK	Lock the special CAT-M cell .....	100
5.2.26	AT+NCELLLOCK	Lock the special NB-IOT cell .....	101
5.2.27	AT+NBSC	Config NB-IOT Scrambling Feature .....	101
5.2.28	AT+CAPNMODE	Select the Mode of Application Configure APN .....	102
5.2.29	AT+CRRCSTATE	Query RRC State .....	103
5.2.30	AT+CBANDCFG	Configure CAT-M Or NB-IOT Band .....	103
5.2.31	AT+CNACT	App Network Active .....	104
5.2.32	AT+CEDUMP	Set whether the module reset when the module is crashed.....	105
5.2.33	AT+CNBS	Configure Band Scan Optimization For NB-IOT .....	106
5.2.34	AT+CNDS	Configure Service Domain Preference For NB-IOT.....	107
5.2.35	AT+CENG	Switch on or off Engineering Mode.....	107
5.2.36	AT+CNACTCFG	IP Protocol Type Config .....	109
5.2.37	AT+CTLIIC	Control the Switch of IIC .....	110
5.2.38	AT+CWIIC	Write Values to Register of IIC Device .....	111
5.2.39	AT+CRIIC	Read Values from Register of IIC Device .....	111
5.2.1	AT+SPWM	Generate the Pulse-Width-Modulation .....	112
<b>6</b>	<b>AT Commands for GPRS Support .....</b>		<b>113</b>
6.1	Overview of AT Commands for GPRS Support .....		113
6.2	Detailed Descriptions of AT Commands for GPRS Support .....		113
6.2.1	AT+CGATT	Attach or Detach from GPRS Service .....	113
6.2.2	AT+CGDCONT	Define PDP Context.....	114
6.2.3	AT+CGACT	PDP Context Activate or Deactivate.....	115
6.2.4	AT+CGPADDR	Show PDP Address.....	116
6.2.5	AT+CGREG	Network Registration Status .....	118
6.2.6	AT+CGSMS	Select Service for MO SMS Messages.....	119
<b>7</b>	<b>AT Commands for IP Application.....</b>		<b>121</b>
7.1	Overview .....		121
7.2	Detailed Descriptions of Commands .....		121
7.2.1	AT+SAPBR	Bearer Settings for Applications Based on IP.....	121
<b>8</b>	<b>AT Commands for TCPIP Application Toolkit .....</b>		<b>123</b>
8.1	Overview .....		123
8.2	Detailed Descriptions of Commands .....		124
8.2.1	AT+CIPMUX	Start Up Multi-IP Connection.....	124
8.2.2	AT+CIPSTART	Start Up TCP or UDP Connection.....	124
8.2.3	AT+CIPSEND	Send Data Through TCP or UDP Connection .....	127
8.2.4	AT+CIPQSEND	Select Data Transmitting Mode .....	129
8.2.5	AT+CIPACK	Query Previous Connection Data Transmitting State .....	129
8.2.6	AT+CIPCLOSE	Close TCP or UDP Connection .....	130
8.2.7	AT+CIPSHUT	Deactivate GPRS PDP Context .....	131
8.2.8	AT+CLPORT	Set Local Port.....	131

8.2.9	AT+CSTT	Start Task and Set APN, USER NAME, PASSWORD .....	132
8.2.10	AT+CIICR	Bring Up Wireless Connection with GPRS .....	133
8.2.11	AT+CIFSR	Get Local IP Address .....	134
8.2.12	AT+CIFSREX	Get Local IP Address extend.....	134
8.2.13	AT+CIPSTATUS	Query Current Connection Status .....	135
8.2.14	AT+CDNSCFG	Configure Domain Name Server .....	137
8.2.15	AT+CDNSGIP	Query the IP Address of Given Domain Name .....	137
8.2.16	AT+CIPHEAD	Add an IP Head at the Beginning of a Package Received.....	138
8.2.17	AT+CIPATS	Set Auto Sending Timer .....	139
8.2.18	AT+CIPSPRT	Set Prompt of '>' When Module Sends Data.....	140
8.2.19	AT+CIPSERVER	Configure Module as Server .....	140
8.2.20	AT+CIPCSGP	Set GPRS for Connection Mode .....	141
8.2.21	AT+CIPSRIP	Show Remote IP Address and Port When Received Data.....	142
8.2.22	AT+CIPDPDP	Set Whether to Check State of GPRS Network Timing.....	143
8.2.23	AT+CIPMODE	Select TCP/IP Application Mode .....	143
8.2.24	AT+CIPCCFG	Configure Transparent Transfer Mode.....	144
8.2.25	AT+CIPSHOWTP	Display Transfer Protocol in IP Head When Received Data.....	145
8.2.26	AT+CIPUDPMODE	UDP Extended Mode.....	146
8.2.27	AT+CIPRXGET	Get Data from Network Manually .....	147
8.2.28	AT+CIPRDTIMER	Set Remote Delay Timer .....	149
8.2.29	AT+CIPSGTXT	Select GPRS PDP context .....	150
8.2.30	AT+CIPSENDHEX	Set CIPSEND Data Format to Hex .....	150
8.2.31	AT+CIPHEXS	Set Output-data Format with suffix.....	151
8.2.32	AT+CIPTKA	Set TCP Keepalive Parameters.....	152
8.2.33	AT+CIPOPTION	Enable or Disable TCP nagle algorithm .....	153
9	AT Commands for HTTP Application .....		154
9.1	Overview .....		154
9.2	Detailed Descriptions of Commands .....		154
9.2.1	AT+HTTPINIT	Initialize HTTP Service.....	154
9.2.2	AT+HTTPTERM	Terminate HTTP Service.....	155
9.2.3	AT+HTTPPARA	Set HTTP Parameters Value .....	155
9.2.4	AT+HTTPDATA	Input HTTP Data.....	157
9.2.5	AT+HTTPACTION	HTTP Method Action .....	157
9.2.6	AT+HTTPREAD	Read the HTTP Server Response .....	159
9.2.7	AT+HTTPSTATUS	Read HTTP Status.....	160
9.2.8	AT+HTTPHEAD	Read the HTTP Header Information of Server Response .....	161
9.2.9	AT+HTTPTOFS	download file to ap file system.....	161
10	AT Commands for PING Application.....		164
10.1	Overview .....		164
10.2	Detailed Descriptions of Commands.....		164
10.2.1	AT+CIPPING	PING Request.....	164
10.2.2	AT+CIPCTL	Set the Mode When Receiving an IP Packet .....	165

10.2.3	AT+CIPFLT	Set the Rules of IP Filter .....	166
<b>11</b>	<b>AT Commands for FTP Application .....</b>		<b>168</b>
11.1	Overview .....		168
11.2	Detailed Descriptions of Commands .....		169
11.2.1	AT+FTPPORT	Set FTP Control Port .....	169
11.2.2	AT+FTPMODE	Set Active or Passive FTP Mode .....	169
11.2.3	AT+FTPYPE	Set the Type of Data to Be Transferred .....	170
11.2.4	AT+FTPPUTOPT	Set FTP Put Type .....	171
11.2.5	AT+FTPCID	Set FTP Bearer Profile Identifier .....	171
11.2.6	AT+FTPREST	Set Resume Broken Download .....	172
11.2.7	AT+FTPSERV	Set FTP Server Address .....	172
11.2.8	AT+FTPUN	Set FTP User Name .....	173
11.2.9	AT+FTPPW	Set FTP Password .....	174
11.2.10	AT+FTPGETNAME	Set Download File Name .....	175
11.2.11	AT+FTPGETPATH	Set Download File Path .....	175
11.2.12	AT+FTPPUTNAME	Set Upload File Name .....	176
11.2.13	AT+FTPPUTPATH	Set Upload File Path .....	177
11.2.14	AT+FTPGET	Download File .....	177
11.2.15	AT+FTPPUT	Set Upload File .....	179
11.2.16	AT+FTPDELE	Delete Specified File in FTP Server .....	180
11.2.17	AT+FTPSIZE	Get the Size of Specified File in FTP Server .....	180
11.2.18	AT+FTPSTATE	Get the FTP State .....	181
11.2.19	AT+FTPEXTPUT	Extend Upload File .....	182
11.2.20	AT+FTPMKD	Make Directory on the Remote Machine .....	183
11.2.21	AT+FTPRMD	Remove Directory on the Remote Machine .....	183
11.2.22	AT+FTPLIST	List Contents of Directory on the Remote Machine .....	184
11.2.23	AT+FTPEXTGET	Extend Download File .....	185
11.2.24	AT+FTPETPUT	Upload File .....	186
11.2.25	AT+FTPETGET	Download File .....	187
11.2.26	AT+FTPQUIT	Quit Current FTP Session .....	188
11.2.27	AT+FTPRENAME	Rename the Specified File on the Remote Machine .....	189
11.2.28	AT+FTPMDTM	Get the Last Modification Timestamp of Specified File on the Remote Machine .....	190
<b>12</b>	<b>AT Command for NTP function .....</b>		<b>191</b>
12.1	Overview .....		191
12.2	Detailed Descriptions of Commands .....		191
12.2.1	AT+CNTPCID	Set GPRS Bearer Profile's ID .....	191
12.2.2	AT+CNTP	Synchronize Network Time .....	191
<b>13</b>	<b>AT Commands for OneNet Application .....</b>		<b>194</b>
13.1	Overview .....		194
13.2	Detailed Descriptions of Commands .....		194



13.2.1	AT+MIPLCREATE	Create OneNet configuration.....	194
13.2.2	AT+MIPLDELETE	Delete OneNet configuration.....	195
13.2.3	AT+MIPLOPEN	Connect to OneNet.....	195
13.2.4	AT+MIPLADDOBJ	Add object.....	196
13.2.5	AT+MIPLDELOBJ	Delete Object .....	197
13.2.6	AT+MIPLCLOSE	Disconnect to OneNet.....	197
13.2.7	AT+MIPLNOTIFY	Notify data to OneNet .....	197
13.2.8	AT+MIPLREADRSP	Send response on read command.....	198
13.2.9	AT+MIPLWRITERSP	Send response on write command .....	199
13.2.10	AT+MIPLEXECUTERSP	Send response on execute command .....	200
13.2.11	AT+MIPLOBSERVERSP	Send response on observe command .....	200
13.2.12	AT+MIPLDISCOVERERRSP	Send response on discover command .....	201
13.2.13	AT+MIPLPARAMETERERRSP	Send response on parameter command.....	201
13.2.14	AT+MIPLUPDATE	Update registration .....	202
13.2.15	AT+MIPLVER	Version of OneNet SDK.....	202
13.2.16	AT+MIPLBOOTSTRAP	Bootstrap mode.....	202
14	AT Commands for Telecom IOT Application .....		204
14.1	Overview .....		204
14.2	Detailed Descriptions of Commands.....		204
14.2.1	AT+SIMLCREATE	Create configuration .....	204
14.2.2	AT+SIMLMODE	Connection mode .....	204
14.2.3	AT+SIMLOPEN	Connect to Telecom IOT .....	205
14.2.4	AT+SIMLSEND	Send data to Telecom IOT.....	205
14.2.5	AT+SIMLCLOSE	Disconnect to Telecom IOT .....	206
15	AT Commands for GNSS Application.....		207
15.1	Overview .....		207
15.2	Detailed Descriptions of Commands.....		208
15.2.1	AT+CGNSPWR	GNSS Power Control.....	208
15.2.2	AT+CGNSINF	GNSS Navigation Information Parsed From NMEA Sentences.....	208
15.2.3	AT+CGNSURC	GNSS Navigation URC Report.....	211
15.2.4	AT+CGNSPORT	GNSS NMEA Out Port Set.....	212
15.2.5	AT+CGNSCOLD	GNSS Cold Start.....	212
15.2.6	AT+CGNSWARM	GNSS Warm Start .....	213
15.2.7	AT+CGNSHOT	GNSS Hot Start .....	213
15.2.8	AT+CGNSMOD	GNSS Work Mode Set .....	214
15.2.9	AT+CGNSCFG	GNSS NMEA Out Configure .....	215
15.2.10	AT+CGNSTST	GNSS NMEA Data Out Put To At Port.....	216
15.2.11	AT+CGNSXTRA	GNSS XTRA Function Open.....	217
15.2.12	AT+CGNSCPY	GNSS XTRA File Copy.....	217
16	AT Commands for File System .....		219
16.1	Overview .....		219

16.2	Detailed Descriptions of Commands.....	219
16.2.1	AT+CFSINIT Get Flash Data Buffer.....	219
16.2.2	AT+CFSWFILE Write File to the Flash Buffer Allocated by CFSINIT .....	220
16.2.3	AT+CFSRFILE Read File from Flash .....	220
16.2.4	AT+CFSDFILE Delete the File from the Flash .....	221
16.2.5	AT+CFSGFIS Get File Size.....	222
16.2.6	AT+CFSREN Rename a file .....	223
16.2.7	AT+CFSGFRS Get the size of File System .....	224
16.2.8	AT+CFSTERM Free the Flash Buffer Allocated by CFSINIT.....	224
16.2.9	AT+CBAINIT Initialize the ap backup file system .....	225
16.2.10	AT+CBALIST Set the files which want to backup .....	225
16.2.11	AT+CBAPPS Start to backup ap file system Allocated by CBAINIT and CBALIST	226
16.2.12	AT+CBART Restore the file into ap file system .....	226
17	AT Commands for SIM Application Toolkit .....	227
17.1	Overview .....	227
17.2	Detailed Descriptions of Commands.....	227
17.2.1	AT+STIN SAT Indication.....	227
17.2.2	AT+STGI Get SAT information .....	228
17.2.3	AT+STGR SAT respond.....	229
17.2.4	AT+STK STK Switch .....	231
18	AT Commands for TCP/UDP Application Supported SSL .....	232
18.1	Overview .....	232
18.2	Detailed Descriptions of Commands.....	232
18.2.1	AT+CACID Set TCP/UDP Identifier .....	232
18.2.3	AT+CASSLCFG Set SSL certificate and timeout parameters .....	233
18.2.4	AT+CAOPEN Open a TCP/UDP connection.....	235
18.2.5	AT+CASEND Send data via an established connection .....	236
18.2.6	AT+CARECV Receive data via an established connection .....	237
18.2.7	AT+CACLOSE Close a TCP/UDP connection.....	237
18.2.8	AT+CSSLCFG Configure SSL parameters of a context identifier.....	238
19	Supported Unsolicited Result Codes .....	243
19.1	Summary of CME ERROR Codes .....	243
19.2	Summary of CMS ERROR Codes .....	246
19.3	Summary of Unsolicited Result Codes .....	250

## Version History

Version	Date	Chapter	What is new
V1.00	2018-09-12		New version

# 1 Introduction

## 1.1 Scope of the document

This document presents the AT Command Set for SIMCom Heracles224G.

## 1.2 Related documents

You can visit the SIMCom Website using the following link:

<http://www.simcomm2m.com>

## 1.3 Conventions and abbreviations

In this document, the GSM engines are referred to as following term:

ME (Mobile Equipment);

MS (Mobile Station);

TA (Terminal Adapter);

DCE (Data Communication Equipment) or facsimile DCE (FAX modem, FAX board);

In application, controlling device controls the GSM engine by sending AT Command via its serial interface. The controlling device at the other end of the serial line is referred to as following term:

TE (Terminal Equipment);

DTE (Data Terminal Equipment) or plainly "the application" which is running on an embedded system;

## 1.4 AT Command syntax

The "AT" or "at" or "aT" or "At" prefix must be set at the beginning of each Command line. To terminate a Command line enter **<CR>**.

Commands are usually followed by a response that includes.

**"<CR><LF><response><CR><LF>"**

Throughout this document, only the responses are presented, **<CR><LF>** are omitted intentionally.

The AT Command set implemented by Heracles224G is a combination of 3GPP TS 27.005, 3GPP TS 27.007 and ITU-T recommendation V.25ter and the AT commands developed by SIMCom.

*Note: Only enter AT Command through serial port after Heracles224G is powered on and Unsolicited Result Code "RDY" is received from serial port. If auto-bauding is enabled, the Unsolicited Result Codes "RDY"*

*and so on are not indicated when you start up the ME, and the "AT" prefix, or "at" prefix must be set at the beginning of each command line.*

All these AT commands can be split into three categories syntactically: **"basic"**, **"S parameter"**, and **"extended"**. These are as follows:

#### 1.4.1 Basic syntax

These AT commands have the format of **"AT<x><n>"**, or **"AT&<x><n>"**, where **"<x>"** is the Command, and **"<n>"** is/are the argument(s) for that Command. An example of this is **"ATE<n>"**, which tells the DCE whether received characters should be echoed back to the DTE according to the value of **"<n>"**. **"<n>"** is optional and a default will be used if missing.

#### 1.4.2 S Parameter syntax

These AT commands have the format of **"ATS<n>=<m>"**, where **"<n>"** is the index of the **S** register to set, and **"<m>"** is the value to assign to it. **"<m>"** is optional; if it is missing, then a default value is assigned.

#### 1.4.3 Extended Syntax

These commands can operate in several modes, as in the following table:

**Table 1: Types of AT commands and responses**

Test Command	AT+<x>=?	The mobile equipment returns the list of parameters and value ranges set with the corresponding Write Command or by internal processes.
Read Command	AT+<x>?	This command returns the currently set value of the parameter or parameters.
Write Command	AT+<x>=<...>	This command sets the user-definable parameter values.
Execution Command	AT+<x>	The execution command reads non-variable parameters affected by internal processes in the GSM engine.

#### 1.4.4 Combining AT commands on the same Command line

You can enter several AT commands on the same line. In this case, you do not need to type the **"AT"** or **"at"** prefix before every command. Instead, you only need type **"AT"** or **"at"** the beginning of the command line. Please note to use a semicolon as the command delimiter after an extended command; in basic syntax or S parameter syntax, the semicolon need not enter, for example: **ATE1Q0S0=1S3=13V1X4;+IFC=0,0;+IPR=115200**.

The Command line buffer can accept a maximum of 559 characters (counted from the first command without **"AT"** or **"at"** prefix) or 39 AT commands. If the characters entered exceeded this number then none of the Command will executed and TA will return **"ERROR"**.

### 1.4.5 Entering successive AT commands on separate lines

When you need to enter a series of AT commands on separate lines, please Note that you need to wait the final response (for example OK, CME error, CMS error) of last AT Command you entered before you enter the next AT Command.

## 1.5 Supported character sets

The Heracles224G AT Command interface defaults to the **IRA** character set. The Heracles224G supports the following character sets:

GSM format

UCS2

IRA

The character set can be set and interrogated using the "**AT+CSCS**" Command (3GPP TS 27.007). The character set is defined in GSM specification 3GPP TS 27.005.

The character set affects transmission and reception of SMS and SMS Cell Broadcast messages, the entry and display of phone book entries text field and SIM Application Toolkit alpha strings.

## 1.6 Flow control

Flow control is very important for correct communication between the GSM engine and DTE. For in the case such as a data or fax call, the sending device is transferring data faster than the receiving side is ready to accept. When the receiving buffer reaches its capacity, the receiving device should be capable to cause the sending device to pause until it catches up.

There are basically two approaches to achieve data flow control: software flow control and hardware flow control. Heracles224G support both two kinds of flow control.

In Multiplex mode, it is recommended to use the hardware flow control.

### 1.6.1 Software flow control (XON/XOFF flow control)

Software flow control sends different characters to stop (XOFF, decimal 19) and resume (XON, decimal 17) data flow. It is quite useful in some applications that only use three wires on the serial interface.

The default flow control approach of Heracles224G is hardware flow control (RTS/CTS flow control), to enable software flow control in the DTE interface and within GSM engine, type the following AT Command:

**AT+IFC=1, 1**

Ensure that any communications software package (e.g. Hyper terminal) uses software flow control.

**NOTE:**

Software Flow control should not be used for data calls where binary data will be transmitted or received (e.g. TCP/IP) as the DTE interface may interpret binary data as flow control characters.

### 1.6.2 Hardware flow control (RTS/CTS flow control)

Hardware flow control achieves the data flow control by controlling the RTS/CTS line. When the data transfer should be suspended, the CTS line is set inactive until the transfer from the receiving buffer has completed. When the receiving buffer is ok to receive more data, CTS goes active once again.

To achieve hardware flow control, ensure that the RTS/CTS lines are present on your application platform.

## 1.7 Definitions

### 1.7.1 Parameter Saving Mode

For the purposes of the present document, the following syntactical definitions apply:

- **NO\_SAVE**: The parameter of the current AT command will be lost if module is rebooted or current AT command doesn't have parameter.
- **AUTO\_SAVE**: The parameter of the current AT command will be kept in NVRAM automatically and take in effect immediately, and it won't be lost if module is rebooted.
- **AUTO\_SAVE\_REBOOT**: The parameter of the current AT command will be kept in NVRAM automatically and take in effect after reboot, and it won't be lost if module is rebooted.
- -: "-" means this AT command doesn't care the parameter saving mode.

### 1.7.2 Max Response Time

Max response time is estimated maximum time to get response, the unit is seconds.

"-" means this AT command doesn't care the response time.

## 2 AT Commands According to V.25TER

These AT Commands are designed according to the ITU-T (International Telecommunication Union, Telecommunication sector) V.25ter document.

### 2.1 Overview of AT Commands According to V.25TER

Command	Description
A/	Re-issues the last command given
ATD	Mobile originated call to dial a number
ATE	Set command echo mode
ATH	Disconnect existing connection
ATI	Display product identification information
ATL	Set monitor speaker loudness
ATM	Set monitor speaker mode
+++	Switch from data mode or ppp online mode to command mode
ATO	Switch from command mode to data mode
ATQ	Set result code presentation mode
ATS0	Set number of rings before automatically answering the call
ATS3	Set command line termination character
ATS4	Set response formatting character
ATS5	Set command line editing character
ATS6	Pause before blind dialling
ATS7	Set number of seconds to wait for connection completion
ATS8	Set number of seconds to wait for comma dial modifier encountered in dial string of D command
ATS10	Set disconnect delay after indicating the absence of data carrier
ATV	TA response format
ATX	Set connect result code format and monitor call progress
ATZ	Reset default configuration
AT&C	Set DCD function mode
AT&D	Set DTR function mode
AT&F	Factory defined configuration
AT&V	Display current configuration
AT&E	Set CONNECT Result Code Format About Speed
AT+GCAP	Request complete TA capabilities list



AT+GMI	Request manufacturer identification
AT+GMM	Request TA model identification
AT+GMR	Request TA revision identification of software release
AT+GOI	Request global object identification
AT+GSN	Request TA serial number identification (IMEI)
AT+ICF	Set TE-TA control character framing
AT+IFC	Set TE-TA local data flow control
AT+IPR	Set TE-TA fixed local rate

## 2.2 Detailed Description of AT Commands According to V.25TER

### 2.2.1 A/ Re-issues the Last Command Given

A/ Re-issues the Last Command Given	
Execution Command A/	Response Re-issues the previous Command
Reference V.25ter	Note

### 2.2.2 ATD Mobile Originated Call to Dial A Number

ATD Mobile Originated Call to Dial A Number	
Execution Command ATD<n>[<mgsms ]	<p>Response</p> <p>This command can be used to set up outgoing data calls. It also serves to control supplementary services.</p> <p>Note: This command may be aborted generally by receiving an <b>ATH</b> Command or a character during execution. The aborting is not possible during some states of connection establishment such as handshaking.</p> <p>If error is related to ME functionality <b>+CME ERROR: &lt;err&gt;</b></p> <p>If no dial tone and (parameter setting <b>ATX2</b> or <b>ATX4</b>) <b>NO DIALTONE</b></p> <p>If busy and (parameter setting <b>ATX3</b> or <b>ATX4</b>) <b>BUSY</b></p> <p>If a connection cannot be established <b>NO CARRIER</b></p>

	<p>If the remote station does not answer <b>NO ANSWER</b></p> <p>If connection successful and non-voice call. <b>CONNECT&lt;text&gt;</b> TA switches to data mode. Note: &lt;text&gt; output only if <b>ATX&lt;value&gt;</b> parameter setting with the &lt;value&gt; &gt;0</p> <p>When TA returns to command mode after call release <b>OK</b></p> <p>Parameters</p> <p>&lt;n&gt; String of dialing digits and optionally V.25ter modifiers dialing digits: <b>0-9, *, #, +, A, B, C</b> Following V.25ter modifiers are ignored: <b>, (comma), T, P, !, W, @</b></p> <p><b>Emergency call:</b></p> <p>&lt;n&gt; Standardized emergency number 112 (no SIM needed)</p> <p>&lt;mgs&gt; String of <b>GSM</b> modifiers:</p> <p><b>I</b> Activates <b>CLIR</b> (Disables presentation of own number to called party)</p> <p><b>i</b> Deactivates <b>CLIR</b> (Enable presentation of own number to called party)</p> <p><b>G</b> Activates Closed User Group invocation for this call only</p> <p><b>g</b> Deactivates Closed User Group invocation for this call only</p>
Parameter Saving Mode	NO_SAVE
Max Response Time	Timeout set with AT57 (data call)
Reference V.25ter	Note

### 2.2.3 ATE Set Command Echo Mode

ATE Set Command Echo Mode	
Execution Command <b>ATE&lt;value&gt;</b>	<p>Response</p> <p>This setting determines whether or not the TA echoes characters received from TE during Command state. <b>OK</b></p> <p>Parameters</p>

	<b>&lt;value&gt;</b> 0   Echo mode off <u>1</u> Echo mode on
Parameter Saving Mode	
Max Response Time	-
Reference V.25ter	Note

#### 2.2.4    ATH    Disconnect Existing Connection

ATH    Disconnect Existing Connection	
Execution Command <b>ATH</b>	Response Disconnect existing call by local TE from Command line and terminate call <b>OK</b> Note: OK is issued after circuit 109(DCD) is turned off, if it was previously on.
Parameter Saving Mode	NO_SAVE
Max Response Time	20s
Reference V.25ter	Note

#### 2.2.5    ATI    Display Product Identification Information

ATI    Display Product Identification Information	
Execution Command <b>ATI</b>	Response TA issues product information text  Example: Heracles224G R1351  <b>OK</b>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference V.25ter	Note

## 2.2.6 ATL Set Monitor speaker loudness

ATL Set Monitor speaker loudness	
Execution Command <b>ATL&lt;value&gt;</b>	Response <b>OK</b>
	Parameters <b>&lt;value&gt; 0..3 Volume</b>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference V.25ter	Note No effect in GSM

## 2.2.7 ATM Set Monitor Speaker Mode

ATM Set Monitor Speaker Mode	
Execution Command <b>ATM&lt;value&gt;</b>	Response <b>OK</b>
	Parameters <b>&lt;value&gt; 0..2 Mode</b>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference V.25ter	Note No effect in GSM

## 2.2.8 +++ Switch from Data Mode or PPP Online Mode to Command Mode

+++ Switch from Data Mode or PPP Online Mode to Command Mode	
Execution Command <b>+++</b>	Response The +++ character sequence causes the TA to cancel the data flow over the AT interface and switch to Command mode. This allows you to enter AT Command while maintaining the data connection to the remote server. <b>OK</b>  To prevent the +++ escape sequence from being misinterpreted as data, it should comply to following sequence: No characters entered for T1 time (1 second) "+++" characters entered with no characters in between (1 second) No characters entered for T1 timer (1 second) Switch to Command mode, otherwise go to step 1.

Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference V.25ter	Note To return from Command mode back to data mode: Enter <b>ATO</b> .

### 2.2.9 ATO Switch from Command Mode to Data Mode

ATO Switch from Command Mode to Data Mode	
Execution Command ATO[n]	<p>Response</p> <p>TA resumes the connection and switches back from command mode to data mode.</p> <p><b>CONNECT</b> If connection is not successfully resumed</p> <p><b>ERROR</b> else TA returns to data mode from command mode <b>CONNECT &lt;text&gt;</b> Note: &lt;text&gt; only if parameter setting <b>ATX&gt;0</b></p> <p>Parameter &lt;n&gt; 0 Switch from command mode to data mode.</p>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference V.25ter	Note

### 2.2.10 ATQ Set Result Code Presentation Mode

ATQ Set Result Code Presentation Mode	
Execution Command ATQ<n>	<p>Response</p> <p>This parameter setting determines whether or not the TA transmits any result code to the TE. Information text transmitted in response is not affected by this setting.</p> <p>If &lt;n&gt;=0: <b>OK</b></p> <p>If &lt;n&gt;=1: (none)</p> <p>Parameters &lt;n&gt; 0 TA transmits result code</p>

	1 Result codes are suppressed and not transmitted
Parameter Saving Mode	
Max Response Time	-
Reference V.25ter	Note

### 2.2.11 ATSO Set Number of Rings before Automatically Answering the Call

ATSO Set Number of Rings before Automatically Answering the Call	
Read Command ATSO?	Response <n>  <b>OK</b>  Parameters See Write Command
Write Command ATSO=<n>	Response This parameter setting determines the number of rings before auto-answer. <b>OK</b>  <b>ERROR</b>  Parameters <n>      0      Automatic answering is disable. 1-255    Number of rings the modem will wait for before answering the phone if a ring is detected.
Parameter Saving Mode	-
Max Response Time	-
Reference V.25ter	Note If <n> is set too high, the calling party may hang up before the call can be answered automatically. If using cmux port, <b>ATH</b> and <b>AT+CHUP</b> can hang up the call (automatically answering) only in the CMUX channel 0. If using dual-physical serial port, <b>ATH</b> and <b>AT+CHUP</b> can hang up the call (automatically answering) only in UART1.

### 2.2.12 ATS3 Set Command Line Termination Character

ATS3 Set Command Line Termination Character	
Read Command ATS3?	Response <n>

	<p><b>OK</b></p> <p>Parameters See Write Command</p>
Write Command <b>ATS3=&lt;n&gt;</b>	<p>Response</p> <p>This parameter setting determines the character recognized by TA to terminate an incoming command line. The TA also returns this character in output.</p> <p><b>OK</b></p> <p><b>ERROR</b></p> <p>Parameters &lt;n&gt;    <u>13</u>    Command line termination character</p>
Parameter Saving Mode	-
Max Response Time	-
Reference V.25ter	<p>Note</p> <p>Default 13 = CR. It only supports default value.</p>

### 2.2.13 ATS4 Set Response Formatting Character

<b>ATS4 Set Response Formatting Character</b>	
Read Command <b>ATS4?</b>	<p>Response</p> <p>&lt;n&gt;</p> <p><b>OK</b></p> <p>Parameters See Write Command</p>
Write Command <b>ATS4=&lt;n&gt;</b>	<p>Response</p> <p>This parameter setting determines the character generated by the TA for result code and information text.</p> <p><b>OK</b></p> <p><b>ERROR</b></p> <p>Parameters &lt;n&gt;    <u>10</u>    Response formatting character</p>
Parameter Saving Mode	-
Max Response Time	-
Reference	Note

V.25ter	Default 10 = LF. It only supports default value.
---------	--

#### 2.2.14 ATS5 Set Command Line Editing Character

ATS5 Set Command Line Editing Character	
Read Command ATS5?	Response < n >  <b>OK</b>  Parameters See Write Command
Write Command ATS5=< n >	Response This parameter setting determines the character recognized by TA as a request to delete from the command line the immediately preceding character. <b>OK</b>  <b>ERROR</b>  Parameters < n >     0-8-127     Response formatting character
Parameter Saving Mode	-
Max Response Time	-
Reference V.25ter	Note Default 8 = Backspace.

#### 2.2.15 ATS6 Pause Before Blind Dialling

ATS6 Pause Before Blind Dialling	
Read Command ATS6?	Response < n >  <b>OK</b>
Write Command ATS6=< n >	Response <b>OK</b>  <b>ERROR</b>  Parameters < n >     0-2-999     Time
Parameter Saving Mode	-
Max Response	-



Time	
Reference	Note
V.25ter	No effect in GSM

### 2.2.16 ATS7 Set Number of Seconds to Wait for Connection Completion

ATS7 Set Number of Seconds to Wait for Connection Completion	
Read Command ATS7?	Response <n>
	OK
	Parameters See Write Command
Write Command ATS7=<n>	Response This parameter setting determines the amount of time to wait for the connection completion in case of answering or originating a call. OK
	ERROR
	Parameters <n>     0-255     Number of seconds to wait for connection completion
Parameter Saving Mode	-
Max Response Time	-
Reference V.25ter	Note If called party has specified a high value for ATS0=<n>, call setup may fail. The correlation between ATS7 and ATS0 is important Example: Call may fail if ATS7=30 and ATS0=20. ATS7 is only applicable to data call.

### 2.2.17 ATS8 Set Number of Seconds to Wait for Comma Dial Modifier Encountered in Dial String of D Command

ATS8 Set Number of Seconds to Wait for Comma Dial Modifier Encountered in Dial String of D Command	
Read Command ATS8?	Response <n>
	OK
	Parameters See Write Command
Write Command	Response

ATS8=<n>	<b>OK</b>
	<b>ERROR</b>
	Parameters <n> 0- <u>2</u> -255 The value of this register determines how long the modem should pause when it sees a comma in the dialing string.
Parameter Saving Mode	-
Max Response Time	-
Reference V.25ter	Note No effect in GSM

### 2.2.18 ATS10 Set Disconnect Delay after Indicating the Absence of Data Carrier

ATS10 Set Disconnect Delay after Indicating the Absence of Data Carrier	
Read Command ATS10?	Response <n>
	<b>OK</b>
	Parameters See Write Command
Write Command ATS10=<n>	Response This parameter setting determines the amount of time that the TA will remain connected in absence of data carrier. If the data carrier is once more detected before disconnecting, the TA remains connected.
	<b>OK</b>
	<b>ERROR</b>
	Parameters <n> 1- <u>14</u> -255 Number of tenths seconds of delay
Parameter Saving Mode	-
Max Response Time	-
Reference V.25ter	Note

### 2.2.19 ATV TA Response Format

ATV TA Response Format	
Execution Command	Response This parameter setting determines the contents of the header and trailer

<b>ATV&lt;value&gt;</b>	<p>transmitted with result codes and information responses.</p> <p>When &lt;value&gt;=0</p> <p><b>0</b></p> <p>When &lt;value&gt;=1</p> <p><b>OK</b></p> <p>Parameters</p> <p>&lt;value&gt;    0    Information response: &lt;text&gt;&lt;CR&gt;&lt;LF&gt;  Short result code format: &lt;numeric code&gt;&lt;CR&gt;  1    Information response: &lt;CR&gt;&lt;LF&gt;&lt;text&gt;&lt;CR&gt;&lt;LF&gt;  Long result code format: &lt;CR&gt;&lt;LF&gt;&lt;verbose code&gt;  &lt;CR&gt;&lt;LF&gt;</p> <p>The result codes, their numeric equivalents and brief descriptions of the use of each are listed in the following table.</p>
Parameter Saving Mode	-
Max Response Time	-
Reference V.25ter	Note

ATV1	ATV0	Description
OK	0	Acknowledges execution of a Command
CONNECT	1	A connection has been established; the DCE is moving from Command state to online data state
RING	2	The DCE has detected an incoming call signal from network
NO CARRIER	3	The connection has been terminated or the attempt to establish a connection failed
ERROR	4	Command not recognized, Command line maximum length exceeded, parameter value invalid, or other problem with processing the Command line
NO DIALTONE	6	No dial tone detected
BUSY	7	Engaged (busy) signal detected
NO ANSWER	8	"@" (Wait for Quiet Answer) dial modifier was used, but remote ringing followed by five seconds of silence was not detected before expiration of the connection timer (S7)
PROCEEDING	9	An AT command is being processed
CONNECT <text>	Manufacturer-specific	Same as CONNECT, but includes manufacturer-specific text that may specify DTE speed, line speed, error control, data compression, or other status

## 2.2.20 ATX Set CONNECT Result Code Format and Monitor Call Progress

ATX Set CONNECT Result Code Format and Monitor Call Progress	
Execution Command <b>ATX&lt;value&gt;</b>	<p>Response</p> <p>This parameter setting determines whether or not the TA detected the presence of dial tone and busy signal and whether or not TA transmits particular result codes.</p> <p><b>OK</b></p> <p><b>ERROR</b></p> <p>Parameters</p> <p><b>&lt;value&gt;</b>    0    <b>CONNECT</b> result code only returned, dial tone and busy detection are both disabled.</p> <p>                 1    <b>CONNECT&lt;text&gt;</b> result code only returned, dial tone and busy detection are both disabled.</p> <p>                 2    <b>CONNECT&lt;text&gt;</b> result code returned, dial tone detection is enabled, busy detection is disabled.</p> <p>                 3    <b>CONNECT&lt;text&gt;</b> result code returned, dial tone detection is disabled, busy detection is enabled.</p> <p>                 4    <b>CONNECT&lt;text&gt;</b> result code returned, dial tone and busy detection are both enabled.</p>
Parameter Saving Mode	-
Max Response Time	-
Reference V.25ter	Note

## 2.2.21 AT&C Set DCD Function Mode

AT&C Set DCD Function Mode	
Execution Command <b>AT&amp;C&lt;value&gt;</b>	<p>Response</p> <p>This parameter determines how the state of circuit 109 (<b>DCD</b>) relates to the detection of received line signal from the distant end.</p> <p><b>OK</b></p> <p><b>ERROR</b></p> <p>Parameters</p> <p><b>&lt;value&gt;</b>    0    <b>DCD</b> line is always ON</p> <p>                 1    <b>DCD</b> line is ON only in the presence of data carrier</p>
Parameter Saving Mode	-
Max Response	-

Time	
Reference V.25ter	Note

### 2.2.22 AT&D Set DTR Function Mode

AT&D Set DTR Function Mode	
Execution Command AT&D[<value>]	<p>Response</p> <p>This parameter determines how the TA responds when circuit 108/2 (DTR) is changed from the ON to the OFF condition during data mode.</p> <p><b>OK</b></p> <p>or</p> <p><b>ERROR</b></p> <p>Parameters</p> <p>&lt;value&gt;    0    TA ignores status on DTR.</p> <p>              1    ON-&gt;OFF on DTR: Change to Command mode with remaining the connected call.</p> <p>              2    ON-&gt;OFF on DTR: Disconnect call, change to Command mode. During state DTR = OFF is auto-answer off.</p>
Parameter Saving Mode	-
Max    Response Time	-
Reference V.25ter	Note

### 2.2.23 AT&E Set CONNECT Result Code Format About Speed

AT&E Set CONNECT Result Code Format About Speed	
Execution Command AT&E[<value>]	<p>This parameter setting determines to report Serial connection rate or Wireless connection speed. It is valid only ATX above 0.</p> <p>Response</p> <p><b>OK</b></p> <p>or</p> <p><b>ERROR</b></p> <p>Parameters</p> <p>&lt;value&gt;</p> <p>              0    Wireless connection speed in integer format.</p> <p>              1    Serial connection rate in integer format. Such as: "115200"</p>
Parameter Saving Mode	NO_SAVE
Max    Response Time	-

Reference V.25ter	Note
----------------------	------

#### 2.2.24 AT+GCAP Request Complete TA Capabilities List

AT+GCAP Request Complete TA Capabilities List	
Execution Command <b>AT+GCAP</b>	Response TA reports a list of additional capabilities. <b>+GCAP:</b> list of supported <name>s  <b>OK</b>
	Parameters <name>    +CGSM    GSM function is supported
Parameter Saving Mode	NO_SAVE
Max    Response Time	-
Reference V.25ter	Note

#### 2.2.25 AT+GMI Request Manufacturer Identification

AT+GMI Request Manufacturer Identification	
Test Command <b>AT+GMI=?</b>	Response <b>OK</b>
	Parameters
Execution Command <b>AT+GMI</b>	TA reports one or more lines of information text which permit the user to identify the manufacturer. <b>SIMCOM_Ltd</b>  <b>OK</b>
Parameter Saving Mode	NO_SAVE
Max    Response Time	-
Reference V.25ter	Note

#### 2.2.26 AT+GMM Request TA Model Identification

AT+GMM Request TA Model Identification
--

Test Command <b>AT+GMM=?</b>	Response <b>OK</b>
Execution Command <b>AT+GMM</b>	TA reports one or more lines of information text which permit the user to identify the specific model of device. <b>&lt;model&gt;</b>  <b>OK</b>
	Parameters <b>&lt;model&gt;</b> Product model identification text
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference V.25ter	Note

### 2.2.27 AT+GMR Request TA Revision Identification of Software Release

AT+GMR Request TA Revision Identification of Software Release	
Test Command <b>AT+GMR=?</b>	Response <b>OK</b>
Execution Command <b>AT+GMR</b>	TA reports one or more lines of information text which permit the user to identify the revision of software release. <b>Revision: &lt;revision&gt;</b>  <b>OK</b>
	Parameters <b>&lt;revision&gt;</b> Revision of software release
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference V.25ter	Note

### 2.2.28 AT+GOI Request Global Object Identification

AT+GOI Request Global Object Identification
---

Test Command <b>AT+GOI=?</b>	Response <b>OK</b>
Execution Command <b>AT+GOI</b>	Response TA reports one or more lines of information text which permit the user to identify the device, based on the ISO system for registering unique object identifiers. <b>&lt;Object Id&gt;</b>  <b>OK</b>
	Parameters <b>&lt;Object Id&gt;</b> Identifier of device type see X.208, 209 for the format of <Object Id>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference V.25ter	Note

### 2.2.29 AT+GSN Request TA Serial Number Identification (IMEI)

<b>AT+GSN Request TA Serial Number Identification(IMEI)</b>	
Test Command <b>AT+GSN=?</b>	Response <b>OK</b>
Execution Command <b>AT+GSN</b>	Response TA reports the IMEI (international mobile equipment identifier) number in information text which permit the user to identify the individual ME device. <b>&lt;sn&gt;</b>  <b>OK</b>
	Parameters <b>&lt;sn&gt;</b> IMEI of the telephone(International Mobile station Equipment Identity)
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference V.25ter	Note The serial number (IMEI) is varied by individual ME device.



## 2.2.30 AT+ICF Set TE-TA Control Character Framing

AT+ICF Set TE-TA Control Character Framing	
Test Command <b>AT+ICF=?</b>	Response <b>+ICF:</b> (list of supported <b>&lt;format&gt;</b> s),(list of supported <b>&lt;parity&gt;</b> s)  <b>OK</b>  Parameters See Write Command
Read Command <b>AT+ICF?</b>	Response <b>+ICF:</b> <b>&lt;format&gt;</b> , <b>&lt;parity&gt;</b>  <b>OK</b>  Parameters See Write Command
Write Command <b>AT+ICF=&lt;format&gt;[,&lt;parity&gt;]</b>	Response This parameter setting determines the serial interface character framing format and parity received by TA from TE.  <b>OK</b>  Parameters <b>&lt;format&gt;</b> 1    8 data 0 parity 2 stop 2    8 data 1 parity 1 stop 3    8 data 0 parity 1 stop 4    7 data 0 parity 2 stop 5    7 data 1 parity 1 stop 6    7 data 0 parity 1 stop <b>&lt;parity&gt;</b> 0    odd 1    even 3    space (0)
Parameter Saving Mode	-
Max Response Time	-
Reference V.25ter	Note The Command is applied for Command state; In <b>&lt;format&gt;</b> parameter, "0 parity" means no parity; The <b>&lt;parity&gt;</b> field is ignored if the <b>&lt;format&gt;</b> field specifies no parity and string " <b>+ICF: &lt;format&gt;,255</b> " will be response to " <b>AT+ICF?</b> " Command.

## 2.2.31 AT+IFC Set TE-TA Local Data Flow Control

### AT+IFC Set TE-TA Local Data Flow Control

Test Command <b>AT+IFC=?</b>	<p>Response</p> <p><b>+IFC:</b> (list of supported <b>&lt;dce_by_dte&gt;s</b>),(list of supported <b>&lt;dte_by_dce&gt;s</b>)</p> <p><b>OK</b></p> <p>Parameters</p> <p>See Write Command</p>
Read Command <b>AT+IFC?</b>	<p>Response</p> <p><b>+IFC:</b> <b>&lt;dce_by_dte&gt;</b>,<b>&lt;dte_by_dce&gt;</b></p> <p><b>OK</b></p> <p>Parameters</p> <p>See Write Command</p>
Write Command <b>AT+IFC=&lt;dce_by_dte&gt;[,&lt;dte_by_dce&gt;]</b>	<p>Response</p> <p>This parameter setting determines the data flow control on the serial interface for data mode.</p> <p><b>OK</b></p> <p>Parameters</p> <p><b>&lt;dce_by_dte&gt;</b> Specifies the method will be used by TE at receive of data from TA</p> <p>0 No flow control 1 Software flow control 2 Hardware flow control</p> <p><b>&lt;dte_by_dce&gt;</b> Specifies the method will be used by TA at receive of data from TE</p> <p>0 No flow control 1 Software flow control 2 Hardware flow control</p>
Parameter Saving Mode	-
Max Response Time	-
Reference V.25ter	Note

### 2.2.32 AT+IPR Set TE-TA Fixed Local Rate

<b>AT+IPR Set TE-TA Fixed Local Rate</b>	
Test Command <b>AT+IPR=?</b>	<p>Response</p> <p><b>+IPR:</b> (list of supported auto detectable <b>&lt;rate&gt;s</b>),(list of supported fixed-only <b>&lt;rate&gt;s</b>)</p>

	<b>OK</b>
	Parameters See Write Command
Read Command <b>AT+IPR?</b>	Response <b>+IPR: &lt;rate&gt;</b>
	<b>OK</b> Parameters See Write Command
Write Command <b>AT+IPR=&lt;rate&gt;</b>	Response This parameter setting determines the data rate of the TA on the serial interface. The rate of Command takes effect following the issuance of any result code associated with the current Command line. <b>OK</b>
	Parameters <b>&lt;rate&gt;</b> Baud rate per second 0 300 600 1200 2400 4800 9600 19200 38400 57600 115200 230400 921600 2000000 2900000 3000000 3200000 3686400 4000000
Parameter Saving Mode	AUTO_SAVE
Max Response Time	-
Reference V.25ter	Note

### 3 AT Commands According to 3GPP TS 27.007

#### 3.1 Overview of AT Command According to 3GPP TS 27.007

Command	Description
AT+CGMI	Request manufacturer identification
AT+CGMM	Request model identification
AT+CGMR	Request TA revision identification of software release
AT+CGSN	Request product serial number identification (identical with +GSN)
AT+CSCS	Select TE character set
AT+CIMI	Request international mobile subscriber identity
AT+CLCK	Facility lock
AT+CMEE	Report mobile equipment error
AT+COPS	Operator selection
AT+CPAS	Phone activity status
AT+CPIN	Enter PIN
AT+CPWD	Change password
AT+CRC	Set cellular result codes for incoming call indication
AT+CREG	Network registration
AT+CRSM	Restricted SIM access
AT+CSQ	Signal quality report
AT+CPOL	Preferred operator list
AT+COPN	Read operator names
AT+CFUN	Set phone functionality
AT+CCLK	Clock
AT+CSIM	Generic SIM access
AT+CBC	Battery charge
AT+CUSD	Unstructured supplementary service data
AT+CNUM	Subscriber Number

#### 3.2 Detailed Descriptions of AT Command According to 3GPP TS 27.007

##### 3.2.1 AT+CGMI Request Manufacturer Identification

AT+CGMI Request Manufacturer Identification	
Test Command	Response
AT+CGMI=?	OK
Execution	Response

Command <b>AT+CGMI</b>	TA returns manufacturer identification text. <b>&lt;manufacturer&gt;</b>
	<b>OK</b>
	Parameters <b>&lt;manufacturer&gt;</b> The ID of manufacturer
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference 3GPP TS 27.007 [13]	Note

### 3.2.2 AT+CGMM Request Model Identification

<b>AT+CGMM Request Model Identification</b>	
Test Command <b>AT+CGMM=?</b>	Response <b>OK</b>
Execution Command <b>AT+CGMM</b>	Response TA returns product model identification text. <b>&lt;model&gt;</b>
	<b>OK</b>
	Parameters <b>&lt;model&gt;</b> Product model identification text
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference 3GPP TS 27.007 [13]	Note

### 3.2.3 AT+CGMR Request TA Revision Identification of Software Release

<b>AT+CGMR Request TA Revision Identification of Software Release</b>	
Test Command <b>AT+CGMR=?</b>	Response <b>OK</b>
Execution Command <b>AT+CGMR</b>	Response TA returns product software version identification text. <b>Revision: &lt;revision&gt;</b>

	<b>OK</b>
	Parameters <revision>      Product software version identification text
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference 3GPP TS 27.007 [13]	Note

### 3.2.4 AT+CGSN Request Product Serial Number Identification

AT+CGSN Request Product Serial Number Identification (Identical with +GSN)	
Test Command <b>AT+CGSN=?</b>	Response <b>OK</b>
Execution Command <b>AT+CGSN</b>	Response see +GSN <sn>
	<b>OK</b>
	Parameters <sn>      International mobile equipment identity (IMEI)
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference 3GPP TS 27.007 [13]	Note

### 3.2.5 AT+CSCS Select TE Character Set

AT+CSCS Select TE Character Set	
Test Command <b>AT+CSCS=?</b>	Response <b>+CSCS:</b> (list of supported <chset>s)
	<b>OK</b>
	Parameters <chset>      "GSM"    GSM 7 bit default alphabet (3GPP TS 23.038); "UCS2"    16-bit universal multiple-octet coded character set (ISO/IEC10646); UCS2 character strings are converted to hexadecimal numbers from 0000 to FFFF; e.g.

	<p>"004100620063" equals three 16-bit characters with decimal values 65, 98 and 99</p> <p><u>"IRA"</u> International reference alphabet (ITU-T T.50)</p>
Read Command <b>AT+CSCS?</b>	<p>Response</p> <p><b>+CSCS: &lt;chset&gt;</b></p> <p><b>OK</b></p> <p>Parameters</p> <p>See Test Command</p>
Write Command <b>AT+CSCS=&lt;chset&gt;</b>	<p>Response</p> <p>Sets which character set &lt;chset&gt; are used by the TE. The TA can then convert character strings correctly between the TE and ME character sets.</p> <p><b>OK</b></p> <p>If error is related to ME functionality:</p> <p><b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters</p> <p>See Test Command</p>
Parameter Saving Mode	
Max Response Time	-
Reference 3GPP TS 27.007 [13]	Note

### 3.2.6 AT+CIMI Request International Mobile Subscriber Identity

<b>AT+CIMI Request International Mobile Subscriber Identity</b>	
Test Command <b>AT+CIMI=?</b>	<p>Response</p> <p><b>OK</b></p>
Execution Command <b>AT+CIMI</b>	<p>Response</p> <p>TA returns &lt;IMSI&gt; for identifying the individual SIM which is attached to ME.</p> <p>&lt;IMSI&gt;</p> <p><b>OK</b></p> <p>If error is related to ME functionality:</p> <p><b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters</p> <p>&lt;IMSI&gt; International Mobile Subscriber Identity (string without double quotes)</p>
Parameter Saving Mode	NO_SAVE

Max Response Time	20s
Reference 3GPP TS 27.007 [13]	Note

### 3.2.7 AT+CLCK Facility Lock

AT+CLCK Facility Lock	
Test Command <b>AT+CLCK=?</b>	Response <b>+CLCK:</b> (list of supported <fac>s)  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+CLCK=&lt;fac&gt; ,&lt;mode&gt;[,&lt;passwd&gt;[,&lt;class&gt;]]</b>	Response This Command is used to lock, unlock or interrogate a ME or a network facility <fac>. Password is normally needed to do such actions. When querying the status of a network service (<mode>=2) the response line for 'not active' case (<status>=0) should be returned only if service is not active for any <class>.  If <mode>≠2 and Command is successful <b>OK</b> If <mode>=2 and Command is successful <b>+CLCK: &lt;status&gt;[,&lt;class1&gt;[&lt;CR&gt;&lt;LF&gt;+CLCK: &lt;status&gt;,&lt;class2&gt;[...]]</b>  <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <fac>  <div style="margin-left: 40px;"> "AB" All Barring services(only for &lt;mode&gt;=0)  "AC" All inComing barring services(only for &lt;mode&gt;=0)  "AG" All outGoing barring services(only for &lt;mode&gt;=0)  "AI" BAIC (Barr All Incoming Calls)  "AO" BAOB (Barr All Outgoing Calls)  "IR" BIC-Roam (Barr Incoming Calls when Roaming outside the home country)  "OI" BOIC (Barr Outgoing International Calls)  "OX" BOIC-exHC (Barr Outgoing International Calls except to Home Country) </div>



	<p>"SC" SIM (lock SIM/UICC card) (SIM/UICC asks password in MT power-up and when this lock command issued) Correspond to PIN1 code.</p> <p>"FD" SIM card or active application in the UICC (GSM or USIM) fixed dialling memory feature (if PIN2 authentication has not been done during the current session, PIN2 is required as &lt;passwd&gt;)</p> <p>"PN" Network Personalization, Correspond to NCK code</p> <p>"PU" Network subset Personalization Correspond to NSCK code</p> <p>"PP" Service Provider Personalization Correspond to SPCK code</p> <p>&lt;mode&gt;     0    unlock               1    lock               2    query status</p> <p>&lt;passwd&gt;    String type (Shall be the same as password specified for the facility from the MT user interface or with command Change Password +CPWD)</p> <p>&lt;class&gt;     1-255               1    Voice (telephony)               2    Data refers to all bearer services; with &lt;mode&gt;=2 this may refer only to some bearer service if TA does not support values 16, 32, 64 and 128)               4    Fax (facsimile services)               7    All classes</p> <p>&lt;status&gt;    0    Not active               1    Active</p>
Parameter    Saving Mode	NO_SAVE
Max        Response Time	15s
Reference 3GPP TS 27.007 [14]	<p>Note</p> <ul style="list-style-type: none"> <li>● CME errors if SIM not inserted or PIN is not entered.</li> </ul>

### 3.2.8 AT+CMEE Report Mobile Equipment Error

AT+CMEE Report Mobile Equipment Error	
Test Command AT+CMEE=?	Response
	+CMEE: (list of supported <n>s)
	<b>OK</b>
	Parameters
	See Write Command

<p>Read Command <b>AT+CMEE?</b></p>	<p>Response <b>+CMEE: &lt;n&gt;</b></p> <p><b>OK</b></p> <p>Parameters See Write Command</p>
<p>Write Command <b>AT+CMEE=[&lt;n&gt; &lt;n&gt;]</b></p>	<p>Response TA disables or enables the use of result code <b>+CME ERROR: &lt;err&gt;</b> as an indication of an error relating to the functionality of the ME. <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters <b>&lt;n&gt;</b>    <u>0</u>    Disable <b>+CME ERROR: &lt;err&gt;</b> result code and use ERROR instead.           1    Enable <b>+CME ERROR: &lt;err&gt;</b> result code and use numeric <b>&lt;err&gt;</b>           2    Enable <b>+CME ERROR: &lt;err&gt;</b> result code and use verbose <b>&lt;err&gt;</b> values</p>
<p>Parameter Saving Mode</p>	
<p>Max Response Time</p>	<p>-</p>
<p>Reference 3GPP TS 27.007 [13]</p>	<p>Note</p>

### 3.2.9 AT+COPS Operator Selection

<b>AT+COPS Operator Selection</b>	
<p>Test Command <b>AT+COPS=?</b></p>	<p>Response TA returns a list of quadruplets, each representing an operator present in the network. Any of the formats may be unavailable and should then be an empty field. The list of operators shall be in order: home network, networks referenced in SIM, and other networks.</p> <p><b>+COPS:</b> (list of supported&lt;stat&gt;,long alphanumeric&lt;oper&gt;,short alphanumeric&lt;oper&gt;,numeric &lt;oper&gt;,&lt;netact&gt;)s[,,(list of supported &lt;mode&gt;s),(list of supported &lt;format&gt;s)]</p> <p><b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p>

	<p>Parameters</p> <p>See Write Command</p>
<p>Read Command</p> <p><b>AT+COPS?</b></p>	<p>Response</p> <p>TA returns the current mode and the currently selected operator. If no operator is selected, &lt;format&gt; and &lt;oper&gt; are omitted.</p> <p><b>+COPS: &lt;mode&gt;[,&lt;format&gt;,&lt;oper&gt;,&lt;netact&gt;]</b></p> <p><b>OK</b></p> <p>If error is related to ME functionality:</p> <p><b>+CME ERROR: &lt;err&gt;</b></p>
	<p>Parameters</p> <p>See Write Command</p>
<p>Write Command</p> <p><b>AT+COPS=&lt;mode&gt;[,&lt;format&gt;[,&lt;oper&gt;]]</b></p>	<p>Response</p> <p>TA forces an attempt to select and register the GSM network operator. If the selected operator is not available, no other operator shall be selected (except &lt;mode&gt;=4). The selected operator name format shall apply to further read commands (AT+COPS?).</p> <p><b>OK</b></p> <p>If error is related to ME functionality:</p> <p><b>+CME ERROR: &lt;err&gt;</b></p>
	<p>Parameters</p> <p><b>&lt;stat&gt;</b>      0   Unknown                         1   Operator available                         2   Operator current                         3   Operator forbidden</p> <p><b>&lt;oper&gt;</b>      Refer to [27.007]                         operator in format as per &lt;format&gt;</p> <p><b>&lt;mode&gt;</b>      0   Automatic mode; &lt;oper&gt; field is ignored                         1   Manual (&lt;oper&gt; field shall be present, and &lt;Act&gt; optionally)                         2   manual deregister from network                         3   set only &lt;format&gt; (for read Command +COPS?) - not shown in Read Command response                         4   Manual/automatic (&lt;oper&gt; field shall be present); if manual selection fails, automatic mode (&lt;mode&gt;=0) is entered</p> <p><b>&lt;format&gt;</b>      0   Long format alphanumeric &lt;oper&gt;                         1   Short format alphanumeric &lt;oper&gt;                         2   Numeric &lt;oper&gt;; GSM Location Area Identification number</p> <p><b>&lt;netact&gt;</b>      0   User-specified GSM access technology                         7   User-specified LTE M1 A GB access technology</p>

	9 User-specified LTE NB S1 access technology
Parameter Saving Mode	AUTO_SAVE
Max Response Time	Test command: 45 seconds Write command: 120 seconds
Reference 3GPP TS 27.007 [14]	Note

### 3.2.10 AT+CPAS Phone Activity Status

AT+CPAS Phone Activity Status	
Test Command AT+CPAS=?	Response +CPAS: (list of supported <pas>s)  <b>OK</b>  Parameters See Execution Command
Execution Command AT+CPAS	Response TA returns the activity status of ME. +CPAS: <pas>  <b>OK</b> If error is related to ME functionality: +CME ERROR: <err>  Parameters <pas>     0   Ready (MT allows commands from TA/TE) 3   Ringing (MT is ready for commands from TA/TE, but the ringer is active) 4   Call in progress (MT is ready for commands from TA/TE, a call is in progress)
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference 3GPP TS 27.007 [13]	Note

### 3.2.11 AT+CPIN Enter PIN

AT+CPIN Enter PIN	
Test Command	Response

<b>AT+CPIN=?</b>	<b>OK</b>														
Read Command <b>AT+CPIN?</b>	<p>Response</p> <p>TA returns an alphanumeric string indicating whether some password is required or not.</p> <p><b>+CPIN: &lt;code&gt;</b></p> <p><b>OK</b></p> <p>Parameters</p> <p><b>&lt;code&gt;</b></p> <table> <tr> <td>READY</td><td>MT is not pending for any password</td></tr> <tr> <td>SIM PIN</td><td>MT is waiting SIM PIN to be given</td></tr> <tr> <td>SIM PUK</td><td>MT is waiting for SIM PUK to be given</td></tr> <tr> <td>PH_SIM PIN</td><td>ME is waiting for phone to SIM card (antitheft)</td></tr> <tr> <td>PH_SIM PUK</td><td>ME is waiting for SIM PUK (antitheft)</td></tr> <tr> <td>SIM PIN2</td><td>PIN2, e.g. for editing the FDN book possible only if preceding Command was acknowledged with +CME ERROR:17</td></tr> <tr> <td>SIM PUK2</td><td>Possible only if preceding Command was acknowledged with error +CME ERROR: 18.</td></tr> </table>	READY	MT is not pending for any password	SIM PIN	MT is waiting SIM PIN to be given	SIM PUK	MT is waiting for SIM PUK to be given	PH_SIM PIN	ME is waiting for phone to SIM card (antitheft)	PH_SIM PUK	ME is waiting for SIM PUK (antitheft)	SIM PIN2	PIN2, e.g. for editing the FDN book possible only if preceding Command was acknowledged with +CME ERROR:17	SIM PUK2	Possible only if preceding Command was acknowledged with error +CME ERROR: 18.
READY	MT is not pending for any password														
SIM PIN	MT is waiting SIM PIN to be given														
SIM PUK	MT is waiting for SIM PUK to be given														
PH_SIM PIN	ME is waiting for phone to SIM card (antitheft)														
PH_SIM PUK	ME is waiting for SIM PUK (antitheft)														
SIM PIN2	PIN2, e.g. for editing the FDN book possible only if preceding Command was acknowledged with +CME ERROR:17														
SIM PUK2	Possible only if preceding Command was acknowledged with error +CME ERROR: 18.														
Write Command <b>AT+CPIN=&lt;pin&gt;[,&lt;new pin&gt;]</b>	<p>Response</p> <p>TA stores a password which is necessary before it can be operated (SIM PIN, SIM PUK, PH-SIM PIN, etc.).</p> <p>If the PIN required is SIM PUK or SIM PUK2, the second pin is required. This second pin,&lt;new pin&gt;, is used to replace the old pin in the SIM.</p> <p><b>OK</b></p> <p>If error is related to ME functionality:</p> <p><b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters</p> <table> <tr> <td><b>&lt;pin&gt;</b></td><td>String type; password</td></tr> <tr> <td><b>&lt;new pin&gt;</b></td><td>String type; If the PIN required is SIM PUK or SIMPUK2: new password</td></tr> </table>	<b>&lt;pin&gt;</b>	String type; password	<b>&lt;new pin&gt;</b>	String type; If the PIN required is SIM PUK or SIMPUK2: new password										
<b>&lt;pin&gt;</b>	String type; password														
<b>&lt;new pin&gt;</b>	String type; If the PIN required is SIM PUK or SIMPUK2: new password														
Parameter Saving Mode	NO_SAVE														
Max Response Time	5s														
Reference 3GPP TS 27.007 [13]	Note														

### 3.2.12 AT+CPWD Change Password

<b>AT+CPWD Change Password</b>	
Test Command	Response

<b>AT+CPWD=?</b>	<p>TA returns a list of pairs which present the available facilities and the maximum length of their password.</p> <p><b>+CPWD:</b> (list of supported &lt;fac&gt;s, list of supported &lt;pwdlength&gt;s)</p> <p><b>OK</b></p> <p>Parameters</p> <p>&lt;fac&gt;                      See Write Command</p> <p>&lt;pwdlength&gt;              Integer max. length of password</p>																				
<p>Write Command</p> <p><b>AT+CPWD=&lt;fac&gt;,&lt;oldpwd&gt;,&lt;newpwd&gt;</b></p>	<p>Response</p> <p>TA sets a new password for the facility lock function.</p> <p><b>OK</b></p> <p>Parameters</p> <p>&lt;fac&gt;</p> <table border="0"> <tr><td>"AB"</td><td>All Barring services</td></tr> <tr><td>"AC"</td><td>All inComing barring services(only for &lt;mode&gt;=0)</td></tr> <tr><td>"AG"</td><td>All outGoing barring services(only for &lt;mode&gt;=0)</td></tr> <tr><td>"AI"</td><td>BAIC (Barr All Incoming Calls)</td></tr> <tr><td>"AO"</td><td>BAOC (Barr All Outgoing Calls)</td></tr> <tr><td>"IR"</td><td>BIC-Roam (Barr Incoming Calls when Roaming outside the home country)</td></tr> <tr><td>"OI"</td><td>BOIC (Barr Outgoing International Calls)</td></tr> <tr><td>"OX"</td><td>BOIC-exHC (Barr Outgoing International Calls except to Home Country)</td></tr> <tr><td>"SC"</td><td>SIM (lock SIM/UICC card) (SIM/UICC asks password in MT power-up and when this lock command issued) Correspond to PIN1 code.</td></tr> <tr><td>"P2"</td><td>SIM PIN2</td></tr> </table> <p>&lt;oldpwd&gt;      String type (string should be included in quotation marks): password specified for the facility from the user interface or with command. If an old password has not yet been set,&lt;oldpwd&gt; is not to enter.</p> <p>&lt;newpwd&gt;      String type (string should be included in quotation marks): new password</p>	"AB"	All Barring services	"AC"	All inComing barring services(only for <mode>=0)	"AG"	All outGoing barring services(only for <mode>=0)	"AI"	BAIC (Barr All Incoming Calls)	"AO"	BAOC (Barr All Outgoing Calls)	"IR"	BIC-Roam (Barr Incoming Calls when Roaming outside the home country)	"OI"	BOIC (Barr Outgoing International Calls)	"OX"	BOIC-exHC (Barr Outgoing International Calls except to Home Country)	"SC"	SIM (lock SIM/UICC card) (SIM/UICC asks password in MT power-up and when this lock command issued) Correspond to PIN1 code.	"P2"	SIM PIN2
"AB"	All Barring services																				
"AC"	All inComing barring services(only for <mode>=0)																				
"AG"	All outGoing barring services(only for <mode>=0)																				
"AI"	BAIC (Barr All Incoming Calls)																				
"AO"	BAOC (Barr All Outgoing Calls)																				
"IR"	BIC-Roam (Barr Incoming Calls when Roaming outside the home country)																				
"OI"	BOIC (Barr Outgoing International Calls)																				
"OX"	BOIC-exHC (Barr Outgoing International Calls except to Home Country)																				
"SC"	SIM (lock SIM/UICC card) (SIM/UICC asks password in MT power-up and when this lock command issued) Correspond to PIN1 code.																				
"P2"	SIM PIN2																				
<p>Parameter    Saving Mode</p>	<p>NO_SAVE</p>																				
<p>Max          Response Time</p>	<p>15s</p>																				
<p>Reference</p> <p>3GPP TS 27.007 [13]</p>	<p>Note</p>																				

### 3.2.13 AT+CRC Set Cellular Result Codes for Incoming Call Indication

AT+CRC Set Cellular Result Codes for Incoming Call Indication	
Test Command <b>AT+CRC=?</b>	<p>Response</p> <p><b>+CRC:</b> (list of supported &lt;mode&gt;s)</p> <p><b>OK</b></p> <p>Parameters</p> <p>See Write Command</p>
Read Command <b>AT+CRC?</b>	<p>Response</p> <p><b>+CRC:</b> &lt;mode&gt;</p> <p><b>OK</b></p> <p>Parameters</p> <p>See Write Command</p>
Write Command <b>AT+CRC=[&lt;mode&gt;]</b>	<p>Response</p> <p>TA controls whether or not the extended format of incoming call indication is used.</p> <p><b>OK</b></p> <p>Parameters</p> <p>&lt;mode&gt;     0    Disable extended format               1    Enable extended format                   Omitted Use previous value</p> <p>Unsolicited Result Code</p> <p>When enabled, an incoming call is indicated to the TE with unsolicited result code <b>+CRING: &lt;type&gt;</b> instead of the normal <b>RING</b>.</p> <p>Parameters</p> <p>&lt;type&gt;        ASYNC        Asynchronous transparent                  SYNC        Synchronous transparent                  REL ASYNC    Asynchronous non-transparent                  REL SYNC    Synchronous non-transparent                  FAX         Facsimile                  VOICE        Voice</p>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference 3GPP TS 27.007 [13]	Note

### 3.2.14 AT+CREG Network Registration

AT+CREG Network Registration	
Test Command <b>AT+CREG=?</b>	Response <b>+CREG:</b> (list of supported <n>s)  <b>OK</b>
	Parameters See Write Command
Read Command <b>AT+CREG?</b>	Response TA returns the status of result code presentation and an integer <stat> which shows whether the network has currently indicated the registration of the ME. Location information elements <lac> and <ci> are returned only when <n>=2 and ME is registered in the network. <b>+CREG:</b> <n>,<stat>[,<lac>,<ci>,<netact>]  <b>OK</b> If error is related to ME functionality: <b>+CME ERROR:</b> <err>
Write Command <b>AT+CREG[=&lt;n&gt;] ]</b>	Response TA controls the presentation of an unsolicited result code <b>+CREG: &lt;stat&gt;</b> when <n>=1 and there is a change in the ME network registration status. <b>OK</b>  Parameters <div> <div>&lt;n&gt;</div> <div> <div>0</div> <div>Disable network registration unsolicited result code</div> </div> <div> <div>1</div> <div>Enable network registration unsolicited result code</div> </div> <div> <div>+CREG: &lt;stat&gt;</div> <div>Enable network registration unsolicited result code with location information(2 is only for module which support GPRS.)</div> </div> <div> <div>CREG: &lt;stat&gt;[,&lt;lac&gt;,&lt;ci&gt;,&lt;netact&gt;]</div> </div> </div> <div> <div>&lt;stat&gt;</div> <div> <div>0</div> <div>Not registered, MT is not currently searching a new operator to register to</div> </div> <div> <div>1</div> <div>Registered, home network</div> </div> <div> <div>2</div> <div>Not registered, but MT is currently searching a new operator to register to</div> </div> <div> <div>3</div> <div>Registration denied</div> </div> <div> <div>4</div> <div>Unknown</div> </div> <div> <div>5</div> <div>Registered, roaming</div> </div> </div> <div> <div>&lt;lac&gt;</div> <div>String type (string should be included in quotation marks); two byte location area code in hexadecimal format</div> </div> <div> <div>&lt;ci&gt;</div> <div>String type (string should be included in quotation marks); two byte cell ID in hexadecimal format</div> </div>



	<p><b>&lt;netact&gt;</b>    0    User-specified GSM access technology</p> <p>Unsolicited Result Code</p> <p>If <b>&lt;n&gt;=1</b> and there is a change in the MT network registration status  <b>+CREG: &lt;stat&gt;</b></p> <p>If <b>&lt;n&gt;=2</b> and there is a change in the MT network registration status or a change of the network cell:  <b>+CREG: &lt;stat&gt;[,&lt;lac&gt;,&lt;ci&gt;,&lt;netact&gt;]</b></p> <p>Parameters  See Write Command</p>
Parameter Saving Mode	-
Max Response Time	-
Reference 3GPP TS 27.007 [13]	Note

### 3.2.15 AT+CRSM Restricted SIM Access

AT+CRSM Restricted SIM Access	
Test Command <b>AT+CRSM=?</b>	Response <b>OK</b>
Write Command <b>AT+CRSM=&lt;Command&gt;[,&lt;fileId&gt;[,&lt;P1&gt;,&lt;P2&gt;,&lt;P3&gt;[,&lt;data&gt;]]]</b>	<p>Response</p> <p><b>+CRSM: &lt;sw1&gt;,&lt;sw2&gt;[,&lt;response&gt;]</b></p> <p><b>OK</b></p> <p><b>ERROR</b></p> <p>If error is related to ME functionality:  <b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters</p> <p><b>&lt;Command&gt;</b></p> <p>176 READ BINARY  178 READ RECORD  192 GET RESPONSE  214 UPDATE BINARY  220 UPDATE RECORD  242 STATUS</p> <p>All other values are reserved; refer GSM 11.11.</p> <p><b>&lt;fileId&gt;</b> Integer type; this is the identifier for an elementary data file on SIM. Mandatory for every Command except STATUS</p> <p><b>&lt;P1&gt;,&lt;P2&gt;,&lt;P3&gt;</b> Integer type, range 0 – 255  Parameters to be passed on by the ME to the SIM; refer GSM 11.11.</p>

	<p><b>&lt;data&gt;</b> Information which shall be written to the SIM (hex-decimal character format)</p> <p><b>&lt;sw1&gt;,&lt;sw2&gt;</b> Integer type, range 0 - 255</p> <p>Status information from the SIM about the execution of the actual Command. These parameters are delivered to the TE in both cases, on successful or failed execution of the Command; refer GSM 11.11.</p> <p><b>&lt;response&gt;</b> Response of a successful completion of the Command previously issued (hexadecimal character format)</p>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference 3GPP TS 27.007 GSM 11.11	Note

### 3.2.16 AT+CSQ Signal Quality Report

AT+CSQ Signal Quality Report													
Test Command <b>AT+CSQ=?</b>	<p>Response</p> <p><b>+CSQ:</b> (list of supported <b>&lt;rssi&gt;</b>s),(list of supported <b>&lt;ber&gt;</b>s)</p> <p><b>OK</b></p>												
Execution Command <b>AT+CSQ</b>	<p>Response</p> <p><b>+CSQ:</b> <b>&lt;rssi&gt;</b>,<b>&lt;ber&gt;</b></p> <p><b>OK</b></p> <p>If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p> <p>Execution Command returns received signal strength indication <b>&lt;rssi&gt;</b> and channel bit error rate <b>&lt;ber&gt;</b> from the ME. Test Command returns values supported by the TA.</p> <p>Parameters</p> <p><b>&lt;rssi&gt;</b></p> <table> <tr> <td>0</td><td>-115 dBm or less</td></tr> <tr> <td>1</td><td>-111 dBm</td></tr> <tr> <td>2...30</td><td>-110... -54 dBm</td></tr> <tr> <td>31</td><td>-52 dBm or greater</td></tr> <tr> <td>99</td><td>not known or not detectable</td></tr> </table> <p><b>&lt;ber&gt;</b> (in percent):</p> <table> <tr> <td>0...7</td><td>As RXQUAL values in the table in GSM 05.08 [20] subclause 7.2.4</td></tr> </table>	0	-115 dBm or less	1	-111 dBm	2...30	-110... -54 dBm	31	-52 dBm or greater	99	not known or not detectable	0...7	As RXQUAL values in the table in GSM 05.08 [20] subclause 7.2.4
0	-115 dBm or less												
1	-111 dBm												
2...30	-110... -54 dBm												
31	-52 dBm or greater												
99	not known or not detectable												
0...7	As RXQUAL values in the table in GSM 05.08 [20] subclause 7.2.4												

	99 Not known or not detectable
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference 3GPP TS 27.007 [13]	Note

### 3.2.17 AT+CPOL Preferred Operator List

AT+CPOL Preferred Operator List	
Test Command <b>AT+CPOL=?</b>	Response <b>+CPOL:</b> (list of supported <index>s),(list of supported <format>s)  <b>OK</b>  Parameters See Write Command
Read Command <b>AT+CPOL?</b>	Response <b>+CPOL:</b> <index1>,<format>,<oper1>[,<GSM>,<GSM_compact>,<UTRAN>,<E-UTRAN>][<CR><LF>+CPOL: <index2>,<format>,<oper2>[,<GSM>,<GSM_compact>,<UTRAN>,<E-UTRAN>][...]]  <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>  Parameters See Write Command
Write Command <b>AT+CPOL=&lt;index&gt;[,&lt;format&gt;[,&lt;oper&gt;[&lt;GSM&gt;,&lt;GSM_compact&gt;,&lt;UTRAN&gt;,&lt;E-UTRAN&gt;]]]</b>	Response <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>  Parameters <index> Integer type: order number of operator in SIM preferred operator list <format> Indicates whether alphanumeric or numeric format used (see +COPS Command) 0 Long format alphanumeric <oper> 1 Short format alphanumeric <oper> 2 Numeric <oper> <oper> String type(string should be included in quotation marks)

	<b>&lt;GSM&gt;</b> GSM access technology 0 Access technology is not selected 1 Access technology is selected <b>&lt;GSM_compact&gt;</b> GSM compact access technology 0 Access technology is not selected 1 Access technology is selected <b>&lt;UTRAN&gt;</b> UTRAN access technology 0 Access technology is not selected 1 Access technology is selected <b>&lt;E-UTRAN&gt;</b> E-UTRAN access technology 0 Access technology is not selected 1 Access technology is selected
Parameter Saving Mode	-
Max Response Time	-
Reference 3GPP TS 27.007 [13]	Note

### 3.2.18 AT+COPN Read Operator Names

AT+COPN Read Operator Names	
Test Command <b>AT+COPN=?</b>	Response <b>OK</b>
Execution Command <b>AT+COPN</b>	Response <b>+COPN: &lt;numeric1&gt;,&lt;alpha1&gt;</b> [<CR><LF> <b>+COPN: &lt;numeric2&gt;,&lt;alpha2&gt;</b> [...]]  <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <b>&lt;numericn&gt;</b> String type (string should be included in quotation marks): operator in numeric format (see <b>+COPS</b> ) <b>&lt;alphaz&gt;</b> String type (string should be included in quotation marks): operator in long alphanumeric format (see <b>+COPS</b> )
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

3GPP TS 27.007  
[13]

### 3.2.19 AT+CFUN Set Phone Functionality

AT+CFUN Set Phone Functionality	
Test Command <b>AT+CFUN=?</b>	<p>Response</p> <p><b>+CFUN:</b> (list of supported &lt;fun&gt;s),(list of supported &lt;rst&gt;s)</p> <p><b>OK</b></p> <p>If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters See Write Command</p>
Read Command <b>AT+CFUN?</b>	<p>Response</p> <p><b>+CFUN: &lt;fun&gt;</b></p> <p><b>OK</b></p> <p>If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters See Write Command</p>
Write Command <b>AT+CFUN=&lt;fun&gt; &gt;[,&lt;rst&gt;]</b>	<p>Response</p> <p><b>OK</b></p> <p>If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters</p> <p><b>&lt;fun&gt;</b></p> <ul style="list-style-type: none"> <li>0 Minimum functionality</li> <li><u>1</u> Full functionality (Default)</li> <li>4 Disable phone both transmit and receive RF circuits.</li> <li>5 Factory Test Mode</li> <li>6 Reset</li> <li>7 Offline Mode</li> </ul> <p><b>&lt;rst&gt;</b></p> <ul style="list-style-type: none"> <li><u>0</u> Do not Reset the MT before setting it to &lt;fun&gt; power level.</li> <li>1 Reset the MT before setting it to &lt;fun&gt; power level.</li> </ul>
Parameter Saving Mode	-
Max Response Time	10s
Reference	Note

3GPP TS 27.007 [13]	<ul style="list-style-type: none"> <li>● The <b>&lt;fun&gt;</b> power level will be written to flash except minimum functionality.</li> <li>● <b>AT+CFUN=1,1</b> can be used to reset module purposely at minimum/full functionality mode.</li> <li>● Response string <b>"OK"</b> will be returned after module resets if baud rate is set to fixed baud rate.</li> </ul>
------------------------	---

### 3.2.20 AT+CCLK Clock

AT+CCLK Clock	
Test Command <b>AT+CCLK=?</b>	Response <b>OK</b>
Read Command <b>AT+CCLK?</b>	Response <b>+CCLK: &lt;time&gt;</b>  <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters See Write Command
Write Command <b>AT+CCLK=&lt;time&gt; e&gt;</b>	Response <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <b>&lt;time&gt;</b> String type(string should be included in quotation marks) value; format is "yy/MM/dd,hh:mm:ss±zz", where characters indicate year (two last digits),month, day, hour, minutes, seconds and time zone (indicates the difference, expressed in quarters of an hour, between the local time and GMT; range -47...+48). E.g. 6th of May 2010, 00:01:52 GMT+2 hours equals to "10/05/06,00:01:52+08".
Parameter Saving Mode	AUTO_SAVE
Max Response Time	-
Reference 3GPP TS 27.007 [13]	Note Only time zone is auto saved.

### 3.2.21 AT+CSIM Generic SIM Access

#### AT+CSIM Generic SIM Access

Test Command <b>AT+CSIM=?</b>	Response <b>OK</b>
Write Command <b>AT+CSIM=&lt;length&gt;,&lt;Command&gt;</b>	Response <b>+CSIM: &lt;length&gt;,&lt;response&gt;</b>  <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <b>&lt;length&gt;</b> Integer type: length of characters sent to the TE in <b>&lt;Command&gt;</b> or <b>&lt;response&gt;</b> (i.e. twice the number of octets in the raw data). <b>&lt;Command&gt;</b> String type (string should be included in quotation marks): hex format: GSM 11.11 SIM Command sent from the ME to the SIM. <b>&lt;response&gt;</b> String type(string should be included in quotation marks): hex format: GSM 11.11 response from SIM to <b>&lt;Command&gt;</b> .
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference 3GPP TS 27.007 [13]	Note

### 3.2.22 AT+CBC Battery Charge

<b>AT+CBC Battery Charge</b>	
Test Command <b>AT+CBC=?</b>	Response <b>+CBC: (list of supported &lt;bcs&gt;s),(list of supported &lt;bcl&gt;s),(&lt;voltage&gt;)</b>  <b>OK</b>
	Parameters See Execution Command
Execution Command <b>AT+CBC</b>	Response <b>+CBC: &lt;bcs&gt;,&lt;bcl&gt;,&lt;voltage&gt;</b>  <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters

	<p><b>&lt;bc&gt;</b> Charge status</p> <p>0 ME is not charging</p> <p>1 ME is charging</p> <p>2 Charging has finished</p> <p><b>&lt;bcl&gt;</b> Battery connection level</p> <p>1...100 battery has 1-100 percent of capacity remaining</p> <p>vent</p> <p><b>&lt;voltage&gt;</b> Battery voltage(mV)</p>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference 3GPP TS 27.007 [13]	Note

### 3.2.23 AT+CUSD Unstructured Supplementary Service Data

AT+CUSD Unstructured Supplementary Service Data	
Test Command <b>AT+CUSD=?</b>	Response <b>+CUSD:</b> (list of supported <n>s)
	<b>OK</b>
	Parameters See Write Command
Read Command <b>AT+CUSD?</b>	Response <b>+CUSD:</b> <n>
	<b>OK</b>
	Parameters See Write Command
Write Command <b>AT+CUSD=&lt;n&gt;,&lt;str&gt;,&lt;dcs&gt;</b>	Response <b>OK</b>
	If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <n> A numeric parameter which indicates control of the unstructured supplementary service data <ul style="list-style-type: none"> <li>0 disable the result code presentation in the TE</li> <li>1 enable the result code presentation in the TE</li> <li>2 cancel session (not applicable to read Command response)</li> </ul> <p>&lt;str&gt; String type (string should be included in quotation marks)</p> <p>USSD-string</p>



	<b>&lt;dc&gt;</b> Cell Broadcast Data Coding Scheme in integer format (default 0)
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference GSM 03.38 [25]	Note When ussd is not support or return error,TE will print +CUSD:4.

### 3.2.24 AT+CNUM Subscriber Number

AT+CNUM Subscriber Number	
Test Command <b>AT+CNUM=?</b>	Response <b>OK</b>
Execution Command <b>AT+CNUM</b>	Response <b>+CNUM: "",&lt;number1&gt;,&lt;type1&gt;</b>  <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <b>&lt;numberx&gt;</b> String type (string should be included in quotation marks) phone number of format specified by <b>&lt;typex&gt;</b> <b>&lt;typex&gt;</b> Type of address octet in integer format (refer GSM04.08[8] subclause 10.5.4.7)
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference 3GPP TS 27.007 [13]	Note

## 4 AT Commands According to 3GPP TS 27.005

The 3GPP TS 27.005 commands are for performing SMS and CBS related operations. Heracles224G supports both Text and PDU modes.

### 4.1 Overview of AT Commands According to 3GPP TS 27.005

Command	Description
AT+CMGD	Delete SMS message
AT+CMGF	Select SMS message format
AT+CMGL	List SMS messages from preferred store
AT+CMGR	Read SMS message
AT+CMGS	Send SMS message
AT+CMGW	Write SMS message to memory
AT+CMSS	Send SMS message from storage
AT+CNMI	New SMS message indications
AT+CPMS	Preferred SMS message storage
AT+CRES	Restore SMS settings
AT+CSAS	Save SMS settings
AT+CSCA	SMS service center address
AT+CSDH	Show SMS text mode parameters
AT+CSMP	Set SMS text mode parameters
AT+CSMS	Select message service

### 4.2 Detailed Descriptions of AT Commands According to 3GPP TS 27.005

#### 4.2.1 AT+CMGD Delete SMS Message

AT+CMGD Delete SMS Message	
Test Command AT+CMGD=?	Response +CMGD: (list of supported <index>s),(list of supported <delflag>s)  OK
	Parameters See Write Command
Write Command AT+CMGD=<in	Response TA deletes message from preferred message storage <mem1> location

<b>dex&gt;[,&lt;delflag&gt;]</b>	<p><b>&lt;index&gt;.</b></p> <p><b>OK</b></p> <p><b>ERROR</b></p> <p>If error is related to ME functionality:</p> <p><b>+CMS ERROR: &lt;err&gt;</b></p> <p>Parameters</p> <p><b>&lt;index&gt;</b> Integer type; value in the range of location numbers supported by the associated memory</p> <p><b>&lt;delflag&gt;</b></p> <ul style="list-style-type: none"> <li><b>0</b> Delete the message specified in <b>&lt;index&gt;</b></li> <li><b>1</b> Delete all read messages from preferred message storage, leaving unread messages and stored mobile originated messages (whether sent or not) untouched</li> <li><b>2</b> Delete all read messages from preferred message storage and sent mobile originated messages, leaving unread messages and unsent mobile originated messages untouched</li> <li><b>3</b> Delete all read messages from preferred message storage, sent and unsent mobile originated messages leaving unread messages untouched</li> <li><b>4</b> Delete all messages from preferred message storage including unread messages</li> </ul>
Parameter Saving Mode	NO_SAVE
Max Response Time	<p>5s (delete 1 message)</p> <p>25s (delete 50 messages)</p> <p>25s (delete 150 messages)</p>
Reference	Note
3GPP TS 27.005	

#### 4.2.2 AT+CMGF Select SMS Message Format

AT+CMGF Select SMS Message Format	
Test Command	Response
<b>AT+CMGF=?</b>	<p><b>+CMGF:</b> (list of supported <b>&lt;mode&gt;</b>s)</p> <p><b>OK</b></p> <p>Parameter</p> <p>See Write Command</p>
Read Command	Response
<b>AT+CMGF?</b>	<p><b>+CMGF: &lt;mode&gt;</b></p> <p><b>OK</b></p> <p>Parameter</p>

	See Write Command
Write Command <b>AT+CMGF=[&lt;mode&gt;]</b>	<p>Response</p> <p>TA sets parameter to denote which input and output format of messages to use.</p> <p><b>OK</b></p>
	<p>Parameter</p> <p><b>&lt;mode&gt;</b>    <u>0</u>   PDU mode                  1   Text mode</p>
Parameter Saving Mode	-
Max Response Time	-
Reference 3GPP TS 27.005	Note

#### 4.2.3 AT+CMGL List SMS Messages from Preferred Store

AT+CMGL List SMS Messages from Preferred Store	
Test Command AT+CMGL=?	Response
	+CMGL: (list of supported <stat>s)
	OK
	Parameter
	See Write Command
Write Command AT+CMGL=<stat>[,<mode>]	Parameters
	1) If text mode:
	<stat>        "REC UNREAD"    Received unread messages
	"REC READ"        Received read messages
	"STO UNSENT"     Stored unsent messages
	"STO SENT"        Stored sent messages
	"ALL"             All messages
	<mode>        0    Normal
	1    Not change status of the specified SMS record
	2) If PDU mode:
<stat>        0    Received unread messages	
1    Received read messages	
2    Stored unsent messages	
3    Stored sent messages	
4    All messages	
<mode>        0    Normal	
1    Not change status of the specified SMS record	
	Response
	TA returns messages with status value <stat> from message storage

<mem1> to the TE. If status of the message is 'received unread', status in the storage changes to 'received read'.

1) If text mode (+CMGF=1) and Command successful:

for SMS-SUBMITs and/or SMS-DELIVERs:

+CMGL: <index>,<stat>,<oa/da>[,<alpha>][,<scts>]  
[,<tooa/toda>,<length>]<CR><LF><data>  
[<CR><LF>+CMGL: <index>,<stat>,<da/oa>  
[,<alpha>][,<scts>][,<tooa/toda>,<length>]<CR><LF><data>[...]]

for SMS-STATUS-REPORTs:

+CMGL: <index>,<stat>,<fo>,<mr>[,<ra>][,<tora>],<scts>,<dt>,<st>  
[<CR><LF>+CMGL: <index>,<stat>,<fo>,<mr>  
[,<ra>][,<tora>],<scts>,<dt>,<st>[...]]

for SMS-COMMANDs:

+CMGL: <index>,<stat>,<fo>,<ct>[<CR><LF>  
+CMGL: <index>,<stat>,<fo>,<ct>[...]]

for CBM storage:

+CMGL: <index>,<stat>,<sn>,<mid>,<page>,<pages>  
<CR><LF><data>  
<CR><LF>+CMGL: <index>,<stat>,<sn>,<mid>,<page>,<pages>  
<CR><LF><data>[...]]

**OK**

2) If PDU mode (+CMGF=0) and Command successful:

+CMGL: <index>,<stat>[,<alpha>],<length>  
<CR><LF><pdu><CR><LF>  
+CMGL: <index>,<stat>[,alpha],<length>  
<CR><LF><pdu>[...]]

**OK**

3) If error is related to ME functionality:

+CMS ERROR: <err>

Parameters

<alpha> String type(string should be included in quotation marks)  
alphanumeric representation of <da> or <oa> corresponding to the entry found in MT phonebook; implementation of this feature is manufacturer specific; used character set should be the one selected with Command Select TE Character Set +CSCS (see definition of this Command in 3GPP TS 27.007)

<da> GSM 03.40 TP-Destination-Address Address-Value field in string format; BCD numbers (or GSM default alphabet characters) are

converted to characters of the currently selected TE character set (refer Command +CSCS in 3GPP TS 27.007); type of address given by <toa> <data> In the case of SMS: GSM 03.40 TP-User-Data in text mode responses; format:

- if <dc> indicates that GSM 03.38 default alphabet is used and <fo> indicates that GSM 03.40 TPUser-Data-Header-Indication is not set:
- if TE character set other than "HEX" (refer Command Select TE Character Set +CSCS in 3GPP TS 27.007):ME/TA converts GSM alphabet into current TE character set according to rules of Annex A
- if TE character set is "HEX": ME/TA converts each 7-bit character of GSM alphabet into two IRA character long hexadecimal number (e.g. character P (GSM 23) is presented as 17 (IRA 49 and 55))
- if <dc> indicates that 8-bit or UCS2 data coding scheme is used, or <fo> indicates that GSM 03.40 TP-User-Data-Header-Indication is set: ME/TA converts each 8-bit octet into two IRA character long hexadecimal number (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)) In the case of CBS: GSM 03.41 CBM Content of Message in text mode responses; format:
- if <dc> indicates that GSM 03.38 default alphabet is used:
- if TE character set other than "HEX" (refer Command +CSCS in 3GPP TS 27.007): ME/TA converts GSM alphabet into current TE character set according to rules of Annex A
- if TE character set is "HEX": ME/TA converts each 7-bit character of GSM alphabet into two IRA character long hexadecimal number
- if <dc> indicates that 8-bit or UCS2 data coding scheme is used: ME/TA converts each 8-bit octet into two IRA character long hexadecimal number

<length> Integer type value indicating in the text mode (+CMGF=1) the length of the message body <data> (or <cdata>) in characters; or in PDU mode (+CMGF=0), the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length)

<index> Integer type; value in the range of location numbers supported by the associated memory

<oa> GSM 03.40 TP-Originating-Address Address-Value field in string format; BCD numbers (or GSM default alphabet characters) are converted to characters of the currently selected TE character set (refer Command +CSCS in 3GPP TS 27.007); type of address given by <toa>

<pdu> In the case of SMS: GSM 04.11 SC address followed by GSM 03.40 TPDU in hexadecimal format: ME/TA converts each octet of

	<p>TP data unit into two IRA character long hexadecimal number (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)). In the case of CBS: GSM 03.41 TPDU in hexadecimal format.</p> <p><b>&lt;scts&gt;</b> GSM 03.40 TP-Service-Center-Time-Stamp in time-string format (refer <b>&lt;dt&gt;</b>)</p> <p><b>&lt;toda&gt;</b> GSM 04.11 TP-Destination-Address Type-of-Address octet in integer format (when first character of <b>&lt;da&gt;</b> is + (IRA 43) default is 145, otherwise default is 129)</p> <p><b>&lt;tooa&gt;</b> GSM 04.11 TP-Originating-Address Type-of-Address octet in integer format (default refer <b>&lt;toda&gt;</b>)</p>
Execution Command <b>AT+CMGL</b>	<p>1) If text mode: the same as <b>AT+CMGL="REC UNREAD"</b>, received unread messages</p> <p>2) If PDU mode: the same as <b>AT+CMGL=0</b>, received unread messages</p> <p>See more messages please refer to Write Command.</p> <p>Parameters See Write Command</p>
Parameter Saving Mode	NO_SAVE
Max Response Time	<p>20s(list 50 messages)</p> <p>20s(list 150 messages)</p>
Reference 3GPP TS 27.005	Note

#### 4.2.4 AT+CMGR Read SMS Message

<b>AT+CMGR Read SMS Message</b>	
Test Command <b>AT+CMGR=?</b>	Response <b>OK</b>
Write Command <b>AT+CMGR=&lt;index&gt;[,&lt;mode&gt;]</b>	<p>Parameters</p> <p><b>&lt;index&gt;</b> Integer type; value in the range of location numbers supported by the associated memory</p> <p><b>&lt;mode&gt;</b> <u>0</u> Normal 1 Not change status of the specified SMS record</p> <p>Response</p> <p>TA returns SMS message with location value <b>&lt;index&gt;</b> from message storage <b>&lt;mem1&gt;</b> to the TE. If status of the message is 'received unread', status in the storage changes to 'received read'.</p> <p>1) If text mode (<b>+CMGF=1</b>) and Command successful: for SMS-DELIVER: <b>+CMGR: &lt;stat&gt;,&lt;oa&gt;[,&lt;alpha&gt;],&lt;scts&gt;[,&lt;tooa&gt;,&lt;fo&gt;,&lt;pid&gt;,&lt;dcs&gt;</b></p>

```
,<sca>,<tosca>,<length>]<CR><LF><data>
for SMS-SUBMIT:
+CMGR: <stat>,<da>[,<alpha>][,<toda>,<fo>,<pid>,<dcs>[,<vp>]
,<sca>,<tosca>,<length>]<CR><LF><data>

for SMS-STATUS-REPORTs:
+CMGR: <stat>,<fo>,<mr>[,<ra>][,<tora>],<scts>,<dt>,<st>

for SMS-COMMANDs:
+CMGR: <stat>,<fo>,<ct>[,<pid>[,<mn>][,<da>][,<toda>]
,<length><CR><LF><cdata>]

for CBM storage:
+CMGR: <stat>,<sn>,<mid>,<dcs>,<page>,<pages><CR><LF><data>
2) If PDU mode (+CMGF=0) and Command successful:
+CMGR: <stat>[,<alpha>],<length><CR><LF><pdu>

OK
3) If error is related to ME functionality:
+CMS ERROR: <err>
```

#### Parameters

**<alpha>** String type (string should be included in quotation marks) alphanumeric representation of <da> or <oa> corresponding to the entry found in MT phonebook; implementation of this feature is manufacturer specific

**<da>** GSM 03.40 TP-Destination-Address Address-Value field in string format; BCD numbers (or GSM default alphabet characters) are converted to characters of the currently selected TE character set (specified by +CSCS in 3GPP TS 27.007); type of address given by <toda>

**<data>** In the case of SMS: GSM 03.40 TP-User-Data in text mode responses; format:

- if <dcs> indicates that GSM 03.38 default alphabet is used and <fo> indicates that GSM 03.40 TPUser-Data-Header-Indication is not set;
- if TE character set other than "HEX" (refer Command Select TE Character Set +CSCS in 3GPP TS 27.007):ME/TA converts GSM alphabet into current TE character set according to rules of Annex A
- if TE character set is "HEX": ME/TA converts each 7-bit character of GSM alphabet into two IRA character long hexadecimal number (e.g. character P (GSM 23) is presented as 17 (IRA 49 and 55))
- if <dcs> indicates that 8-bit or UCS2 data coding scheme is used, or <fo> indicates that GSM 03.40



TP-User-Data-Header-Indication is set: ME/TA converts each 8-bit octet into two IRA character long hexadecimal number (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)) In the case of CBS: GSM 03.41 CBM Content of Message in text mode responses; format:

- if **<dc>** indicates that GSM 03.38 default alphabet is used:
- if TE character set other than "HEX" (refer Command +CSCS in 3GPP TS 27.007): ME/TA converts GSM alphabet into current TE character set according to rules of Annex A
- if TE character set is "HEX": ME/TA converts each 7-bit character of GSM alphabet into two IRA character long hexadecimal number
- if **<dc>** indicates that 8-bit or UCS2 data coding scheme is used: ME/TA converts each 8-bit octet into two IRA character long hexadecimal number

**<dc>** Depending on the Command or result code: GSM 03.38 SMS Data Coding Scheme (default 0), or Cell Broadcast Data Coding Scheme in integer format

**<fo>** Depending on the Command or result code: first octet of GSM 03.40 SMS-DELIVER, SMS-SUBMIT (default 17), SMS-STATUS-REPORT, or SMS-COMMAND (default 2) in integer format

**<length>** integer type value indicating in the text mode (+CMGF=1) the length of the message body **<data>** (or **<cdata>**) in characters; or in PDU mode (+CMGF=0), the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length)

**<mid>** GSM 03.41 CBM Message Identifier in integer format

**<oa>** GSM 03.40 TP-Originating-Address Address-Value field in string format; BCD numbers (or GSM default alphabet characters) are converted characters of the currently selected TE character set (specified by +CSCS in 3GPP TS 27.007); type of address given by **<tooa>**

**<pdu>** In the case of SMS: GSM 04.11 SC address followed by GSM 03.40 TPDU in hexadecimal format: ME/TA converts each octet of TP data unit into two IRA character long hexadecimal number (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)). In the case of CBS: GSM 03.41 TPDU in hexadecimal format.

**<pid>** GSM 03.40 TP-Protocol-Identifier in integer format (default 0)

**<sca>** GSM 04.11 RP SC address Address-Value field in string format; BCD numbers (or GSM default alphabet characters) are converted to characters of the currently selected TE character set (specified by +CSCS in 3GPP TS 27.007); type of address given by **<tosca>**

**<scts>** GSM 03.40 TP-Service-Centre-Time-Stamp in time-string format (refer **<dt>**)

	<p><b>&lt;stat&gt;</b>      0 "REC UNREAD"      Received unread messages</p> <p>                 1 "REC READ"            Received read messages</p> <p>                 2 "STO UNSENT"        Stored unsent messages</p> <p>                 3 "STO SENT"            Stored sent messages</p> <p>                 4 "ALL"                All messages</p> <p><b>&lt;toda&gt;</b>        GSM 04.11 TP-Destination-Address Type-of-Address octet in integer format (when first character of <b>&lt;da&gt;</b> is + (IRA 43) default is 145, otherwise default is 129)</p> <p><b>&lt;tooa&gt;</b>        GSM 04.11 TP-Originating-Address Type-of-Address octet in integer format (default refer <b>&lt;toda&gt;</b>)</p> <p><b>&lt;tosca&gt;</b>        GSM 04.11 RP SC address Type-of-Address octet in integer format (default refer <b>&lt;toda&gt;</b>)</p> <p><b>&lt;vp&gt;</b>        Depending on SMS-SUBMIT <b>&lt;fo&gt;</b> setting: GSM 03.40 TP-Validity-Period either in integer format (default 167) or in time-string format (refer <b>&lt;dt&gt;</b>)</p>
Parameter Saving Mode	NO_SAVE
Max Response Time	5s
Reference	Note
3GPP TS 27.005	

#### 4.2.5 AT+CMGS Send SMS Message

AT+CMGS Send SMS Message	
Test Command <b>AT+CMGS=?</b>	Response <b>OK</b>
Write Command 1) If text mode (+CMGF=1): <b>+CMGS=&lt;da&gt;[, &lt;toda&gt;]</b> <b>&lt;CR&gt;text</b> is entered <b>&lt;ctrl-Z/ESC&gt;</b> ESC quits without sending	Parameters <b>&lt;da&gt;</b> GSM 03.40 TP-Destination-Address Address-Value field in string format(string should be included in quotation marks); BCD numbers (or GSM default alphabet characters) are converted to characters of the currently selected TE character set (specified by <b>+CSCS</b> in 3GPP TS 27.007); type of address given by <b>&lt;toda&gt;</b> <b>&lt;toda&gt;</b> GSM 04.11 TP-Destination-Address Type-of-Address octet in integer format (when first character of <b>&lt;da&gt;</b> is + (IRA 43) default is 145, otherwise default is 129) <b>&lt;length&gt;</b> Integer type value (not exceed 160 bytes) indicating in the text mode ( <b>+CMGF=1</b> ) the length of the message body <b>&lt;data&gt;</b> (or <b>&lt;cdata&gt;</b> ) in characters; or in PDU mode ( <b>+CMGF=0</b> ), the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length)
2) If PDU mode (+CMGF=0): <b>+CMGS=&lt;length&gt;</b> <b>&gt;</b> <b>&lt;CR&gt;PDU</b> is given	Response TA sends message from a TE to the network (SMS-SUBMIT). Message

<ctrl-Z/ESC>	<p>reference value &lt;mr&gt; is returned to the TE on successful message delivery. Optionally (when +CSMS &lt;service&gt; value is 1 and network supports) &lt;sects&gt; is returned. Values can be used to identify message upon unsolicited delivery status report result code.</p> <p>1) If text mode(+CMGF=1) and sending successful: +CMGS: &lt;mr&gt;</p> <p><b>OK</b></p> <p>2) If PDU mode(+CMGF=0) and sending successful: +CMGS: &lt;mr&gt;</p> <p><b>OK</b></p> <p>3) If error is related to ME functionality: +CMS ERROR: &lt;err&gt;</p>
	<p>Parameter</p> <p>&lt;mr&gt; GSM 03.40 TP-Message-Reference in integer format</p>
Parameter Saving Mode	NO_SAVE
Max Response Time	60s
Reference 3GPP TS 27.005	<p>Note</p> <ul style="list-style-type: none"> <li>Reject incoming call when sending messages.</li> </ul>

#### 4.2.6 AT+CMGW Write SMS Message to Memory

AT+CMGW Write SMS Message to Memory	
Test Command AT+CMGW=?	Response <b>OK</b>
Write Command 1) If text mode (+CMGF=1): AT+CMGW=<oa>,<tooa/toda>,<stat> <CR> text is entered <ctrl-Z/ESC> <ESC> quits without sending	<p>Response</p> <p>TA transmits SMS message (either SMS-DELIVER or SMS-SUBMIT) from TE to memory storage &lt;mem2&gt;. Memory location &lt;index&gt; of the stored message is returned. By default message status will be set to 'stored unsent', but parameter &lt;stat&gt; allows also other status values to be given.</p> <p>If writing is successful: +CMGW: &lt;index&gt;</p> <p><b>OK</b></p> <p>If error is related to ME functionality: +CMS ERROR: &lt;err&gt;</p>
2) If PDU mode (+CMGF=0): AT+CMGW=<le	<p>Parameters</p> <p>&lt;oa&gt; GSM 03.40 TP-Originating-Address Address-Value field in string format(string should be included in quotation marks); BCD numbers</p>

<p><b>length&gt;[,&lt;stat&gt;]</b>  <b>&lt;CR&gt;PDU is</b>  <b>given</b>  <b>&lt;ctrl-Z/ESC&gt;</b></p>	<p>(or GSM default alphabet characters) are converted to characters of the currently selected TE character set (specified by +CSCS in 3GPP TS 27.007); type of address given by <b>&lt;tooa&gt;</b></p> <p><b>&lt;da&gt;</b> GSM 03.40 TP-Destination-Address Address-Value field in string format(string should be included in quotation marks); BCD numbers (or GSM default alphabet characters) are converted to characters of the currently selected TE character set (specified by +CSCS in 3GPP TS 27.007); type of address given by <b>&lt;tooa&gt;</b></p> <p><b>&lt;tooa&gt;</b> GSM 04.11 TP-Originating-Address Type-of-Address octet in integer format (default refer <b>&lt;tooa&gt;</b>)</p> <p><b>&lt;tooa&gt;</b> GSM 04.11 TP-Destination-Address Type-of-Address octet in integer format (when first character of <b>&lt;da&gt;</b> is + (IRA 43) default is 145, otherwise default is 129)</p> <p>129 Unknown type(ISDN format number)  161 National number type(ISDN format)  145 International number type(ISDN format)  177 Network specific number(ISDN format)</p> <p><b>&lt;length&gt;</b> Integer type value (not exceed 160 bytes) indicating in the text mode (+<b>CMGF=1</b>) the length of the message body <b>&lt;data&gt;</b> (or <b>&lt;cdata&gt;</b>) in characters;  or in PDU mode (+<b>CMGF=0</b>), the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length)</p> <p><b>&lt;stat&gt;</b> in the text mode (+<b>CMGF=1</b>):  <u>"STO UNSENT"</u> Stored unsent messages  "STO SENT" Stored sent messages  in PDU mode (+<b>CMGF=0</b>):  0 Received unread messages  1 Received read messages  2 Stored unsent messages  3 Stored sent messages</p> <p><b>&lt;pdu&gt;</b> In the case of SMS: GSM 04.11 SC address followed by GSM 03.40 TPDU in hexadecimal format: ME/TA converts each octet of TP data unit into two IRA character long hexadecimal number (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)). In the case of CBS: GSM 03.41 TPDU in hexadecimal format.</p> <p><b>&lt;index&gt;</b> Index of message in selected storage <b>&lt;mem2&gt;</b></p>
<p>Execution  Command  <b>AT+CMGW</b></p>	<p>Response</p> <p>TA transmits SMS message (either SMS-DELIVER or SMS-SUBMIT) from TE to memory storage <b>&lt;mem2&gt;</b>. Memory location <b>&lt;index&gt;</b> of the stored message is returned. By default message status will be set to 'stored unsent', but parameter <b>&lt;stat&gt;</b> allows also other status values to be given.</p> <p>If writing is successful:</p>

	<b>+CMGW: &lt;index&gt;</b>  <b>OK</b> If error is related to ME functionality: <b>+CMS ERROR: &lt;err&gt;</b>
Parameter Saving Mode	NO_SAVE
Max Response Time	5s
Reference	Note
3GPP TS 27.005	

#### 4.2.7 AT+CMSS Send SMS Message from Storage

AT+CMSS Send SMS Message from Storage	
Test Command <b>AT+CMSS=?</b>	Response <b>OK</b>
Write Command <b>AT+CMSS=&lt;index&gt;[,&lt;da&gt;,&lt;tda&gt;]</b>	Response TA sends message with location value <b>&lt;index&gt;</b> from message storage <b>&lt;mem2&gt;</b> to the network (SMS-SUBMIT). If new recipient address <b>&lt;da&gt;</b> is given, it shall be used instead of the one stored with the message. Reference value <b>&lt;mr&gt;</b> is returned to the TE on successful message delivery. Values can be used to identify message upon unsolicited delivery status report result code.  1) If text mode( <b>+CMGF=1</b> ) and sending successful: <b>+CMSS: &lt;mr&gt;</b>  <b>OK</b> 2) If PDU mode( <b>+CMGF=0</b> ) and sending successful: <b>+CMSS: &lt;mr&gt;</b>  <b>OK</b> 3) If error is related to ME functionality: <b>+CMS ERROR: &lt;err&gt;</b>
	Parameters <b>&lt;index&gt;</b> Integer type; value in the range of location numbers supported by the associated memory <b>&lt;da&gt;</b> GSM 03.40 TP-Destination-Address Address-Value field in string format(string should be included in quotation marks); BCD numbers (or GSM default alphabet characters) are converted to characters of the currently selected TE character set (specified by <b>+CSCS</b> in 3GPP TS 27.007); type of address given by <b>&lt;tda&gt;</b> <b>&lt;tda&gt;</b> GSM 04.11 TP-Destination-Address Type-of-Address octet

	in integer format (when first character of <da> is + (IRA 43) default is 145, otherwise default is 129) <mr> GSM 03.40 TP-Message-Reference in integer format
Parameter Saving Mode	NO_SAVE
Max Response Time	60s
Reference 3GPP TS 27.005	Note

#### 4.2.8 AT+CNMI New SMS Message Indications

AT+CNMI New SMS Message Indications	
Test Command AT+CNMI=?	<p>Response</p> <p>+CNMI: (list of supported &lt;mode&gt;s),(list of supported &lt;mt&gt;s),(list of supported &lt;bm&gt;s),(list of supported &lt;ds&gt;s),(list of supported &lt;bfr&gt;s)</p> <p><b>OK</b></p> <p>Parameters See Write Command</p>
Read Command AT+CNMI?	<p>Response</p> <p>+CNMI: &lt;mode&gt;,&lt;mt&gt;,&lt;bm&gt;,&lt;ds&gt;,&lt;bfr&gt;</p> <p><b>OK</b></p> <p>Parameters See Write Command</p>
Write Command AT+CNMI=<mode>[,<mt>[,<bm>[,<ds>[,<bfr>]]]]	<p>Response</p> <p>TA selects the procedure for how the receiving of new messages from the network is indicated to the TE when TE is active, e.g. DTR signal is ON. If TE is inactive (e.g. DTR signal is OFF), message receiving should be done as specified in GSM 03.38.</p> <p><b>OK</b></p> <p><b>ERROR</b></p> <p>Parameters</p> <p>&lt;mode&gt; 0 Buffer unsolicited result codes in the TA. If TA result code buffer is full, indications can be buffered in some other place or the oldest indications may be discarded and replaced with the new received indications.</p> <p>1 Discard indication and reject new received message unsolicited result codes when TA-TE link is reserved (e.g. in on-line data mode). Otherwise forward them directly to the TE.</p> <p>2 Buffer unsolicited result codes in the TA when TA-TE</p>

link is reserved (e.g. in on-line data mode) and flush them to the TE after reservation. Otherwise forward them directly to the TE.

**<mt>** (the rules for storing received SMs depend on its data coding scheme (refer GSM 03.38 [2]), preferred memory storage (+CPMS) setting and this value):

0 No SMS-DELIVER indications are routed to the TE.

1 If SMS-DELIVER is stored into ME/TA, indication of the memory location is routed to the TE using unsolicited result code:

+CMTI: <mem>,<index>

2 SMS-DELIVERs (except class 2) are routed directly to the TE using unsolicited result code:

+CMT: [<alpha>],<length><CR><LF><pdu> (PDU mode enabled) or

+CMT: <oa>,<alpha>,<scts>

[,<tooa>,<fo>,<pid>,<dc>,<sca>,<tosca>,<length>]<CR><LF><data> (text mode enabled; about parameters in italics, refer Command Show Text Mode Parameters +CSDH). Class 2 messages result in indication as defined in **<mt>=1**.

3 Class 3 SMS-DELIVERs are routed directly to TE using unsolicited result codes defined in **<mt>=2**. Messages of other classes result in indication as defined in **<mt>=1**.

**<bm>** (the rules for storing received CBMs depend on its data coding scheme (refer GSM 03.38 [2]), the setting of Select CBM Types (+CSCB) and this value):

0 No CBM indications are routed to the TE.

2 New CBMs are routed directly to the TE using unsolicited result code: +CBM: <length><CR><LF><pdu> (PDU mode enabled) or

+CBM: <sn>,<mid>,<dc>,<page>,<pages><CR><LF><data> (text mode enabled).

**<ds>** 0 No SMS-STATUS-REPORTs are routed to the TE.

1 SMS-STATUS-REPORTs are routed to the TE using unsolicited result code: +CDS: <length><CR><LF><pdu> (PDU mode enabled) or +CDS: <fo>,<mr>[,<ra>][,<tora>],<scts>,<dt>,<st> (text mode enabled)

2 If SMS-STATUS-REPORT is stored into ME/TA, indication of the memory location is routed to the TE using unsolicited result code: +CDSI: <mem3>,<index>

**<bfr>** 0 TA buffer of unsolicited result codes defined within this Command is flushed to the TE when **<mode>** 1...3 is entered (OK response shall be given before flushing the codes).

1 TA buffer of unsolicited result codes defined within this command is cleared when **<mode>** 1...3 is entered

Unsolicited result code

1. Indicates that new message has been received

	<p>If <b>&lt;mt&gt;=1</b>:</p> <p><b>+CMTI:</b> <b>&lt;mem3&gt;,&lt;index&gt;</b></p> <p>If <b>&lt;mt&gt;=2</b> (PDU mode enabled):</p> <p><b>+CMT:</b> <b>[&lt;alpha&gt;],&lt;length&gt;&lt;CR&gt;&lt;LF&gt;&lt;pdu&gt;</b></p> <p>If <b>&lt;mt&gt;=2</b> (text mode enabled):</p> <p><b>+CMT:</b></p> <p><b>&lt;oa&gt;,&lt;scts&gt;[,&lt;tooa&gt;,&lt;fo&gt;,&lt;pid&gt;,&lt;dc&gt;,&lt;sca&gt;,&lt;tosca&gt;,&lt;length&gt;]&lt;CR&gt;&lt;LF&gt;&lt;data&gt;</b></p> <p>2. Indicates that new cell broadcast message has been received</p> <p>If <b>&lt;bm&gt;=2</b> (PDU mode enabled):</p> <p><b>+CBM:</b> <b>&lt;length&gt;&lt;CR&gt;&lt;LF&gt;&lt;pdu&gt;</b></p> <p>If <b>&lt;bm&gt;=2</b> (text mode enabled):</p> <p><b>+CBM:</b> <b>&lt;sn&gt;,&lt;mid&gt;,&lt;dc&gt;,&lt;page&gt;,&lt;pages&gt;&lt;CR&gt;&lt;LF&gt;&lt;data&gt;</b></p> <p>3. Indicates that new SMS status report has been received</p> <p>If <b>&lt;ds&gt;=1</b> (PDU mode enabled):</p> <p><b>+CDS:</b> <b>&lt;length&gt;&lt;CR&gt;&lt;LF&gt;&lt;pdu&gt;</b></p> <p>If <b>&lt;ds&gt;=1</b> (text mode enabled):</p> <p><b>+CDS:</b> <b>&lt;fo&gt;,&lt;mr&gt;[,&lt;ra&gt;][,&lt;tora&gt;],&lt;scts&gt;,&lt;dt&gt;,&lt;st&gt;</b></p>
Parameter Saving Mode	-
Max Response Time	-
Reference 3GPP TS 27.005	<p>Note</p> <ul style="list-style-type: none"> <li>This command is used to select the procedure how receiving of new messages from the network is indicated to the TE when TE is active, e.g. DTR signal is ON. If TE is inactive (e.g. DTR signal is OFF). If set <b>&lt;mt&gt;=2,&lt;mt&gt;=3</b> or <b>&lt;ds&gt;=1</b>, make sure <b>&lt;mode&gt;=1</b>, otherwise it will return error..</li> </ul>

#### 4.2.9 AT+CPMS Preferred SMS Message Storage

AT+CPMS Preferred SMS Message Storage	
Test Command AT+CPMS=?	<p>Response</p> <p><b>+CPMS:</b> (list of supported <b>&lt;mem1&gt;s</b>),(list of supported <b>&lt;mem2&gt;s</b>),(list of supported <b>&lt;mem3&gt;s</b>)</p> <p><b>OK</b></p> <p>Parameters See Write Command</p>
Read Command AT+CPMS?	<p>Response</p> <p><b>+CPMS:</b> <b>&lt;mem1&gt;,&lt;used1&gt;,&lt;total1&gt;,&lt;mem2&gt;,&lt;used2&gt;,&lt;total2&gt;,&lt;mem3&gt;,&lt;used3&gt;,&lt;total3&gt;</b></p>



	<p>&lt;mem3&gt;,&lt;used3&gt;,&lt;total3&gt;</p> <p><b>OK</b></p> <p><b>ERROR</b></p> <p>Parameters</p> <p>See Write Command</p>
<p>Write Command</p> <p><b>AT+CPMS=&lt;mem1&gt;[,&lt;mem2&gt;[,&lt;mem3&gt;]]</b></p>	<p>Response</p> <p>TA selects memory storages &lt;mem1&gt;,&lt;mem2&gt; and &lt;mem3&gt; to be used for reading, writing, etc.</p> <p>+CPMS: &lt;used1&gt;,&lt;total1&gt;,&lt;used2&gt;,&lt;total2&gt;,&lt;used3&gt;,&lt;total3&gt;</p> <p><b>OK</b></p> <p><b>ERROR</b></p> <p>Parameters</p> <p><b>&lt;mem1&gt;</b> Messages to be read and deleted from this memory storage "SM" SIM message storage</p> <p><b>&lt;mem2&gt;</b> Messages will be written and sent to this memory storage "SM" SIM message storage</p> <p><b>&lt;mem3&gt;</b> Received messages will be placed in this memory storage if routing to PC is not set (" +CNMI") "SM" SIM message storage</p> <p><b>&lt;usedx&gt;</b> Integer type; Number of messages currently in &lt;memx&gt;</p> <p><b>&lt;totalx&gt;</b> Integer type; Number of messages storable in &lt;memx&gt;</p>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note
3GPP TS 27.005	

#### 4.2.10 AT+CRES Restore SMS Settings

AT+CRES Restore SMS Settings	
<p>Test Command</p> <p><b>AT+CRES=?</b></p>	<p>Response</p> <p>+CRES: list of supported &lt;profile&gt;s</p> <p><b>OK</b></p> <p>Parameter</p> <p>See Write Command</p>
<p>Write Command</p> <p><b>AT+CRES=&lt;profile&gt;</b></p>	<p>Response</p> <p>Execution command restores message service settings from non-volatile memory to active memory. A TA can contain several profiles of settings. Settings specified in commands Service Centre Address +CSCA and Set</p>

	<p>Message Parameters +CSMP are restored. Certain settings may not be supported by the storage (e.g. (U)SIM SMS parameters) and therefore can not be restored.</p> <p><b>OK</b></p> <p><b>ERROR</b></p>
	<p>Parameter</p> <p><b>&lt;profile&gt; 0</b> Restore SM service settings from profile 0</p>
<p>Execution Command</p> <p><b>AT+CRES</b></p>	<p>Response</p> <p>Same as <b>AT+CRES=0</b>.</p> <p><b>OK</b></p> <p>If error is related to ME functionality:</p> <p><b>+CMS ERROR &lt;err&gt;</b></p>
<p>Parameter Saving Mode</p>	<p>NO_SAVE</p>
<p>Max Response Time</p>	<p>5s</p>
<p>Reference</p> <p>3GPP TS 27.005</p>	<p>Note</p>

#### 4.2.11 AT+CSAS Save SMS Settings

AT+CSAS Save SMS Settings	
<p>Test Command</p> <p><b>AT+CSAS=?</b></p>	<p>Response</p> <p><b>+CSAS:</b> list of supported <b>&lt;profile&gt;s</b></p> <p><b>OK</b></p>
	<p>Parameter</p> <p>See Write Command</p>
<p>Write Command</p> <p><b>AT+CSAS=&lt;profile&gt;</b></p>	<p>Response</p> <p>Execution command saves active message service settings to a non-volatile memory. Settings specified in commands Service Centre Address +CSCA and Set Message Parameters +CSMP are saved. Certain settings may not be supported by the storage (e.g. (U)SIM SMS parameters) and therefore can not be saved.</p> <p><b>OK</b></p> <p><b>ERROR</b></p>
	<p>Parameter</p> <p><b>&lt;profile&gt; 0</b> Save SM service setting in profile 0</p>
<p>Execution Command</p> <p><b>AT+CSAS</b></p>	<p>Response</p> <p>Same as <b>AT+CSAS=0</b></p> <p><b>OK</b></p> <p>If error is related to ME functionality:</p>

	<b>+CMS ERROR &lt;err&gt;</b>
Parameter Saving Mode	NO_SAVE
Max Response Time	5s
Reference	Note
3GPP TS 27.005	

#### 4.2.12 AT+CSCA SMS Service Center Address

AT+CSCA SMS Service Center Address	
Test Command <b>AT+CSCA=?</b>	Response <b>OK</b>
Read Command <b>AT+CSCA?</b>	Response <b>+CSCA: &lt;sca&gt;,&lt;tosca&gt;[,&lt;scaAlpha&gt;]</b>  <b>OK</b>  Parameters See Write Command
Write Command <b>AT+CSCA=&lt;sca&gt;[,&lt;tosca&gt;]</b>	Response TA updates the SMSC address, through which mobile originated SMS are transmitted. In text mode, setting is used by send and writes commands. In PDU mode, setting is used by the same commands, but only when the length of the SMSC address coded into <pdu> parameter equals zero.  Note: The Command writes the parameters in NON-VOLATILE memory. <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>  Parameters <b>&lt;sca&gt;</b> GSM 04.11 RP SC address Address-Value field in string format(string should be included in quotation marks); BCD numbers (or GSM default alphabet characters) are converted to characters of the currently selected TE character set (specified by +CSCS in 3GPP TS 27.007); type of address given by <tosca> <b>&lt;tosca&gt;</b> Service center address format GSM 04.11 RP SC address Type-of-Address octet in integer format (default refer <tosca>) <b>&lt;scaAlpha&gt;</b> String type(string should be included in quotation marks)  Service center address alpha data
Parameter Saving Mode	NO_SAVE
Max Response	5s

Time	
Reference 3GPP TS 27.005	Note

#### 4.2.13 AT+CSDH Show SMS Text Mode Parameters

AT+CSDH Show SMS Text Mode Parameters	
Test Command <b>AT+CSDH=?</b>	Response <b>+CSDH:</b> (list of supported <show>s)  <b>OK</b>
	Parameter See Write Command
Read Command <b>AT+CSDH?</b>	Response <b>+CSDH:</b> <show>  <b>OK</b>
	Parameter See Write Command
Write Command <b>AT+CSDH=&lt;show&gt;</b>	Response TA determines whether detailed header information is shown in text mode result codes. <b>OK</b>
	Parameter <b>&lt;show&gt;</b> <u>0</u> Do not show header values defined in commands +CSCA and +CSMP (<sca>,<tosca>,<fo>,<vp>,<pid> and <dcs>) nor <length>,<toda> or <toa> in +CMT, +CMGL, +CMGR result codes for SMS-DELIVERs and SMS-SUBMITs in text mode 1        Show the values in result codes
Execution Command <b>AT+CSDH</b>	Response <b>OK</b>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference 3GPP TS 27.005	Note

#### 4.2.14 AT+CSMP Set SMS Text Mode Parameters

AT+CSMP Set SMS Text Mode Parameters	
Test Command	Response

AT+CSMP=?	OK
	Parameters See Write Command
Read Command AT+CSMP?	Response +CSMP: <fo>,<vp>,<pid>,<dc>
	OK Parameters See Write Command
Write Command AT+CSMP=[<fo>,<vp>,<pid>,<dc>]	Response TA selects values for additional parameters needed when SM is sent to the network or placed in a storage when text mode is selected (+CMGF=1). It is possible to set the validity period starting from when the SM is received by the SMSC (<vp> is in range 0... 255) or define the absolute time of the validity period termination (<vp> is a string).
	Note: The Command writes the parameter <fo> in NON-VOLATILE memory. OK Parameters <fo> Depending on the command or result code: first octet of GSM 03.40 SMS-DELIVER, SMS-SUBMIT (default 17), SMS-STATUS-REPORT, or SMS-COMMAND (default 2) in integer format. SMS status report is supported under text mode if <fo> is set to 49. <vp> Depending on SMS-SUBMIT <fo> setting: GSM 03.40 TP-Validity-Period either in integer format (default 167) or in time-string format (refer <dt>) <pid> GSM 03.40 TP-Protocol-Identifier in integer format (default 0). <dc> GSM 03.38 SMS Data Coding Scheme in Integer format.
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note
3GPP TS 27.005	

#### 4.2.15 AT+CSMS Select Message Service

AT+CSMS Select Message Service	
Test Command AT+CSMS=?	Response +CSMS: (list of supported <service>s)
	OK

	Parameter See Write Command
Read Command <b>AT+CSMS?</b>	Response <b>+CSMS: &lt;service&gt;,&lt;mt&gt;,&lt;mo&gt;,&lt;bm&gt;</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+CSMS=&lt;service&gt;</b>	Response <b>+CSMS: &lt;mt&gt;,&lt;mo&gt;,&lt;bm&gt;</b>  <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <b>&lt;service&gt;</b> <u>0</u> GSM 03.40 and 03.41 (the syntax of SMS AT commands is compatible with 3GPP TS 27.005 Phase 2 version 4.7.0; Phase 2+ features which do not require new Command syntax may be supported (e.g. correct routing of messages with new Phase 2+ data coding schemes)) 1   GSM 03.40 and 03.41 (the syntax of SMS AT commands is compatible with 3GPP TS 27.005 Phase 2+ version; the requirement of <service> setting 1 is mentioned under corresponding command descriptions) <b>&lt;mt&gt;</b> Mobile Terminated Messages: 0   Type not supported 1   Type supported <b>&lt;mo&gt;</b> Mobile Originated Messages: 0   Type not supported 1   Type supported <b>&lt;bm&gt;</b> Broadcast Type Messages: 0   Type not supported 1   Type supported
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference 3GPP TS 27.005	Note

## 5 AT Commands Special for SIMCom

### 5.1 Overview

Command	Description
AT+CPOWD	Power off
AT+CADC	Read ADC
AT+CFGRI	Indicate RI when using URC
AT+CLTS	Get local timestamp
AT+CBAND	Get and set mobile operation band
AT+CNBP	Set the state of the band preference
AT+CNSMOD	Show network system mode
AT+CSCLK	Configure slow clock
AT+CCID	Show ICCID
AT+CDEVICE	View Current Flash Device Type
AT+GSV	Display product identification information
AT+SGPIO	Control the GPIO
AT+SLEDS	Set the timer period of net light
AT+CNETLIGHT	Close the net light or open it to shining
AT+CSGS	Netlight indication of GPRS status
AT+CGPIO	Control the GPIO by PIN Index
AT+CBATCHK	Set VBAT checking feature ON/OFF
AT+CNMP	Preferred mode selection
AT+CMNB	Preferred selection between CAT-M and NB-IoT
AT+CPSMS	Power Saving Mode Setting
AT+CEDRXS	Entended-DRX Setting
AT+CPSI	Inquiring UE system information
AT+CGNAPN	Get Network APN in CAT-M Or NB-IOT
AT+CSDP	Service Domain Preference
AT+MCELLLOCK	Lock the special CAT-M cell
AT+NCELLLOCK	Lock the special NB-IOT cell
AT+NBSC	Config NB-IOT Scrambling Feature
AT+CAPNMODE	Select the mode of application configure APN
AT+CRRCSTATE	Query RRC State
AT+CBANDCFG	Configure CAT-M Or NB-IOT Band
AT+CNACT	App Network Active
AT+CEDUMP	Set whether the module reset when the module is crashed

AT+CNBS	Configure Band Scan Optimization for NB-IOT
AT+CNDS	Configure Service Domain Preference For NB-IOT
AT+CENG	Switch on or off Engineering Mode
AT+CNACTCFG	IP Protocol Type Config
AT+ CTIIC	Control the Switch of IIC
AT+CWIIC	Write Values to Register of IIC Device
AT+CRIIC	Read Values from Register of IIC Device
AT+SPWM	Generate the Pulse-Width-Modulation

## 5.2 Detailed Descriptions of Commands

### 5.2.1 AT+CPOWD Power off

AT+CPOWD Power Off	
Write Command AT+CPOWD=<n> >	Response [NORMAL POWER DOWN]  Parameter <n>        0    Power off urgently (Will not send out NORMAL POWER DOWN) 1    Normal power off    (Will send out NORMAL POWER DOWN)
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 5.2.2 AT+CADC Read ADC

AT+CADC Read ADC	
Test Command AT+CADC=?	Response +CADC: (list of supported <status>s),(list of supported <value>s)  <b>OK</b>  Parameters <status>    1    Success 0    Fail <value>     Integer 0,100-1700
Read Command AT+CADC?	Response +CADC: <status>,<value>



	<b>OK</b>
	Parameters See Test Command
Parameter Saving Mode	NO_SAVE
Max Response Time	2s
Reference	Note

### 5.2.3 AT+CFGRI Indicate RI When Using URC

AT+CFGRI Indicate RI When Using URC	
Test Command AT+CFGRI=?	Response +CFGRI: (0-2)  OK
	Parameters See Write Command
Read Command AT+CFGRI?	Response +CFGRI: <status>  OK
	Parameters See Write Command
Write Command AT+CFGRI=<status>	Response OK ERROR
	Parameters <status>     0     Off 1     On(TCPIP, FTP and URC control RI pin) 2     On(only TCP/IP control RI pin)
Parameter Saving Mode	-
Max Response Time	-
Reference	Note ● RI pin can not controll by "AT+CFGRI" command when module has call service or receiving SMS.

### 5.2.4 AT+CLTS Get Local Timestamp

#### AT+CLTS Get Local Timestamp

Test Command <b>AT+CLTS=?</b>	Response <b>+CLTS: "yy/MM/dd,hh:mm:ss+/-zz"</b>  <b>OK</b>
Read Command <b>AT+CLTS?</b>	Response <b>+CLTS: &lt;mode&gt;</b>  <b>OK</b>
Write Command <b>AT+CLTS=&lt;mode&gt;</b>	Response <b>OK</b> <b>ERROR</b>
	Parameters <b>&lt;mode&gt;</b>  <u>0</u> Disable 1    Enable
	Unsolicited Result Code When "get local timestamp" function is enabled, the following URC may be reported if network sends the message to the MS to provide the MS with subscriber specific information. 1. Refresh network name by network: <b>*PSNWID: "&lt;mcc&gt;", "&lt;mnc&gt;", "&lt;full network name&gt;",&lt;full network name CI&gt;,"&lt;short network name&gt;",&lt;short network name CI&gt;</b>  2. Refresh time and time zone by network: This is UTC time, the time queried by AT+CCLK command is local time. <b>*PSUTTZ: &lt;year&gt;,&lt;month&gt;,&lt;day&gt;,&lt;hour&gt;,&lt;min&gt;,&lt;sec&gt;,"&lt;time zone&gt;",&lt;dst&gt;</b>  3. Refresh network time zone by network: <b>+CTZV: "&lt;time zone&gt;"</b>  4. Refresh Network Daylight Saving Time by network: <b>DST: &lt;dst&gt;</b>
	Parameters <b>&lt;mcc&gt;</b> String type; mobile country code <b>&lt;mnc&gt;</b> String type; mobile network code <b>&lt;full network name&gt;</b> String type; name of the network in full length. <b>&lt;full network name CI&gt;</b> Integer type; indicates whether to add CI. 0    The MS will not add the initial letters of the Country's

	<p>Name to the text string.</p> <p>1 The MS will add the initial letters of the Country's Name and a separator (e.g. a space) to the text string.</p> <p><b>&lt;short network name&gt;</b> String type; abbreviated name of the network</p> <p><b>&lt;short network name CI&gt;</b> Integer type; indicates whether to add CI.</p> <p>0 The MS will not add the initial letters of the Country's Name to the text string.</p> <p>1 The MS will add the initial letters of the Country's Name and a separator (e.g. a space) to the text string.</p> <p><b>&lt;year&gt;</b> 4 digits of year (from network)</p> <p><b>&lt;month&gt;</b> Month (from network)</p> <p><b>&lt;day&gt;</b> Day (from network)</p> <p><b>&lt;hour&gt;</b> Hour (from network)</p> <p><b>&lt;min&gt;</b> Minute (from network)</p> <p><b>&lt;sec&gt;</b> Second (from network)</p> <p><b>&lt;time zone&gt;</b> String type; network time zone. If the network time zone has been adjusted for Daylight Saving Time, the network shall indicate this by including the &lt;dst&gt; (Network Daylight Saving Time)</p> <p><b>&lt;dst&gt;</b> Network Daylight Saving Time; the content of this indicates the value that used to adjust the network time zone</p> <p>0 No adjustment for Daylight Saving Time</p> <p>1 +1 hour adjustment for Daylight Saving</p> <p>2 +2 hours adjustment for Daylight Saving Time</p> <p>others Reserved</p>
Parameter Saving Mode	-
Max Response Time	-
Reference	<p>Note</p> <p>Support for this Command will be network dependent.</p> <p>Set <b>AT+CLTS=1</b>, it means user can receive network time updating and use <b>AT+CCLK</b> to show current time.</p> <p><b>*PSUTTZ</b> may report twice.</p>

### 5.2.5 AT+CBAND Get and Set Mobile Operation Band

AT+CBAND Get and Set Mobile Operation Band	
Test Command <b>AT+CBAND=?</b>	<p>Response</p> <p><b>+CBAND:</b> (list of supported <b>&lt;op_band&gt;s</b>)</p> <p><b>OK</b></p>
	<p>Parameter</p> <p>See Write Command</p>

Read Command <b>AT+CBAND?</b>	Response <b>+CBAND: &lt;op_band&gt;</b>  <b>OK</b>
	Parameter See Write Command
Write Command <b>AT+CBAND=&lt;op_band&gt;</b>	Response <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameter <b>&lt;op_band&gt;</b> A string parameter which indicate the operation band. And the following strings should be included in quotation marks.  EGSM_MODE DCS_MODE ALL_MODE
Parameter Saving Mode	AUTO_SAVE
Max Response Time	-
Reference	Note <ul style="list-style-type: none"> <li>● Radio settings are stored in non-volatile memory.</li> <li>● Only for GSM</li> </ul>

### 5.2.6 AT+CNBP Set the state of the band preference

<b>AT+CNBP Set the state of the band preference</b>	
Read Command <b>AT+CNBP?</b>	Response <b>+CNBP: &lt;mode&gt;[,&lt;lte_mode&gt;]</b>  <b>OK</b>
	Parameter See Write Command
Write Command <b>AT+CNBP=&lt;mode&gt;[,&lt;lte_mode&gt;]</b>	Response <b>OK</b> <b>ERROR</b>
	Parameter <b>&lt;mode&gt;</b> 64bit number, the value is "1" << "<pos>", then or by bit. Some special mode value declared below: 0x40000000 BAND_PREF_NO_CHANGE  <b>&lt;pos&gt;</b>

0xFFFFFFFF7FFFFFFF	Any (any value)
7	GSM_DCS_1800
8	GSM_EGSM_900
9	GSM_PGSM_900
<b>&lt;lte_mode&gt;</b> 64bit number, the value is "1" << "<lte_pos>", then or by bit	
<b>&lt;lte_pos&gt;</b>	
0x000007FF3FDF3FFF	Any (any value)
0	EUTRAN_BAND1(UL:1920-1980; DL:2110-2170)
1	EUTRAN_BAND2(UL:1850-1910; DL:1930-1990)
2	EUTRAN_BAND3(UL:1710-1785; DL:1805-1880)
3	EUTRAN_BAND4(UL:1710-1755; DL:2110-2155)
4	EUTRAN_BAND5(UL: 824-849; DL: 869-894)
5	EUTRAN_BAND6(UL: 830-840; DL: 875-885)
6	EUTRAN_BAND7(UL:2500-2570; DL:2620-2690)
7	EUTRAN_BAND8(UL: 880-915; DL: 925-960)
8	EUTRAN_BAND9(UL:1749.9-1784.9; DL:1844.9-1879.9)
9	EUTRAN_BAND10(UL:1710-1770; DL:2110-2170)
10	EUTRAN_BAND11(UL:1427.9-1452.9; DL:1475.9-1500.9)
11	EUTRAN_BAND12(UL:698-716; DL:728-746)
12	EUTRAN_BAND13(UL: 777-787; DL: 746-756)
13	EUTRAN_BAND14(UL: 788-798; DL: 758-768)
16	EUTRAN_BAND17(UL: 704-716; DL: 734-746)
17	EUTRAN_BAND18(UL: 815-830; DL: 860-875)
18	EUTRAN_BAND19(UL: 830-845; DL: 875-890)
19	EUTRAN_BAND20(UL: 832-862; DL: 791-821)
20	EUTRAN_BAND21(UL: 1447.9-1462.9; DL: 1495.9-1510.9)
22	EUTRAN_BAND23(UL: 2000-2020; DL: 2180-2200)
23	EUTRAN_BAND24(UL: 1626.5-1660.5; DL: 1525 -1559)
24	EUTRAN_BAND25(UL: 1850-1915; DL: 1930 -1995)
25	EUTRAN_BAND26(UL: 814-849; DL: 859 -894)
26	EUTRAN_BAND27(UL: 807.5-824; DL: 852 -869)
27	EUTRAN_BAND28(703-748; DL: 758-803)
28	EUTRAN_BAND29(UL:1850-1910 or 1710-1755; DL:716-728)
29	EUTRAN_BAND30(UL: 2305-2315 ; DL: 2350 - 2360)
32	EUTRAN_BAND33(UL: 1900-1920; DL: 1900-1920)
33	EUTRAN_BAND34(UL: 2010-2025; DL: 2010-2025)
34	EUTRAN_BAND35(UL: 1850-1910; DL: 1850-1910)
35	EUTRAN_BAND36(UL: 1930-1990; DL: 1930-1990)
36	EUTRAN_BAND37(UL: 1910-1930; DL: 1910-1930)
37	EUTRAN_BAND38(UL: 2570-2620; DL: 2570-2620)

	38	EUTRAN_BAND39(UL: 1880-1920; DL: 1880-1920)
	39	EUTRAN_BAND40(UL: 2300-2400; DL: 2300-2400)
	40	EUTRAN_BAND41(UL: 2496-2690; DL: 2496-2690)
	41	EUTRAN_BAND42(UL: 3400-3600; DL: 3400-3600)
	42	EUTRAN_BAND43(UL: 3600-3800; DL: 3600-3800)
Parameter Saving Mode	AUTO_SAVE	
Max Response Time	-	
Reference	Note <ul style="list-style-type: none"> <li>● Radio settings are stored in non-volatile memory.</li> </ul>	

### 5.2.7 AT+CNSMOD Show network system mode

AT+CNSMOD Show network system mode	
Test Command AT+CNSMOD=?	Response <b>+CNSMOD: (list of supported &lt;n&gt;s)</b>  <b>OK</b>
	Parameter See Write Command
Read Command AT+CNSMOD?	Response <b>+CNSMOD: &lt;n&gt;,&lt;stat&gt;</b>  <b>OK</b>
	Parameter See Write Command
Write Command AT+CNSMOD= <n>	Response <b>OK</b> <b>ERROR:</b>
	Parameter <n> <u>0</u> Disable auto report the network system mode information 1      Auto report the network system mode information, command: <b>+CNSMOD: &lt;stat&gt;</b> <stat> 0      no service 1      GSM 3      EGPRS 7      LTE M1 9      LTE NB

Parameter Saving Mode	-
Max Response Time	
Reference	

### 5.2.8 AT+CSCLK Configure Slow Clock

AT+CSCLK Configure Slow Clock	
Test Command <b>AT+CSCLK=?</b>	Response <b>+CSCLK:</b> (list of supported <n>s)  <b>OK</b>  Parameter See Write Command
Read Command <b>AT+CSCLK?</b>	Response <b>+CSCLK:</b> <n>  <b>OK</b>  Parameter See Write Command
Write Command <b>AT+CSCLK=&lt;n&gt;</b>	Response <b>OK</b> <b>ERROR</b>  Parameter <n>      0    Disable slow clock, module will not enter sleep mode. 1    Enable slow clock, it is controlled by DTR. When DTR is high, module can enter sleep mode. When DTR changes to low level, module can quit sleep mode.
Parameter Saving Mode	AUTO_SAVE
Max Response Time	-
Reference	Note

### 5.2.9 AT+CCID Show ICCID

AT+CCID Show ICCID	
Test Command <b>AT+CCID=?</b>	Response <b>OK</b>

Execution Command <b>AT+CCID</b>	Response <b>Ccid data</b> [ex. 898600810906F8048812]  <b>OK</b>
Parameter Saving Mode	NO_SAVE
Max Response Time	2s
Reference	Note

### 5.2.10 AT+CDEVICE View Current Flash Device Type

<b>AT+CDEVICE View Current Flash Device Type</b>	
Read Command <b>AT+CDEVICE?</b>	Response <b>Device Name: Current flash device type</b> <b>Ram Size: Current RAM size</b>  <b>OK</b>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference V.25ter	Note

### 5.2.11 AT+GSV Display Product Identification Information

<b>AT+GSV Display Product Identification Information</b>	
Execution Command <b>AT+GSV</b>	Response TA returns product information text  Example: <b>SIMCOM_Ltd</b> <b>SIMCOM_Heracles224G</b> <b>Revision: 1351B01Heracles224G</b>  <b>OK</b>
Parameter Saving Mode	NO_SAVE
Max Response Time	-



Reference	Note
-----------	------

### 5.2.12 AT+SGPIO Control the GPIO

AT+SGPIO Control the GPIO	
Test Command <b>AT+SGPIO=?</b>	Response <b>+SGPIO: (0-1),(0-4),(0-1),(0-1)</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+SGPIO=&lt;operation&gt;,&lt;GPIO&gt;,&lt;function&gt;,&lt;level&gt;</b> <b>&gt;</b>	Response <b>OK</b> or <b>ERROR</b>
	Parameters <b>&lt;operation&gt;</b> 0 Set the GPIO function including the GPIO output. 1 Read the GPIO level. Please note that only when the gpio is set as input, user can use parameter 1 to read the GPIO level, otherwise the module will return "ERROR". <b>&lt;GPIO&gt;</b> The GPIO you want to be set. (It has relations with the hardware, please refer to the hardware manual) <b>&lt;function&gt;</b> Only when <b>&lt;operation&gt;</b> is set to 0, this option takes effect. 0 Set the GPIO to input. 1 Set the GPIO to output <b>&lt;level&gt;</b> 0 Set the GPIO low level 1 Set the GPIO high level
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 5.2.13 AT+SLEDS Set the Timer Period of Net Light

AT+SLEDS Set the Timer Period of Net Light	
Test Command <b>AT+SLEDS=?</b>	Response <b>+SLEDS: (1-3),(0,40-65535),(0,40-65535)</b>  <b>OK</b>

	Parameters See Write Command
Read Command <b>AT+SLEDS?</b>	Response <b>+SLEDS: &lt;mode&gt;,&lt;timer_on&gt;,&lt;timer_off&gt;</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+SLEDS=&lt;m ode&gt;,&lt;timer_on&gt; ,&lt;timer_off&gt;</b>	Response <b>OK</b> <b>ERROR</b>  Parameters <b>&lt;mode&gt;</b> 1 Set the timer period of net light while Heracles224G does not register to the network 2 Set the timer period net light while Heracles224G has already registered to the network 3 Set the timer period net light while Heracles224G is in the state of PPP communication <b>&lt;timer_on&gt;</b> Timer period of "LED ON" in decimal format which range is 0 or 40-65535(ms) <b>&lt;timer_off&gt;</b> Timer period of "LED OFF" in decimal format which range is 0 or 40-65535(ms)
Parameter Saving Mode	-
Max Response Time	-
Reference	Note The default value is : <b>&lt;mode&gt;,&lt;timer_on&gt;,&lt;timer_off&gt;</b> 1,64,800 2,64,3000 3,64,300

#### 5.2.14 AT+CNETLIGHT Close the Net Light or Open It to Shining

AT+CNETLIGHT Close the Net Light or Open It to Shining	
Test Command <b>AT+CNETLIGH T=?</b>	Response <b>+CNETLIGHT: (0,1)</b>  <b>OK</b>

	Parameters See Write Command
Read Command <b>AT+CNETLIGHT?</b>	Response <b>+CNETLIGHT: &lt;mode&gt;</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+CNETLIGHT=&lt;mode&gt;</b>	Response <b>OK</b> <b>ERROR</b>
	Parameters <b>&lt;mode&gt;</b> 0   Close the net light 1   Open the net light to shining
Parameter Saving Mode	AUTO_SAVE
Max Response Time	-
Reference	Note

#### 5.2.15 AT+CSGS Netlight Indication of GPRS Status

AT+CSGS Netlight Indication of GPRS Status	
Test Command <b>AT+CSGS=?</b>	Response <b>+CSGS: (0-2)</b>  <b>OK</b>
	Parameters See Write Command
Read Command <b>AT+CSGS?</b>	Response <b>+CSGS: &lt;mode&gt;</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+CSGS=&lt;mode&gt;</b>	Response <b>OK</b> <b>ERROR</b>

	Parameters <b>&lt;mode&gt;</b> 0    Disable 1    Enable, the netlight will be forced to enter into 64ms on/300ms off blinking state in GPRS data transmission service. Otherwise, the netlight state is not restricted. 2    Enable, the netlight will blink according to <b>AT+SLEDS</b> in GPRS data transmission service.
Parameter Saving Mode	
Max Response Time	-
Reference	Note

#### 5.2.16 AT+CGPIO Control the GPIO by PIN Index

AT+CGPIO Control the GPIO by PIN Index	
Test Command <b>AT+CGPIO=?</b>	Response <b>+CGPIO: (0-1),( list of supported &lt;pin&gt;s),(0-1),(0-1)</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+CGPIO=&lt;operation&gt;,&lt;pin&gt;,&lt;function&gt;,&lt;level&gt;</b>	Response <b>OK</b> or <b>ERROR</b>
	Parameters <b>&lt;operation&gt;</b> 0    Set the GPIO function including the GPIO output . 1    Read the GPIO level. Please note that only when the gpio is set as input, user can use parameter 1 to read the GPIO level, otherwise the module will return "ERROR". <b>&lt;pin&gt;</b> The PIN index you want to be set. (It has relations with the hardware, please refer to the hardware manual) <b>&lt;function&gt;</b> Only when <b>&lt;operation&gt;</b> is set to 0, this option takes effect. 0    Set the GPIO to input. 1    Set the GPIO to output <b>&lt;level&gt;</b> 0    Set the GPIO low level 1    Set the GPIO high level
Parameter Saving	-

Mode	
Max Response Time	-
Reference	Note

### 5.2.17 AT+CBATCHK Set VBAT Checking Feature ON/OFF

AT+CBATCHK Set VBAT Checking Feature ON/OFF	
Test Command <b>AT+CBATCHK=?</b>	Response <b>+CBATCHK: (0,1)</b>  <b>OK</b>
Read Command <b>AT+CBATCHK?</b>	Response <b>+CBATCHK: &lt;mode&gt;</b>  <b>OK</b>  Parameters See Write Command
Write Command <b>AT+CBATCHK=&lt;mode&gt;</b>	Response <b>OK</b> If failed: <b>+CME ERROR: &lt;err&gt;</b>  Parameters <b>&lt;mode&gt;</b> <u>0</u> Close the function of VBAT checking 1    Open the function of VBAT checking
Parameter Saving Mode	AUTO_SAVE
Max Response Time	-
Reference	Note

### 5.2.18 AT+CNMP Preferred mode selection

AT+CNMP Preferred mode selection	
Test Command <b>AT+CNMP=?</b>	Response <b>+CNMP: (list of supported &lt;mode&gt;s)</b>  <b>OK</b>
Read Command <b>AT+CNMP?</b>	Response <b>+CNMP: &lt;mode&gt;</b>

	<b>OK</b>
	Parameters See Write Command
Write Command <b>AT+CNMP=&lt;mode&gt;</b>	Response <b>OK</b> If failed: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <b>&lt;mode&gt;</b> 2    Automatic 13   GSM only 38   LTE only 51   GSM and LTE only
Parameter Saving Mode	AUTO_SAVE
Max Response Time	-
Reference	Note Default value of parameter <b>&lt;mode&gt;</b> is different among Heracles224G project.

#### 5.2.19 AT+CMNB Preferred selection between CAT-M and NB-IoT

<b>AT+CMNB Preferred selection between CAT-M and NB-IoT</b>	
Test Command <b>AT+CMNB=?</b>	Response <b>+CMNB:</b> (list of supported <b>&lt;mode&gt;</b> s)  <b>OK</b>
Read Command <b>AT+CMNB?</b>	Response <b>+CMNB: &lt;mode&gt;</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+CMNB=&lt;mode&gt;</b>	Response <b>OK</b> If failed: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <b>&lt;mode&gt;</b> 1    CAT-M 2    NB-Iot 3    CAT-M and NB-IoT
Parameter Saving Mode	AUTO_SAVE

Max Response Time	-
Reference	Note Default value of parameter <b>&lt;mode&gt;</b> is different among Heracles224G project.

### 5.2.20 AT+CPSMS Power Saving Mode Setting

AT+CPSMS Power Saving Mode Setting	
Test Command <b>AT+CPSMS=?</b>	Response <b>+CPSMS:</b> (list of supported <b>&lt;mode&gt;</b> s),(list of supported <b>&lt;Requested_Periodic-RAU&gt;</b> s),(list of supported <b>&lt;Requested_GPRS-READY-timer&gt;</b> s),(list of supported <b>&lt;Requested_Periodic-TAU&gt;</b> s),(list of supported <b>&lt;Requested_Active-Time&gt;</b> s)  <b>OK</b>
Read Command <b>AT+CPSMS?</b>	Response <b>+CPSMS:</b> <b>&lt;mode&gt;</b> ,[ <b>&lt;Requested_Periodic-RAU&gt;</b> ],[ <b>&lt;Requested_GPRS-READY-timer&gt;</b> ],[ <b>&lt;Requested_Periodic-TAU&gt;</b> ],[ <b>&lt;Requested_Active-Time&gt;</b> ]  <b>OK</b>  Parameters See Write Command
Write Command <b>AT+CPSMS=[&lt;mode&gt;[,&lt;Requested_Periodic-RAU&gt;[,&lt;Requested_GPRS-READY-timer&gt;[,&lt;Requested_Periodic-TAU&gt;[,&lt;Requested_Active-Time&gt;]]]]</b>	Response <b>OK</b> If failed: <b>+CME ERROR: &lt;err&gt;</b>  Parameters <b>&lt;mode&gt;</b> 0 Disable the use of PSM 1 Enable the use of PSM <b>&lt;Requested_Periodic-RAU&gt;</b> Not supported <b>&lt;Requested_GPRS-READY-timer&gt;</b> Not supported <b>&lt;Requested_Periodic-TAU&gt;</b> String type; one byte in an 8 bit format. Requested extended periodic TAU value (T3412) to be allocated to the UE in E-UTRAN. The requested extended periodic TAU value is coded as one byte (octet 3) of the GPRS Timer 3 information element coded as bit format (e.g. "01000111" equals 70 hours). For the coding and the value range, see the GPRS Timer 3 IE in 3GPP TS 24.008 [8] Table 10.5.163a/3GPP TS 24.008. See also 3GPP TS 23.682 [149] and 3GPP TS 23.401 [82]. The default value, if available, is

	<p>manufacturer specific.</p> <p><b>&lt;Requested_Active-Time&gt;</b></p> <p>String type; one byte in an 8 bit format. Requested Active Time value (T3324) to be allocated to the UE. The requested Active Time value is coded as one byte (octet 3) of the GPRS Timer 2 information element coded as bit format (e.g. "00100100" equals 4 minutes). For the coding and the value range, see the GPRS Timer 2 IE in 3GPP TS 24.008 [8] Table 10.5.163/3GPP TS 24.008. See also 3GPP TS 23.682 [149], 3GPP TS 23.060 [47] and 3GPP TS 23.401 [82]. The default value, if available, is manufacturer specific.</p>
Parameter Saving Mode	AUTO_SAVE
Max Response Time	-
Reference	Note

#### 5.2.21 AT+CEDRXS Entended-DRX Setting

AT+CEDRXS Entended-DRX Setting	
Test Command <b>AT+CEDRXS=?</b>	<p>Response</p> <p><b>+CEDRXS:</b> (list of supported &lt;n&gt;s),&lt;AcT-type&gt;,&lt;Requested_eDRX_value&gt;</p> <p><b>OK</b></p>
Read Command <b>AT+CEDRXS?</b>	<p>Response</p> <p><b>+CEDRXS:</b> &lt;AcT-type&gt;,&lt;Requested_eDRX_value&gt;</p> <p><b>OK</b></p> <p>Parameters See Write Command</p>
Write Command <b>AT+CEDRXS=&lt;n&gt;,&lt;AcT-type&gt;,&lt;Requested_eDRX_value&gt;</b>	<p>Response</p> <p><b>OK</b></p> <p>If failed: <b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters</p> <p><b>&lt;n&gt;</b></p> <ul style="list-style-type: none"> <li>0 Disable the use of eDRX</li> <li>1 Enable the use of eDRX</li> <li>2 Enable the use of eDRX and auto report</li> <li>3 Disable the use of eDRX(Reserved)</li> </ul> <p><b>&lt;AcT-type&gt;</b></p> <ul style="list-style-type: none"> <li>4 CAT-M</li> </ul>



	5 NB-IoT <b>&lt;Requested_eDRX_value&gt;</b> Requested eDRX value. 4 bit format. "0000"-"1111"
Parameter Saving Mode	AUTO_SAVE
Max Response Time	-
Reference	Note ● The Requested_eDRX_value is the value of cycle length, separately means 5.12,10.24,20.48,40.96,61.44,81.92,102.40,122.88,143.36,163.84,327.68,655.36,1310.72,2621.44,5242.88,10485.76.(seconds)

### 5.2.22 AT+CPSI Inquiring UE system information

AT+CPSI Inquiring UE system information	
Test Command AT+CPSI=?	Response <b>OK</b>
Read Command AT+CPSI?	If camping on a gsm cell: <b>+CPSI: &lt;System Mode&gt;,&lt;Operation Mode&gt;,&lt;MCC&gt;-&lt;MNC&gt;,&lt;LAC&gt;,&lt;Cell ID&gt;,&lt;Absolute RF Ch Num&gt;,&lt;RxLev&gt;,&lt;Track LO Adjust&gt;,&lt;C1-C2&gt;</b>  <b>OK</b> If camping on a CAT-M or NB-IOT cell: <b>+CPSI: &lt;System Mode&gt;,&lt;Operation Mode&gt;,&lt;MCC&gt;-&lt;MNC&gt;,&lt;TAC&gt;,&lt;SCellID&gt;,&lt;PCellID&gt;,&lt;Frequency Band&gt;,&lt;earfcn&gt;,&lt;dlbw&gt;,&lt;ulbw&gt;,&lt;RSRQ&gt;,&lt;RSRP&gt;,&lt;RSSI&gt;,&lt;RSSNR&gt;</b>  <b>OK</b> If no service: <b>+CPSI: NO SERVICE,Online</b>  <b>OK</b> If failed: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <b>&lt;System Mode&gt;</b> System mode. "NO SERVICE" "GSM" "LTE CAT-M1" "LTE NB-IOT" <b>&lt;Operation Mode&gt;</b> UE operation mode. "Online",

	<p>"Offline",  "Factory Test Mode",  "Reset",  "Low Power Mode".</p> <p>&lt;MCC&gt; Mobile Country Code (first part of the PLMN code)  &lt;MNC&gt; Mobile Network Code (second part of the PLMN code)  &lt;LAC&gt; Location Area Code (hexadecimal digits)  &lt;Cell ID&gt; Service-cell Identify  &lt;Absolute RF Ch Num&gt; AFRCN for service-cell.  &lt;Track LO Adjust&gt; Track LO Adjust  &lt;C1&gt; Coefficient for base station selection  &lt;C2&gt; Coefficient for Cell re-selection  &lt;TAC&gt; Tracing Area Code  &lt;SCellID&gt; Serving Cell ID  &lt;PCellID&gt; Physical Cell ID  &lt;Frequency Band&gt; Frequency Band of active set  &lt;earfcn&gt; E-UTRA absolute radio frequency channel number for searching CAT-M or NB-IOT cells  &lt;dlbw&gt; Transmission bandwidth configuration of the serving cell on the downlink  &lt;ulbw&gt; Transmission bandwidth configuration of the serving cell on the uplink  &lt;RSRP&gt; Current reference signal received power. Available for CAT-M or NB-IOT.  &lt;RSRQ&gt; Current reference signal receive quality as measured by L1.  &lt;RSSI&gt; Current Received signal strength indicator  &lt;RSSNR&gt; Average reference signal signal-to-noise ratio of the serving cell The value of <b>SINR</b> can be calculated according to &lt;RSSNR&gt;, the formula is as below:  <math display="block">\text{SINR} = 2 * \text{&lt;RSSNR&gt;} - 20</math> The range of <b>SINR</b> is from -20 to 30</p>
Parameter Saving Mode	-
Max Response Time	-
Reference	Note

### 5.2.23 AT+CGNAPN Get Network APN in CAT-M Or NB-IOT

AT+CGNAPN Get Network APN in CAT-M Or NB-IOT	
Test Command	Response
AT+CGNAPN=?	+CGNAPN: (list of supported <valid>s),<length>

	<b>OK</b>
Execution Command <b>AT+CGNAPN</b>	<p>Response <b>+CGNAPN: &lt;valid&gt;,&lt;Network_APN&gt;</b></p> <p><b>OK</b></p> <p>If failed: <b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters</p> <p><b>&lt;valid&gt;</b></p> <ul style="list-style-type: none"> <li>0 The network did not sent APN parameter to UE.In the case,&lt;Network_APN&gt; is NULL.</li> <li>1 The network sent APN parameter to UE.</li> </ul> <p><b>&lt;length&gt;</b></p> <p>Max the length of &lt;network_APN&gt;.</p> <p><b>&lt;Network_APN&gt;</b></p> <p>String type.The network sends APN parameter to UE when UE registers CAT-M or NB-IOT network successfully.In GSM,&lt;Network_APN&gt; always is NULL.</p>
Parameter Saving Mode	-
Max Response Time	-
Reference	<p>Note</p> <ul style="list-style-type: none"> <li>● In CAT-M or NB-IOT,after UE sending attach request message,If core network responds attach accept message that includes APN parameter,&lt;Network_APN&gt; is valid.</li> </ul>

#### 5.2.24 AT+CSDP Service Domain Preference

<b>AT+CSDP Service Domain Preference</b>	
Test Command <b>AT+CSDP=?</b>	<p>Response <b>+CSDP: (list of supported &lt;domain&gt;s)</b></p> <p><b>OK</b></p>
Read Command <b>AT+CSDP?</b>	<p>Response <b>+CSDP: &lt;domain&gt;</b></p> <p><b>OK</b></p> <p>Parameters See Write Command</p>
Write Command <b>AT+CSDP=&lt;do</b>	<p>Response <b>OK</b></p>

<b>main&gt;</b>	If failed: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <b>&lt;domain&gt;</b> 0 CS(Circuit Switched Domain) ONLY 1 PS(Packet Switched Domain) ONLY <u>2</u> CS(Circuit Switched Domain) + PS(Packet Switched Domain)
Parameter Saving Mode	AUTO_SAVE_REBOOT
Max Response Time	-
Reference	Note

### 5.2.25 AT+MCELLLOCK Lock the special CAT-M cell

<b>AT+MCELLLOCK Lock the special CAT-M cell</b>	
Test Command <b>AT+MCELLLOCK=?</b>	Response <b>+MCELLLOCK: (0,1),(0-65535),(0-503)</b>  <b>OK</b>
Read Command <b>AT+MCELLLOCK?</b>	Response <b>+MCELLLOCK: &lt;mode&gt;[,&lt;earfcn&gt;,&lt;pci&gt;]</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+MCELLLOCK=&lt;mode&gt;[,&lt;earfcn&gt;,&lt;pci&gt;]</b>	Response <b>OK</b> If failed: <b>+CME ERROR: &lt;err&gt;</b>
	Parameter <b>&lt;mode&gt;</b> <u>0</u> Unlock 1 Lock <b>&lt;earfcn&gt;</b> A number in the range 0-65535 representing the EARFCN to search <b>&lt;pci&gt;</b> A number in the range 0-503 representing the Physical Cell ID to search
Parameter Saving Mode	AUTO_SAVE_REBOOT
Max Response Time	-
Reference	Note

## 5.2.26 AT+NCELLLOCK Lock the special NB-IOT cell

AT+NCELLLOCK Lock the special NB-IOT cell	
Test Command <b>AT+NCELLLOCK=?</b>	Response <b>+NCELLLOCK: (0,1),(0-65535),(0-503)</b>  <b>OK</b>
Read Command <b>AT+NCELLLOCK?</b>	Response <b>+NCELLLOCK: &lt;mode&gt;[,&lt;earfcn&gt;,&lt;pci&gt;]</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+NCELLLOCK=&lt;mode&gt;[,&lt;earfcn&gt;,&lt;pci&gt;]</b>	Response <b>OK</b> If failed: <b>+CME ERROR: &lt;err&gt;</b>
	Parameter <b>&lt;mode&gt;</b> 0    Unlock 1    Lock <b>&lt;earfcn&gt;</b> A number in the range 0-65535 representing the EARFCN to search <b>&lt;pci&gt;</b> A number in the range 0-503 representing the Physical Cell ID to search
Parameter Saving Mode	AUTO_SAVE_REBOOT
Max Response Time	-
Reference	Note

## 5.2.27 AT+NBSC Config NB-IOT Scrambling Feature

AT+NBSC Config NB-IOT Scrambling Feature	
Test Command <b>AT+NBSC=?</b>	Response <b>+NBSC: (list of supported &lt;mode&gt;s)</b>  <b>OK</b>
Read Command <b>AT+NBSC?</b>	Response <b>+NBSC: &lt;mode&gt;</b>  <b>OK</b>
	Parameters

	See Write Command
Write Command <b>AT+NBSC=&lt;mode&gt;</b>	<p>Response</p> <p><b>OK</b></p> <p>If failed:</p> <p><b>+CME ERROR: &lt;err&gt;</b></p>
	<p>Parameters</p> <p><b>&lt;mode&gt;</b></p> <p>0 Disable the scrambling feature in NB-IOT network.</p> <p>1 Enable the scrambling feature in NB-IOT network.</p>
Parameter Saving Mode	AUTO_SAVE_REBOOT
Max Response Time	-
Reference	<p>Note</p> <ul style="list-style-type: none"> <li>Please configure UE in accordance with the base station,Otherwise UE can not register NB-IOT network.</li> </ul>

### 5.2.28 AT+CAPNMODE Select the Mode of Application Configure APN

<b>AT+CAPNMODE Select the Mode of Application Configure APN</b>	
Test Command <b>AT+CAPNMODE=?</b>	<p>Response</p> <p><b>+CAPNMODE:</b> (list of supported <b>&lt;mode&gt;</b>s)</p> <p><b>OK</b></p>
Read Command <b>AT+CAPNMODE?</b>	<p>Response</p> <p><b>+CAPNMODE: &lt;mode&gt;</b></p> <p><b>OK</b></p> <p>Parameters</p> <p>See Write Command</p>
Write Command <b>AT+CAPNMODE=&lt;mode&gt;</b>	<p>Response</p> <p><b>OK</b></p> <p>If failed:</p> <p><b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters</p> <p><b>&lt;mode&gt;</b> mode of application configure APN.In CAT-M or NB-IOT network,if module has registered to the network successfully,it will get an APN from base station delivering.</p> <p>0 Automatic mode.Applications(AT+CSTT and AT+SAPBR) do not need to config APN,it will use the APN from base station delivering.</p> <p>1 Manual mode,Applications(AT+CSTT,AT+SAPBR) need to config APN,these APNs can get from operators.</p>

Parameter Saving Mode	-
Max Response Time	-
Reference	Note <ul style="list-style-type: none"> <li>● If module are using in GPRS network,you must config <b>&lt;mode&gt;</b> to 1</li> </ul>

### 5.2.29 AT+CRRSTATE Query RRC State

AT+CRRSTATE Query RRC State	
Test Command <b>AT+CRRSTATE E=?</b>	Response <b>+CRRSTATE:</b> (list of supported <b>&lt;n&gt;</b> s)  <b>OK</b>
Read Command <b>AT+CRRSTATE E?</b>	Response <b>+CRRSTATE:</b> <b>&lt;n&gt;</b> , <b>&lt;state&gt;</b>  <b>OK</b>  Parameters See Write Command
Write Command <b>AT+CRRSTATE E=&lt;n&gt;</b>	Response <b>OK</b> If failed: <b>+CME ERROR: &lt;err&gt;</b>  Parameters <b>&lt;n&gt;</b> Integer type 0 Disable unsolicited result code 1 Enable unsolicited result code " <b>+CRRSTATE: &lt;state&gt;</b> " <b>&lt;state&gt;</b> Integer type,indicates RRC connection state 0 Idle 1 Connected 255 Other
Parameter Saving Mode	-
Max Response Time	-
Reference	Note <ul style="list-style-type: none"> <li>● The command is only valid that module registering in CAT-M or NB-IOT network.</li> </ul>

### 5.2.30 AT+CBANDCFG Configure CAT-M Or NB-IOT Band

AT+CBANDCFG Configure CAT-M Or NB-IOT Band	
Test Command	Response

<b>AT+CBANDCFG G=?</b>	<b>+CBANDCFG: (CAT-M,NB-IOT),(list of supported &lt;band&gt;s)</b>  <b>OK</b>
Read Command <b>AT+CBANDCFG G?</b>	Response <b>+CBANDCFG: "CAT-M",&lt;band&gt;[,&lt;band&gt;...]</b> <b>&lt;CR&gt;&lt;LF&gt;+CBANDCFG: "NB-IOT",&lt;band&gt;[,&lt;band&gt;...]</b>  <b>OK</b>  Parameters See Write Command
Write Command <b>AT+CBANDCFG G=&lt;mode&gt;,&lt;band&gt;[,&lt;band&gt;...]</b>	Response <b>OK</b> If failed: <b>+CME ERROR: &lt;err&gt;</b>  Parameters <b>&lt;mode&gt;</b> string type; network system mode. "CAT-M" LTE Cat.M1(eMTC) "NB-IOT" Narrow Band Internet of Things <b>&lt;band&gt;</b> Integer type;The value of <b>&lt;band&gt;</b> must is in the band list of getting from <b>AT+CBANDCFG=?</b>
Parameter Saving Mode	AUTO_SAVE
Max Response Time	-
Reference	Note <ul style="list-style-type: none"> <li>The command can take effect immediately,It does not need to reboot module.</li> </ul>

### 5.2.31 AT+CNACT App Network Active

<b>AT+CNACT App Network Active</b>	
Read Command <b>AT+CNACT?</b>	Response <b>+CNACT: &lt;status&gt;,&lt;ip_addr&gt;</b>  <b>OK</b>  Parameters See Write Command
Write Command <b>AT+CNACT=&lt;mode&gt;[,&lt;apn&gt;]</b>	Response <b>OK</b> If failed: <b>+CME ERROR: &lt;err&gt;</b>  Parameters



	<p><b>&lt;mode&gt;</b></p> <p>0 Deactive</p> <p>1 Active</p> <p>2 Auto Active</p> <p><b>&lt;apn&gt;</b></p> <p>(Access Point Name) A string parameter (string should be included in quotation marks) which is a logical name that is used to select the GGSN or the external packet data network. If the value is null or omitted, then the subscription value will be requested. The default value is NULL.</p> <p><b>&lt;status&gt;</b></p> <p>0 Deactivated</p> <p>1 Activated</p>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	<p>Note</p> <p>"+APP PDP: ACTIVE" will be reported if the app network activated, and "+APP PDP: DEACTIVE" will be reported if the app network deactivated. Auto Active means the will active automatically if the activation failed.</p>

### 5.2.32 AT+CEDUMP Set whether the module reset when the module is crashed

AT+CEDUMP Set whether the module reset when the module is crashed	
Read Command <b>AT+CEDUMP?</b>	<p>Response</p> <p><b>+CEDUMP: &lt;mode&gt;</b></p> <p><b>OK</b></p> <p>If error is related to ME functionality:</p> <p><b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters</p> <p>See Write Command</p>
Write Command <b>AT+CEDUMP=&lt;mode&gt;</b>	<p>Response</p> <p><b>OK</b></p> <p>If error is related to ME functionality:</p> <p><b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters</p> <p><b>&lt;fun&gt;</b></p> <p>0 The module will reset when the module is crashed(Default)</p> <p>1 The module will go into download mode when the module is crashed</p>
Parameter Saving	-

Mode	
Max Response Time	
Reference	Note

### 5.2.33 AT+CNBS Configure Band Scan Optimization For NB-IOT

AT+CNBS Configure Band Scan Optimization for NB-IOT	
Test Command <b>AT+CNBS=?</b>	Response <b>+CNBS: (1-5)</b>  <b>OK</b>
Read Command <b>AT+CNBS?</b>	Response <b>+CNBS: &lt;n&gt;</b>  <b>OK</b>  Parameters See Write Command
Write Command <b>AT+CNBS=&lt;n&gt;</b>	Response <b>OK</b> If failed: <b>+CME ERROR: &lt;err&gt;</b>  Parameters Band scan is performed in the following levels based on the SNR: level 0 Used for good SNR levels(0 db and above); detects strong cells first and takes the shortest time to acquire cells.UE scans each raster in 30 ms. level 1 Used for medium SNR levels(-9 dB and above),UE scans each raster for 200 ms level 2 Used for poor SNR levels(-12.6 dB and above),UE scans each raster for 500 ms.  <b>&lt;n&gt;</b> 1 UE tries SNR level 0 band scan 2 UE tries SNR level 0 and level 1 band scan 3 UE tries SNR level 0, level 1, and level 2 band scan 4 Reserved 5 UE tries SNR level 2 band scan only
Parameter Saving Mode	AUTO_SAVE_REBOOT
Max Response Time	-
Reference	Note

- The command controls the band scan for different SNR levels. This optimization is applicable only for NB-IOT and it reduces the band scan time and power consumption.

### 5.2.34 AT+CNDS Configure Service Domain Preference For NB-IOT

AT+CNDS Configure Service Domain Preference For NB-IOT	
Test Command <b>AT+CNDS=?</b>	Response <b>+CNDS: (list of supported &lt;domain&gt;s)</b>  <b>OK</b>  Parameters See Write Command
Read Command <b>AT+CNDS?</b>	Response <b>+CNDS: &lt;domain&gt;</b>  <b>OK</b>  Parameters See Write Command
Write Command <b>AT+CNDS=&lt;domain&gt;</b>	Response <b>OK</b> If failed: <b>+CME ERROR: &lt;err&gt;</b>  Parameters <b>&lt;domain&gt;</b> <ol style="list-style-type: none"> <li>1 PS(Packet Switched Domain) ONLY</li> <li>2 CS(Circuit Switched Domain) + PS(Packet Switched Domain)</li> </ol>
Parameter Saving Mode	AUTO_SAVE_REBOOT
Max Response Time	-
Reference	Note <ul style="list-style-type: none"> <li>● The command of <b>AT+CSDP</b> is used to config service domain preference for GSM and CAT-M.If you want to config service domain preference for NB-IOT,you can use <b>AT+CNDS</b>.</li> </ul>

### 5.2.35 AT+CENG Switch on or off Engineering Mode

AT+CENG Switch on or off Engineering Mode	
Test Command <b>AT+CENG=?</b>	Response TA returns the list of supported modes. <b>+CENG: (list of supported &lt;mode&gt;s),(list of supported &lt;Ncell&gt;s)</b>

	<b>OK</b>									
	Parameters See Write Command									
Read Command <b>AT+CENG?</b>	<p>Response</p> <p>Engineering Mode is designed to allow a field engineer to view and test the network information received by a handset, when the handset is either in idle mode or dedicated mode (that is: with a call active). In each mode, the engineer is able to view network interaction for the "serving cell" (the cell the handset is currently registered with) or for the neighboring cells.</p> <p>TA returns the current engineering mode. The network information including serving cell and neighboring cells are returned. &lt;cell&gt; carry with them corresponding network interaction.</p> <p>If camping on a gsm cell: <b>+CENG: &lt;mode&gt;,&lt;Ncell&gt;,&lt;cell num&gt;,&lt;System Mode&gt;</b></p> <p>[<b>+CENG: &lt;cell&gt;,"&lt;bcch&gt;,&lt;rxl&gt;,&lt;bsic&gt;,&lt;cellid&gt;,&lt;mcc&gt;,&lt;mnc&gt;,&lt;lac&gt;"&lt;CR&gt;&lt;LF&gt;+CENG:&lt;cell&gt;,"&lt;bcch&gt;,&lt;rxl&gt;,&lt;bsic&gt;,&lt;cellid&gt;,&lt;mcc&gt;,&lt;mnc&gt;,&lt;lac&gt;"...</b>]</p> <p><b>OK</b></p> <p>If camping on a CAT-M or NB-IOT cell: <b>+CENG: &lt;mode&gt;,&lt;Ncell&gt;,&lt;cell num&gt;,&lt;System Mode&gt;</b></p> <p>[<b>+CENG: &lt;cell&gt;,"&lt;earfcn&gt;,&lt;pci&gt;,&lt;rsrp&gt;,&lt;rssi&gt;,&lt;rsrq&gt;,&lt;sinr&gt;,&lt;tac&gt;,&lt;cellid&gt;,&lt;mcc&gt;,&lt;mnc&gt;,&lt;tx power&gt;"&lt;CR&gt;&lt;LF&gt;+CENG:&lt;cell&gt;,"&lt;earfcn&gt;,&lt;pci&gt;,&lt;rsrp&gt;,&lt;rssi&gt;,&lt;rsrq&gt;,&lt;sinr&gt;"...</b>]</p> <p><b>OK</b></p>									
	Parameters See Write Command									
Write Command <b>AT+CENG=&lt;mode&gt;[,&lt;Ncell&gt;]</b>	<p>Switch on or off engineering mode.</p> <p><b>OK</b></p> <p>If failed: <b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters</p> <table><tr><td><b>&lt;mode&gt;</b></td><td>0</td><td>Switch off engineering mode</td></tr><tr><td></td><td>1</td><td>Switch on engineering mode</td></tr><tr><td><b>&lt;Ncell&gt;</b></td><td>1</td><td>Display neighbor cell ID</td></tr></table>	<b>&lt;mode&gt;</b>	0	Switch off engineering mode		1	Switch on engineering mode	<b>&lt;Ncell&gt;</b>	1	Display neighbor cell ID
<b>&lt;mode&gt;</b>	0	Switch off engineering mode								
	1	Switch on engineering mode								
<b>&lt;Ncell&gt;</b>	1	Display neighbor cell ID								

	<p><b>&lt;cell num&gt;</b> The number of cell,it includes serving cell and neighbor cells.</p> <p><b>&lt;System Mode&gt;</b> System mode.</p> <p>"NO SERVICE"</p> <p>"GSM"</p> <p>"LTE CAT-M1"</p> <p>"LTE NB-IOT"</p> <p><b>&lt;cell&gt;</b> 0 The serving cell 1-6 The index of the neighboring cell</p> <p><b>&lt;bcch&gt;</b> ARFCN(Absolute radio frequency channel number) of BCCH carrier, in decimal format</p> <p><b>&lt;rxl&gt;</b> Receive level, in decimal format</p> <p><b>&lt;mcc&gt;</b> Mobile country code, in decimal format</p> <p><b>&lt;mnc&gt;</b> Mobile network code, in decimal format</p> <p><b>&lt;bsic&gt;</b> Base station identity code, in decimal format</p> <p><b>&lt;cellid&gt;</b> Cell id, in hexadecimal format</p> <p><b>&lt;lac&gt;</b> Location area code, in hexadecimal format</p> <p><b>&lt;earfcn&gt;</b> E-UTRA absolute radio frequency channel number for searching CAT-M or NB-IOT cells</p> <p><b>&lt;pci&gt;</b> Physical Cell ID</p> <p><b>&lt;rsrp&gt;</b> Current reference signal received power.Available for CAT-M or NB-IOT.</p> <p><b>&lt;rssi&gt;</b> Current Received signal strength indicator</p> <p><b>&lt;rsrq&gt;</b> Current reference signal receive quality as measured by L1.</p> <p><b>&lt;sinr&gt;</b> Signal to Interference plus Noise Ratio,The range is from -20 to 30.</p> <p><b>&lt;tac&gt;</b> Tracing Area Code, in decimal format</p> <p><b>&lt;tx power&gt;</b> Tx power value in 1/10 dBm. <b>&lt;tx power&gt;</b> is only meaningful when the device is in traffic. When there is no traffic, the value is invalid.The value of <b>&lt;tx power&gt;</b> is 255.</p>
Parameter Saving Mode	-
Max Response Time	-
Reference	Note

### 5.2.36 AT+CNACTCFG IP Protocol Type Config

AT+CNACTCFG IP Protocol Type Config	
Test Command	Response
AT+CNACTCFG?	+CNACTCFG: ("IPV4","IPV6","IPV4V6")
	OK

	Parameters See Write Command
Read Command <b>AT+CNACTCFG?</b>	Response <b>+CNACTCFG: &lt;IPType&gt;</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+CNACTCFG=&lt;IPType&gt;</b>	Response <b>OK</b> If failed: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <b>&lt; IPType &gt;</b> <div> <div>"IPV4"</div> <div>IPv4 protocol</div> </div> <div> <div>"IPV6"</div> <div>IPv6 protocol</div> </div> <div> <div>"IPV4V6"</div> <div>IPv4 and IPv6 protocol</div> </div>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 5.2.37 AT+CTLIIC Control the Switch of IIC

<b>AT+ CTLIIC Control the Switch of IIC</b>	
Test Command <b>AT+CTLIIC=?</b>	Response <b>+CTLIIC: (0,1)</b>  <b>OK</b>
	Parameters See Write Command
Read Command <b>AT+ CTLIIC?</b>	Response <b>+CTLIIC: &lt;mode&gt;</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+CTLIIC=&lt;mode&gt;</b>	Response <b>OK</b> or <b>ERROR</b>

	Parameters <b>&lt;mode&gt;</b> 0 switch off the IIC 1 switch on the IIC
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 5.2.38 AT+CWIIC Write Values to Register of IIC Device

AT+CWIIC Write Values to Register of IIC Device	
Test Command <b>AT+CWIIC=?</b>	Response <b>OK</b>
Write Command <b>AT+CWIIC=&lt;addr&gt;,&lt;reg&gt;,&lt;data&gt;,&lt;len&gt;</b>	Response <b>OK</b> or <b>ERROR</b>  Parameters <b>&lt;addr&gt;</b> Device address. Input format must be hex, such as 0xFF. <b>&lt;reg&gt;</b> Register address. Input format must be hex, such as 0xFF. <b>&lt;len&gt;</b> Read length. Range: 1-4; unit: byte. <b>&lt;data&gt;</b> Data written. Input format must be hex, such as 0xFF-0xFFFFFFFF
Parameter Saving Mode	-
Max Response Time	-
Reference	Note

### 5.2.39 AT+CRIIC Read Values from Register of IIC Device

AT+CRIIC Read Values from Register of IIC Device	
Test Command <b>AT+CRIIC=?</b>	Response <b>OK</b>

Write Command <b>AT+CRHIC=&lt;addr&gt;,&lt;reg&gt;,&lt;len&gt;</b>	Response <b>+CRHIC: &lt;data&gt;</b>  <b>OK</b> or <b>ERROR</b>
	Parameters <addr> Device address. Input format must be hex, such as 0xFF. <reg> Register address. Input format must be hex, such as 0xFF. <len> Read length. Range:1-4; unit:byte. <data> Data read. Input format must be hex, such as 0xFF.
Parameter Saving Mode	-
Max Response Time	-
Reference	Note

#### 5.2.40 AT+SPWM Generate the Pulse-Width-Modulation

<b>AT+SPWM Generate the Pulse-Width-Modulation</b>	
Test Command <b>AT+SPWM=?</b>	Response <b>+SPWM: (list of supported&lt;div&gt;s),(list of supported&lt;level&gt;s)</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+SPWM=&lt;div&gt;,&lt;level&gt;</b>	Response <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <div> The range of <div> is 0-31, the output frequency equals to (192KHz)/(period+1). <level> 0-100: tone level, which can be converted to duty ratio.
Reference	Note <ul style="list-style-type: none"> <li>The equation of final frequency and &lt;period&gt; is this: frequency=192KHz/(period+1), when <b>div</b> is 0 or 1, the period is 1. When <b>div</b> is 2, the period is 1.5. When <b>div</b> is 3, the period is 2. When <b>div</b> is 4, the period is 2.5.....</li> <li>The equation of &lt;level&gt; and duty factor is: duty factor=(level+1).</li> </ul>



## 6 AT Commands for GPRS Support

### 6.1 Overview of AT Commands for GPRS Support

Command	Description
AT+CGATT	Attach or detach from GPRS service
AT+CGDCONT	Define PDP context
AT+CGACT	PDP context activate or deactivate
AT+CGPADDR	Show PDP address
AT+CGREG	Network registration status
AT+CGSMS	Select service for MO SMS messages

### 6.2 Detailed Descriptions of AT Commands for GPRS Support

#### 6.2.1 AT+CGATT Attach or Detach from GPRS Service

AT+CGATT Attach or Detach from GPRS Service	
Test Command AT+CGATT=?	Response +CGATT: (list of supported <state>s)  <b>OK</b>
	Parameters See Write Command
Read Command AT+CGATT?	Response +CGATT: <state>  <b>OK</b>
	Parameters See Write Command
Write Command AT+CGATT=<state>	Response <b>OK</b> If error is related to ME functionality: +CME ERROR: <err>
	Parameters <state>            Indicates the state of GPRS attachment 0   Detached 1   Attached  Other values are reserved and will result in an ERROR response to the Write Command.

Parameter Saving Mode	NO_SAVE
Max Response Time	75 seconds
Reference	Note

### 6.2.2 AT+CGDCONT Define PDP Context

AT+CGDCONT	Define PDP Context
Test Command AT+CGDCONT=?	<p>Response</p> <p>+CGDCONT: (range of supported &lt;cid&gt;s),&lt;PDP_type&gt;,,(list of supported &lt;d_comp&gt;s),(list of supported &lt;h_comp&gt;s)(list of &lt;ipv4_ctrl&gt;s),(list of &lt;emergency_flag&gt;s)</p> <p><b>OK</b></p> <p>Parameters See Write Command</p>
Read Command AT+CGDCONT?	<p>Response</p> <p>+CGDCONT: [&lt;cid&gt;,&lt;PDP_type&gt;,&lt;APN&gt;,&lt;PDP_addr&gt;,&lt;d_comp&gt;,&lt;h_comp&gt;,&lt;ipv4_ctrl&gt;,&lt;emergency_flag&gt;[&lt;CR&gt;&lt;LF&gt;+CGDCONT: &lt;cid&gt;,&lt;PDP_type&gt;,&lt;APN&gt;,&lt;PDP_addr&gt;,&lt;d_comp&gt;,&lt;h_comp&gt;,&lt;ipv4_ctrl&gt;,&lt;emergency_flag&gt;[...]]]</p> <p><b>OK</b></p> <p>Parameters See Write Command</p>
Write Command AT+CGDCONT=<cid>[,<PDP_type>[,<APN>[,<PDP_addr>[,<d_comp>[,<h_comp>[,<ipv4_ctrl>[,<emergency_flag>]]]]]]]	<p>Response</p> <p><b>OK</b></p> <p>or</p> <p><b>ERROR</b></p> <p>Parameters</p> <p>&lt;cid&gt; (PDP Context Identifier) a numeric parameter which specifies a particular PDP context definition. The parameter is local to the TE-MT interface and is used in other PDP context-related commands. The range of permitted values (minimum value=1) is returned by the test form of the command. 1...24</p> <p>&lt;PDP_type&gt; (Packet Data Protocol type) A string parameter which specifies the type of packet data protocol. IP Internet Protocol (IETF STD 5)</p>

	<p>PPP Point to Point Protocol</p> <p>IPV6 Internet Protocol Version 6</p> <p>IPV4V6 Dual PDN Stack</p> <p><b>&lt;APN&gt;</b> (Access Point Name) A string parameter (string should be included in quotation marks) which is a logical name that is used to select the GGSN or the external packet data network. If the value is null or omitted, then the subscription value will be requested. The default value is NULL.</p> <p><b>&lt;PDP_addr&gt;</b> A string parameter that identifies the MT in the address space applicable to the PDP. Format: "&lt;n&gt;.&lt;n&gt;.&lt;n&gt;.&lt;n&gt;" where &lt;n&gt;=0..255 If the value is null or equals 0.0.0.0 a dynamic address will be requested. The allocated address may be read using the +CGPADDR command.</p> <p><b>&lt;d_comp&gt;</b> A numeric parameter that controls PDP data compression</p> <ul style="list-style-type: none"> <li>0 Off (default if value is omitted)</li> <li>1 On</li> <li>2 V.42bis</li> </ul> <p><b>&lt;h_comp&gt;</b> A numeric parameter that controls PDP head compression</p> <ul style="list-style-type: none"> <li>0 Off (default if value is omitted)</li> <li>1 On</li> <li>2 RFC1144</li> <li>3 RFC2507</li> <li>4 RFC3095</li> </ul> <p><b>&lt;ipv4_ctrl&gt;</b> Parameter that controls how the MT/TA requests to get the IPv4 address information:</p> <ul style="list-style-type: none"> <li>0 Address Allocation through NAS Signaling</li> <li>1 on</li> </ul> <p><b>&lt;emergency_flag&gt;</b> Emergency_flag:</p> <ul style="list-style-type: none"> <li>0 Off (default if value is omitted)</li> <li>1 On</li> </ul>
Parameter Saving Mode	AUTO_SAVE
Max Response Time	-
Reference	<p>Note</p> <p>&lt;cid&gt; values 17 to 24 are supported from MPSS JO 1.0+ onwards.</p>

### 6.2.3 AT+CGACT PDP Context Activate or Deactivate

AT+CGACT PDP Context Activate or Deactivate	
Test Command	Response
AT+CGACT=?	+CGACT: (list of supported <state>s)

	<b>OK</b>
	Parameters See Write Command
Read Command <b>AT+CGACT?</b>	Response <b>+CGACT: &lt;cid&gt;,&lt;state&gt;[&lt;CR&gt;&lt;LF&gt;+CGACT: &lt;cid&gt;,&lt;state&gt;...]</b>
	<b>OK</b> Parameters See Write Command
Write Command <b>AT+CGACT=&lt;state&gt;[,&lt;cid&gt;[,&lt;cid&gt;[,&lt;cid&gt;...]]]</b>	Response <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <b>&lt;state&gt;</b> Indicates the state of PDP context activation 0 Deactivated 1 Activated Other values are reserved and will result in an ERROR response to the Write Command. <b>&lt;cid&gt;</b> A numeric parameter which specifies a particular PDP context definition (see +CGDCONT Command). If the <cid> is omitted, it only affects the first cid. <cid> values 17 to 24 are supported from MPSS JO 1.0+ onwards. 1...24
Parameter Saving Mode	NO_SAVE
Max Response Time	150 seconds
Reference	Note <ul style="list-style-type: none"> <li>This command is used to test PDPs with network simulators. Successful activation of PDP on real network is not guaranteed.</li> </ul>

#### 6.2.4 AT+CGPADDR Show PDP Address

<b>AT+CGPADDR Show PDP Address</b>	
Test Command <b>AT+CGPADDR=?</b>	Response <b>+CGPADDR: (list of defined &lt;cid&gt;s)</b>
	<b>OK</b> Parameters See Write Command

<p>Write Command</p> <p><b>AT+CGPADDR=</b>  <b>&lt;cid&gt;[,&lt;cid&gt;[...]</b>  <b>]</b></p>	<p>Response</p> <p><b>+CGPADDR: &lt;cid&gt;,&lt;PDP_addr&gt;</b>  <b>[&lt;CR&gt;&lt;LF&gt;+CGPADDR: &lt;cid&gt;,&lt;PDP_addr&gt;[...]]</b></p> <p><b>OK</b>  or  <b>ERROR</b></p> <p>Parameters</p> <p><b>&lt;cid&gt;</b>      A numeric parameter which specifies a particular PDP context definition (see <b>+CGDCONT</b> Command)  1...24</p> <p><b>&lt;PDP_addr&gt;</b>    String type, IP address  Format: "&lt;n&gt;.&lt;n&gt;.&lt;n&gt;.&lt;n&gt;" where &lt;n&gt;=0..255</p> <p><b>&lt;PDP_addr_IPV4&gt;</b>  A string parameter that identifies the MT in the address space applicable to the PDP.</p> <p><b>&lt;PDP_addr_IPV6&gt;</b>  A string parameter that identifies the MT in the address space applicable to the PDP when the sim_card supports ipv6.  The pdp type must be set to "ipv6" or "ipv4v6" by the AT+CGDCONT command.</p>
<p>Execution Command</p> <p><b>AT+CGPADDR</b></p>	<p>Response</p> <p><b>[+CGPADDR: &lt;cid&gt;,&lt;PDP_addr&gt;] +CGPADDR: &lt;cid&gt;,&lt;PDP_addr&gt;[...]]</b></p> <p><b>OK</b>  If error is related to ME functionality:  <b>+CME ERROR: &lt;err&gt;</b></p> <p>If SIM card supports IPV4V6 type and the PDP_type of the command "AT+CGDCONT" defined is ipv4v6 :</p> <p><b>[+CGPADDR: &lt;cid&gt;,&lt;PDP_addr_IPV4&gt;,&lt;PDP_addr_IPV6&gt;]  +CGPADDR: &lt;cid&gt;,&lt;PDP_addr_IPV4&gt;,&lt;PDP_addr_IPV6&gt; [...]]</b></p> <p><b>OK</b></p> <p>Parameters</p> <p>See Write Command</p>
<p>Parameter Saving Mode</p>	<p>NO_SAVE</p>
<p>Max Response Time</p>	<p>-</p>
<p>Reference</p>	<p>Note</p> <ul style="list-style-type: none"> <li>● &lt;cid&gt; values 17 to 24 are supported from MPSS JO 1.0+ onwards.</li> </ul>

- Write command returns address provided by the network if a connection has been established.

### 6.2.5 AT+CGREG Network Registration Status

AT+CGREG Network Registration Status	
Test Command <b>AT+CGREG=?</b>	<p>Response</p> <p><b>+CGREG:</b> (list of supported &lt;n&gt;s)</p> <p><b>OK</b></p> <p>Parameters</p> <p>See Write Command</p>
Read Command <b>AT+CGREG?</b>	<p>Response</p> <p><b>+CGREG:</b> &lt;n&gt;,&lt;stat&gt;[,&lt;lac&gt;,&lt;ci&gt;,&lt;netact&gt; [,&lt;Active-Time&gt;],&lt;Periodic-RAU&gt;],[&lt;GPRS-READY-timer&gt;]]</p> <p><b>OK</b></p> <p>If error is related to ME functionality: <b>+CME ERROR:</b> &lt;err&gt;</p> <p>Parameters</p> <p>See Write Command</p>
Write Command <b>AT+CGREG[=&lt;n&gt;]</b>	<p>Response</p> <p><b>OK</b></p> <p><b>ERROR</b></p> <p>Parameters</p> <p>&lt;n&gt;      0    Disable network registration unsolicited result code           1    Enable network registration unsolicited result code</p> <p><b>+CGREG: &lt;stat&gt;</b></p> <p>          2    Enable network registration and location information unsolicited result code <b>+CGREG:</b>                  &lt;stat&gt;[,&lt;lac&gt;,&lt;ci&gt;,&lt;netact&gt;]</p> <p>          4    Enable display gprs time and periodic RAU</p> <p><b>&lt;stat&gt;</b></p> <p>          0    Not registered, MT is not currently searching an operator to register to. The GPRS service is disabled, the UE is allowed to attach for GPRS if requested by the user.</p> <p>          1    Registered, home network.</p> <p>          2    Not registered, but MT is currently trying to attach or searching an operator to register to. The GPRS service is enabled, but an allowable PLMN is currently not available. The UE will start a GPRS attach as soon as an allowable PLMN is available.</p> <p>          3    Registration denied, The GPRS service is disabled, the UE</p>

	<p>is not allowed to attach for GPRS if it is requested by the user.</p> <p>4 Unknown</p> <p>5 Registered, roaming</p> <p><b>&lt;lac&gt;</b> String type (string should be included in quotation marks); two byte location area code in hexadecimal format (e.g. "00C3" equals 195 in decimal)</p> <p><b>&lt;ci&gt;</b> String type (string should be included in quotation marks); two bytes cell ID in hexadecimal format</p> <p><b>&lt;netact&gt;</b> 0 User-specified GSM access technology 8 User-specified LTE M1 A GB access technology 9 User-specified LTE NB S1 access technology</p> <p><b>&lt;Active-Time&gt;</b> String type; one byte in an 8 bit format. Requested Active Time value (T3324) to be allocated to the UE. The requested Active Time value is coded as one byte (octet 3) of the GPRS Timer 2 information element coded as bit format (e.g. "00100100" equals 4 minutes).</p> <p><b>&lt;Periodic-RAU&gt;</b> String type; one byte in an 8 bit format. Requested extended periodic TAU value (T3412) to be allocated to the UE in E-UTRAN. The requested extended periodic TAU value is coded as one byte (octet 3) of the GPRS Timer 3 information element coded as bit format (e.g. "01000111" equals 70 hours).</p> <p><b>&lt;GPRS-READY-timer&gt;</b> String type; one byte in an 8 bit format. Requested GPRS READY timer value (T3314) to be allocated to the UE in GERAN/UTRAN. The requested GPRS READY timer value is coded as one byte (octet 2) of the GPRS Timer information element coded as bit format (e.g. "01000011" equals 3 decihours or 18 minutes).</p>
Parameter Saving Mode	-
Max Response Time	-
Reference	Note

### 6.2.6 AT+CGSMS Select Service for MO SMS Messages

AT+CGSMS Select Service for MO SMS Messages	
Test Command AT+CGSMS=?	Response +CGSMS: (list of currently available <service>s)  <b>OK</b>
	Parameters

	See Write Command
Read Command <b>AT+CGSMS?</b>	<p>Response</p> <p><b>+CGSMS: &lt;service&gt;</b></p> <p><b>OK</b></p> <p>Parameters</p> <p>See Write Command</p>
Write Command <b>AT+CGSMS=&lt;service&gt;</b>	<p>Response</p> <p><b>OK</b></p> <p>If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters</p> <p><b>&lt;service&gt;</b>      A numeric parameter which indicates the service or service preference to be used</p> <p>0   Packet Domain(value is not really supported and is internally mapped to 2)</p> <p><u>1</u>   Circuit switched(value is not really supported and is internally mapped to 3)</p> <p>2   Packet Domain preferred (use circuit switched if GPRS not available)</p> <p>3   Circuit switched preferred (use Packet Domain if circuit switched not available)</p>
Parameter Saving Mode	AUTO_SAVE
Max Response Time	-
Reference	Note



## 7 AT Commands for IP Application

### 7.1 Overview

Command	Description
AT+SAPBR	Bearer settings for applications based on IP

### 7.2 Detailed Descriptions of Commands

#### 7.2.1 AT+SAPBR Bearer Settings for Applications Based on IP

AT+SAPBR Bearer Settings for Applications Based on IP	
Test Command AT+SAPBR=?	Response <b>+SAPBR: (0-4),(1-3), "ConParamTag","ConParamValue"</b>
	<b>OK</b>
	Parameters See Write Command
Write Command AT+SAPBR=<cmd_type>,<cid>[,<ConParamTag>,<ConParamValue>]	Response <b>OK</b>
	If <cmd_type>=2 <b>+SAPBR: &lt;cid&gt;,&lt;Status&gt;,&lt;IP_Addr&gt;</b> <b>OK</b>
	If <cmd_type>=4 <b>+SAPBR:</b> <b>&lt;ConParamTag&gt;,&lt;ConParamValue&gt;</b> <b>OK</b>
	Unsolicited Result Code <b>+SAPBR &lt;cid&gt;: DEACT</b>
	Parameters <b>&lt;cmd_type&gt;</b> 0 Close bearer 1 Open bearer 2 Query bearer 3 Set bearer parameters 4 Get bearer parameters
	<b>&lt;cid&gt;</b> Bearer profile identifier <b>&lt;Status&gt;</b> 0 Bearer is connecting

	<p>1 Bearer is connected 2 Bearer is closing 3 Bearer is closed</p> <p><b>&lt;ConParamTag&gt;</b> Bearer parameter</p> <p>"APN" Access point name string: maximum 64 characters</p> <p>"USER" User name string: maximum 32 characters</p> <p>"PWD" Password string: maximum 32 characters</p> <p><b>&lt;ConParamValue&gt;</b> Bearer parameter value</p> <p><b>&lt;IP_Addr&gt;</b> The IP address of bearer</p>
Parameter Saving Mode	NO_SAVE
Max Response Time	<p>When <b>&lt;cmd_type&gt;</b> is 1, 85 seconds</p> <p>When <b>&lt;cmd_type&gt;</b> is 0, 65 seconds</p>
Reference	<p>Note</p> <p>This command is applied to activate some applications such as HTTP, FTP.</p>

## 8 AT Commands for TCPIP Application Toolkit

### 8.1 Overview

Command	Description
AT+CIPMUX	Start up multi-IP connection
AT+CIPSTART	Start up TCP or UDP connection
AT+CIPSEND	Send data through TCP or UDP connection
AT+CIPQSEND	Select data transmitting mode
AT+CIPACK	Query previous connection data transmitting state
AT+CIPCLOSE	Close TCP or UDP connection
AT+CIPSHUT	Deactivate GPRS PDP context
AT+CLPORT	Set local port
AT+CSTT	Start task and set APN, user name, password
AT+CIICR	Bring up wireless connection with GPRS
AT+CIFSR	Get local IP address
AT+CIFSREX	Get Local IP Address extend
AT+CIPSTATUS	Query current connection status
AT+CDNSCFG	Configure domain name server
AT+CDNSGIP	Query the IP address of given domain name
AT+CIPHEAD	Add an IP head at the beginning of a package received
AT+CIPATS	Set auto sending timer
AT+CIPSPRT	Set prompt of '>' when module sends data
AT+CIPSERVER	Configure module as server
AT+CIPCSGP	Set GPRS for connection mode
AT+CIPSRIP	Show remote IP address and port when received data
AT+CIPDPDP	Set whether to check state of GPRS network timing
AT+CIPMODE	Select TCPIP application mode
AT+CIPCCFG	Configure transparent transfer mode
AT+CIPSHOWTP	Display transfer protocol in IP head when received data
AT+CIPUDPMODE	UDP extended mode
AT+CIPRXGET	Get data from network manually
AT+CIPRDTIMER	Set remote delay timer

AT+CIPSGTXT	Select GPRS PDP context
AT+CIPSENDHEX	Set CIPSEND Data Format to HEX
AT+CIPHEXS	Set Output-data Format with suffix
AT+CIPTKA	Set TCP keepalive parameters
AT+CIPOPTION	Enable or Disable TCP nagle algorithm

## 8.2 Detailed Descriptions of Commands

### 8.2.1 AT+CIPMUX Start Up Multi-IP Connection

AT+CIPMUX Start Up Multi-IP Connection	
Test Command AT+CIPMUX=?	Response <b>+CIPMUX: (0,1)</b>  <b>OK</b>  Parameters See Write Command
Read Command AT+CIPMUX?	Response <b>+CIPMUX: &lt;n&gt;</b>  <b>OK</b>  Parameters See Write Command
Write Command AT+CIPMUX=<n>	Response <b>OK</b>  Parameters <n>     0    Single IP connection 1    Multi IP connection
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note <ul style="list-style-type: none"> <li>● Only in IP initial state, <b>AT+CIPMUX=1</b> is effective;</li> <li>● Only when multi IP connection and GPRS application are both shut down, <b>AT+CIPMUX=0</b> is effective.</li> </ul>

### 8.2.2 AT+CIPSTART Start Up TCP or UDP Connection

AT+CIPSTART Start Up TCP or UDP Connection	
Test Command	Response

<p><b>AT+CIPSTART=?</b></p>	<p>1) If AT+CIPMUX=0  <b>+CIPSTART:</b> (list of supported &lt;mode&gt;),( &lt;IP address&gt;),( &lt;port&gt;)  <b>+CIPSTART:</b> (list of supported &lt;mode&gt;),( &lt;domain name&gt;),( &lt;port&gt;)</p> <p><b>OK</b></p> <p>2) If AT+CIPMUX=1  <b>+CIPSTART:</b> (list of supported &lt;n&gt;),(list of supported &lt;mode&gt;),( &lt;IP address&gt;),( &lt;port&gt;)  <b>+CIPSTART:</b> (list of supported &lt;n&gt;),(list of supported &lt;mode&gt;),( &lt;domain name&gt;),( &lt;port&gt;)</p> <p><b>OK</b></p> <p>Parameters  See Write Command</p>
<p>Write Command</p> <p>1)If single IP connection  (+CIPMUX=0)  <b>AT+CIPSTART=&lt;mode&gt;,&lt;IP address&gt;,&lt;port&gt;</b>  Or  <b>AT+CIPSTART=&lt;mode&gt;,&lt;domain name&gt;,&lt;port&gt;</b></p> <p>2)If multi-IP connection  (+CIPMUX=1)  <b>AT+CIPSTART=&lt;n&gt;,&lt;mode&gt;,&lt;address&gt;,&lt;port&gt;</b>  <b>AT+CIPSTART=&lt;n&gt;,&lt;mode&gt;,&lt;domain name&gt;,&lt;port&gt;</b></p>	<p>Response</p> <p>1)If single IP connection (+CIPMUX=0)  If format is right response  <b>OK</b>  otherwise response  If error is related to ME functionality:  <b>+CME ERROR &lt;err&gt;</b>  Response when connection exists  <b>ALREADY CONNECT</b>  Response when connection is successful  <b>CONNECT OK</b>  Otherwise  <b>STATE: &lt;state&gt;</b></p> <p><b>CONNECT FAIL</b></p> <p>2)If multi-IP connection  (+CIPMUX=1)  If format is right  <b>OK</b>,  otherwise response  If error is related to ME functionality:  <b>+CME ERROR &lt;err&gt;</b>  Response when connection exists  &lt;n&gt;,&amp;b&gt;ALREADY CONNECT  If connection is successful  &lt;n&gt;,&amp;b&gt;CONNECT OK  Otherwise  &lt;n&gt;,&amp;b&gt;CONNECT FAIL</p> <p>Parameters  &lt;n&gt;                    0..7        A numeric parameter which indicates the connection</p>

	<p>number</p> <p><b>&lt;mode&gt;</b> A string parameter which indicates the connection type</p> <p>"TCP" Establish a TCP connection</p> <p>"UDP" Establish a UDP connection</p> <p><b>&lt;IP address&gt;</b> A string parameter which indicates remote server IP address</p> <p><b>&lt;port&gt;</b> Remote server port</p> <p><b>&lt;domain name&gt;</b> A string parameter which indicates remote server domain name</p> <p><b>&lt;state&gt;</b> A string parameter which indicates the progress of connecting</p> <p>0 IP INITIAL</p> <p>1 IP START</p> <p>2 IP CONFIG</p> <p>3 IP GPRSACT</p> <p>4 IP STATUS</p> <p>5 TCP CONNECTING/UDP CONNECTING/ SERVER LISTENING</p> <p>6 CONNECT OK</p> <p>7 TCP CLOSING/UDP CLOSING</p> <p>8 TCP CLOSED/UDP CLOSED</p> <p>9 PDP DEACT</p> <p>In Multi-IP state:</p> <p>0 IP INITIAL</p> <p>1 IP START</p> <p>2 IP CONFIG</p> <p>3 IP GPRSACT</p> <p>4 IP STATUS</p> <p>5 IP PROCESSING</p> <p>9 PDP DEACT</p>
Parameter Saving Mode	NO_SAVE
Max Response Time	<p>When mode is multi-IP state, the max response time 75 seconds.</p> <p>When mode is single state, and the state is IP INITIAL, the max response time is 160 seconds.</p>
Reference	<p>Note</p> <ul style="list-style-type: none"> <li>This command allows establishment of a TCP/UDP connection only when the state is IP INITIAL or IP STATUS when it is in single state. In multi-IP state, the state is in IP STATUS only. So it is necessary to process "AT+CIPSHUT" before user establishes a TCP/UDP connection with this command when the state is not IP INITIAL or IP STATUS.</li> <li>When module is in multi-IP state, before this command is executed, it is necessary to process "AT+CSST, AT+CIICR, AT+CIFSR".</li> </ul>

### 8.2.3 AT+CIPSEND Send Data Through TCP or UDP Connection

AT+CIPSEND Send Data Through TCP or UDP Connection	
Test Command <b>AT+CIPSEND=?</b>	<p>Response</p> <p>1) For single IP connection (+CIPMUX=0) <b>+CIPSEND: &lt;length&gt;</b></p> <p><b>OK</b></p> <p>2) For multi IP connection (+CIPMUX=1) <b>+CIPSEND: (0-7),&lt;length&gt;</b></p> <p><b>OK</b></p> <p>Parameters See Write Command</p>
Read Command <b>AT+CIPSEND?</b>	<p>Response</p> <p>1) For single IP connection (+CIPMUX=0) <b>+CIPSEND: &lt;size&gt;</b></p> <p><b>OK</b></p> <p>2) For multi IP connection (+CIPMUX=1) <b>+CIPSEND: &lt;n&gt;,&lt;size&gt;</b></p> <p><b>OK</b></p> <p>Parameters</p> <p><b>&lt;n&gt;</b> A numeric parameter which indicates the connection number</p> <p><b>&lt;size&gt;</b> A numeric parameter which indicates the data length sent at a time</p>
Write Command 1) If single IP connection (+CIPMUX=0) <b>AT+CIPSEND=&lt;length&gt;</b> 2) If multi IP connection (+CIPMUX=1) <b>AT+CIPSEND=&lt;n&gt;[,&lt;length&gt;]</b>	<p>Response</p> <p>This Command is used to send changeable length data</p> <p>If single IP is connected (+CIPMUX=0)</p> <p>If connection is not established or module is disconnected: If error is related to ME functionality: <b>+CME ERROR &lt;err&gt;</b></p> <p>If sending is successful: When +CIPQSEND=0 <b>SEND OK</b></p> <p>When +CIPQSEND=1 <b>DATA ACCEPT: &lt;length&gt;</b></p> <p>If sending fails: <b>SEND FAIL</b></p> <p>If multi IP connection is established (+CIPMUX=1)</p> <p>If connection is not established or module is disconnected: If error is related to ME functionality: <b>+CME ERROR &lt;err&gt;</b></p>

	<p>If sending is successful: When +CIPQSEND=0 <b>&lt;n&gt;,SEND OK</b> When +CIPQSEND=1 <b>DATA ACCEPT: &lt;n&gt;,&lt;length&gt;</b> If sending fails: <b>&lt;n&gt;,SEND FAIL</b></p> <p>Parameters</p> <p><b>&lt;n&gt;</b>                    A numeric parameter which indicates the connection number <b>&lt;length&gt;</b>            A numeric parameter which indicates the length of sending data, it must be less than &lt;size&gt;</p>
<p>Execution Command <b>AT+CIPSEND</b> Response "&gt;", then type data for send, tap CTRL+Z to send, tap ESC to cancel the operation</p>	<p>Response</p> <p>This Command is used to send changeable length data. If single IP connection is established (+CIPMUX=0) If connection is not established or module is disconnected: If error is related to ME functionality: <b>+CME ERROR &lt;err&gt;</b> If sending is successful: When +CIPQSEND=0 <b>SEND OK</b> When +CIPQSEND=1 <b>DATA ACCEPT: &lt;length&gt;</b> If sending fails: <b>SEND FAIL</b></p> <p>Note</p> <p>This Command can only be used in single IP connection mode (+CIPMUX=0) and to send data on the TCP or UDP connection that has been established already. Ctrl-Z is used as a termination symbol. ESC is used to cancel sending data. There are at most &lt;size&gt; bytes which can be sent at a time.</p>
<p>Parameter Saving Mode</p>	<p>NO_SAVE</p>
<p>Max Response Time</p>	<p>When +CIPQSEND=0 and the remote server no response, after 645 seconds, "CLOSE" will be reported.</p>
<p>Reference</p>	<p>Note</p> <ul style="list-style-type: none"> <li>● The data length which can be sent depends on network status.</li> <li>● Set the time that send data automatically with the Command of AT+CIPATS.</li> <li>● Only send data at the status of established connection.</li> </ul>



## 8.2.4 AT+CIPQSEND Select Data Transmitting Mode

AT+CIPQSEND Select Data Transmitting Mode	
Test Command <b>AT+CIPQSEND=?</b>	Response <b>+CIPQSEND: (0,1)</b>  <b>OK</b>
	Parameters See Write Command
Read Command <b>AT+CIPQSEND?</b>	Response <b>+CIPQSEND: &lt;n&gt;</b>  <b>OK</b>
	Parameter See Write Command
Write Command <b>AT+CIPQSEND=&lt;n&gt;</b>	Response <b>OK</b>
	Parameters <b>&lt;n&gt;</b> <u>0</u> Normal mode – when the server receives TCP data, it will respond SEND OK. 1    Quick send mode – when the data is sent to module, it will respond DATA ACCEPT: <n>,<length>, while not responding SEND OK.
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

## 8.2.5 AT+CIPACK Query Previous Connection Data Transmitting State

AT+CIPACK Query Previous Connection Data Transmitting State	
Test Command <b>AT+CIPACK=?</b>	Response <b>OK</b>
Write Command If in multi IP connection (+CIPMUX=1) <b>AT+CIPACK=&lt;n&gt;</b>	Response <b>+CIPACK: &lt;txlen&gt;,&lt;acklen&gt;,&lt;nacklen&gt;</b>  <b>OK</b>
	Parameters <b>&lt;n&gt;</b> A numeric parameter which indicates the connection number <b>&lt;txlen&gt;</b> The data amount which has been sent <b>&lt;acklen&gt;</b> The data amount confirmed successfully by the server <b>&lt;nacklen&gt;</b> The data amount without confirmation by the server

Execution Command If in single IP connection (+CIPMUX=0) <b>AT+CIPACK</b>	Response <b>+CIPACK: &lt;txlen&gt;,&lt;acklen&gt;,&lt;nacklen&gt;</b>  <b>OK</b>
Parameter Saving Mode	Parameters See Write Command
Max Response Time	-
Reference	Note

### 8.2.6 AT+CIPCLOSE Close TCP or UDP Connection

<b>AT+CIPCLOSE</b>	<b>Close TCP or UDP Connection</b>
Test Command <b>AT+CIPCLOSE=?</b>	Response <b>OK</b>
Write Command 1) If single IP connection (+CIPMUX=0)  <b>AT+CIPCLOSE=&lt;n&gt;</b> 2) If multi IP connection (+CIPMUX=1) <b>AT+CIPCLOSE=&lt;id&gt;,&lt;n&gt;</b>	Response: 1) For single IP connection (+CIPMUX=0) <b>CLOSE OK</b> 2) For multi IP connection (+CIPMUX=1) <b>&lt;id&gt;,&lt;n&gt;,CLOSE OK</b>
Parameters <b>&lt;n&gt;</b> 0 Slow close 1 Quick close <b>&lt;id&gt;</b> A numeric parameter which indicates the connection number	
Execution Command <b>AT+CIPCLOSE</b>	Response If close is successfully: <b>CLOSE OK</b> If close fails: <b>ERROR</b>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note AT+CIPCLOSE only closes connection at corresponding status of TCP/UDP stack. To see the status use AT+CIPSTATUS command. Status

	<p>should be:</p> <p>TCP CONNECTING, UDP CONNECTING, SERVER LISTENING or CONNECT OK in single-connection mode (see &lt;state&gt; parameter);</p> <p>CONNECTING or CONNECTED in multi-connection mode (see &lt;client state&gt;);</p> <p>OPENING or LISTENING in multi-connection mode (see &lt;server state&gt;).</p> <p>Otherwise it will return "ERROR".</p>
--	--

## 8.2.7 AT+CIPSHUT Deactivate GPRS PDP Context

AT+CIPSHUT Deactivate GPRS PDP Context	
Test Command <b>AT+CIPSHUT=?</b>	Response <b>OK</b>
Execution Command <b>AT+CIPSHUT</b>	<p>Response</p> <p>If close is successful: <b>SHUT OK</b></p> <p>If close fails: <b>ERROR</b></p>
Parameter Saving Mode	NO_SAVE
Max Response Time	65 seconds
Reference	<p>Note</p> <ul style="list-style-type: none"> <li>● If this command is executed in multi-connection mode, all of the IP connection will be shut.</li> <li>● User can close gprs pdp context by AT+CIPSHUT. After it is closed, the status is IP INITIAL.</li> <li>● If "+PDP: DEACT" urc is reported which means the gprs is released by the network, then user still needs to execute "AT+CIPSHUT" command to make PDP context come back to original state.</li> </ul>

## 8.2.8 AT+CLPORT Set Local Port

AT+CLPORT Set Local Port	
Test Command <b>AT+CLPORT=?</b>	<p>Response</p> <p>1) For single IP connection (+CIPMUX=0) <b>+CLPORT: ("TCP","UDP"),(0-65535)</b></p> <p><b>OK</b></p> <p>2) For multi IP connection (+CIPMUX=1) <b>+CLPORT: (0-7),("TCP","UDP"),(0-65535)</b></p> <p><b>OK</b></p>
	Parameters

	See Write Command
Read Command <b>AT+CLPORT?</b>	<p>Response</p> <p>1) For single IP connection (+CIPMUX=0) <b>+CLPORT: &lt;TCP port&gt;,&lt;UDP port&gt;</b></p> <p><b>OK</b></p> <p>2) For multi IP connection (+CIPMUX=1) <b>+CLPORT: 0,&lt;TCP port&gt;,&lt;UDP port&gt;</b> <b>+CLPORT: 1,&lt;TCP port&gt;,&lt;UDP port&gt;</b> <b>+CLPORT: 2,&lt;TCP port&gt;,&lt;UDP port&gt;</b> <b>+CLPORT: 3,&lt;TCP port&gt;,&lt;UDP port&gt;</b> <b>+CLPORT: 4,&lt;TCP port&gt;,&lt;UDP port&gt;</b> <b>+CLPORT: 5,&lt;TCP port&gt;,&lt;UDP port&gt;</b> <b>+CLPORT: 6,&lt;TCP port&gt;,&lt;UDP port&gt;</b> <b>+CLPORT: 7,&lt;TCP port&gt;,&lt;UDP port&gt;</b></p> <p><b>OK</b></p> <p>Parameters See Write Command</p>
Write Command 1) For single IP connection (+CIPMUX=0) <b>AT+CLPORT=&lt;mode&gt;,&lt;port&gt;</b> 2) For multi IP connection (+CIPMUX=1) <b>AT+CLPORT=&lt;n&gt;,&lt;mode&gt;,&lt;port&gt;</b>	<p>Response</p> <p><b>OK</b> <b>ERROR</b></p> <p>Parameters</p> <p><b>&lt;n&gt;</b>            0..7        A numeric parameter which indicates the connection number    this used in multi IP connection</p> <p><b>&lt;mode&gt;</b>            A string parameter which indicates the connection type                       "TCP"        TCP local port                       "UDP"        UDP local port</p> <p><b>&lt;port&gt;</b>            0-65535 A numeric parameter which indicates the local port.                       Default value is 0, a port can be dynamically allocated a port.</p>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	<p>Note</p> <p>This command will be effective when module is set as a Client.</p>

### 8.2.9 AT+CSTT Start Task and Set APN, USER NAME, PASSWORD

<b>AT+CSTT Start Task and Set APN, USER NAME, PASSWORD</b>	
Test Command <b>AT+CSTT=?</b>	<p>Response</p> <p><b>+CSTT: "APN","USER","PWD"</b></p>

	<b>OK</b> Parameters See Write Command
Read Command <b>AT+CSTT?</b>	Response <b>+CSTT: &lt;apn&gt;,&lt;user name&gt;,&lt;password&gt;</b>  <b>OK</b> Parameters See Write Command
Write Command <b>AT+CSTT=&lt;apn&gt;,&lt;user name&gt;,&lt;password&gt;</b>	Response <b>OK</b> <b>ERROR</b> Parameters <b>&lt;apn&gt;</b> A string parameter which indicates the GPRS access point name. The max length is 50 bytes.Default value is "CMNET". <b>&lt;user name&gt;</b> A string parameter which indicates the GPRS user name. The max length is 50 bytes. <b>&lt;password&gt;</b> A string parameter which indicates the GPRS password. The max length is 50 bytes.
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Execution Command <b>AT+CSTT</b>	Response <b>OK</b> <b>ERROR</b>
Reference	Note The write command and execution command of this command is valid only at the state of IP INITIAL. After this command is executed, the state will be changed to IP START.

### 8.2.10 AT+CIICR Bring Up Wireless Connection with GPRS

<b>AT+CIICR Bring Up Wireless Connection with GPRS</b>	
Test Command <b>AT+CIICR=?</b>	Response <b>OK</b>
Execution Command <b>AT+CIICR</b>	Response <b>OK</b> <b>ERROR</b>
Parameter Saving Mode	NO_SAVE

Max Response Time	85 seconds
Reference	<p>Note</p> <ul style="list-style-type: none"> <li>● AT+CIICR only activates moving scene at the status of IP START, after operating this Command is executed, the state will be changed to IP CONFIG.</li> <li>● After module accepts the activated operation, if it is activated successfully, module state will be changed to IP GPRSACT, and it responds OK, otherwise it will respond ERROR.</li> </ul>

### 8.2.11 AT+CIFSR Get Local IP Address

AT+CIFSR Get Local IP Address	
Test Command <b>AT+CIFSR=?</b>	Response <b>OK</b>
Execution Command <b>AT+CIFSR</b>	Response <b>&lt;IP address&gt;</b> <b>ERROR</b>
	Parameter <b>&lt;IP address&gt;</b> A string parameter which indicates the IP address assigned from GPRS
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	<p>Note</p> <p>Only after PDP context is activated, local IP address can be obtained by AT+CIFSR, otherwise it will respond ERROR. To see the status use AT+CIPSTATUS command. Status should be:  IP GPRSACT, TCP CONNECTING, UDP CONNECTING, SERVER LISTENING, IP STATUS, CONNECT OK, TCP CLOSING, UDP CLOSING, TCP CLOSED, UDP CLOSED in single-connection mode (see &lt;state&gt; parameter);  IP STATUS, IP PROCESSING in multi-connection mode (see &lt;state&gt; parameter).</p>

### 8.2.12 AT+CIFSREX Get Local IP Address extend

AT+CIFSREX Get Local IP Address extend	
Test Command <b>AT+CIFSREX=?</b>	Response <b>OK</b>
Execution Command	Response <b>+CIFSREX: &lt;IP address&gt;</b>

<b>AT+CIFSREX</b>	<b>OK</b>
	Parameter <IP address> A string parameter which indicates the IP address assigned from GPRS
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	<p>Note</p> <p>Only after PDP context is activated, local IP address can be obtained by AT+CIFSR, otherwise it will respond ERROR. To see the status use AT+CIPSTATUS command. Status should be:</p> <p>IP GPRSACT, TCP CONNECTING, UDP CONNECTING, SERVER LISTENING, IP STATUS, CONNECT OK, TCP CLOSING, UDP CLOSING, TCP CLOSED, UDP CLOSED in single-connection mode (see &lt;state&gt; parameter);</p> <p>IP STATUS, IP PROCESSING in multi-connection mode (see &lt;state&gt; parameter).</p>

### 8.2.13 AT+CIPSTATUS Query Current Connection Status

<b>AT+CIPSTATUS Query Current Connection Status</b>	
Test Command <b>AT+CIPSTATUS=?</b>	Response <b>OK</b>
Write Command If multi IP connection mode (+CIPMUX=1) <b>AT+CIPSTATUS=&lt;n&gt;</b>	<p>Response <b>+CIPSTATUS: &lt;n&gt;,&lt;bearer&gt;,&lt;TCP/UDP&gt;,&lt;IP address&gt;,&lt;port&gt;,&lt;client state&gt;</b></p> <p><b>OK</b></p> <p>Parameters See Execution Command</p>
Execution Command <b>AT+CIPSTATUS</b>	<p>Response</p> <p>1) If in single connection mode (+CIPMUX=0) <b>OK</b></p> <p><b>STATE: &lt;state&gt;</b></p> <p>2) If in multi-connection mode (+CIPMUX=1) <b>OK</b></p> <p><b>STATE: &lt;state&gt;</b></p>

	<p>If the module is set as server</p> <p><b>S: 0,&lt;bearer&gt;,&lt;port&gt;,&lt;server state&gt;</b></p> <p><b>C: &lt;n&gt;,&lt;bearer&gt;,&lt;TCP/UDP&gt;,&lt;IP address&gt;,&lt;port&gt;,&lt;client state&gt;</b></p> <p>Parameters</p> <p><b>&lt;n&gt;</b> 0-7 A numeric parameter which indicates the connection number</p> <p><b>&lt;bearer&gt;</b> 0-1 GPRS bearer, default is 0</p> <p><b>&lt;server state&gt;</b> OPENING LISTENING CLOSING</p> <p><b>&lt;client state&gt;</b> INITIAL CONNECTING CONNECTED REMOTE CLOSING CLOSING CLOSED</p> <p><b>&lt;state&gt;</b> A string parameter which indicates the progress of connecting</p> <p>0 IP INITIAL 1 IP START 2 IP CONFIG 3 IP GPRSACT 4 IP STATUS 5 TCP CONNECTING/UDP CONNECTING /SERVER LISTENING 6 CONNECT OK 7 TCP CLOSING/UDP CLOSING 8 TCP CLOSED/UDP CLOSED 9 PDP DEACT</p> <p>In Multi-IP state:</p> <p>0 IP INITIAL 1 IP START 2 IP CONFIG 3 IP GPRSACT 4 IP STATUS 5 IP PROCESSING 9 PDP DEACT</p>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note



## 8.2.14 AT+CDNSCFG Configure Domain Name Server

AT+CDNSCFG Configure Domain Name Server	
Test Command <b>AT+CDNSCFG=?</b>	Response <b>+CDNSCFG: ("Primary DNS"),("Secondary DNS")</b>  <b>OK</b>  Parameters See Write Command
Read Command <b>AT+CDNSCFG?</b>	Response <b>PrimaryDns: &lt;pri_dns&gt;</b> <b>SecondaryDns: &lt;sec_dns&gt;</b>  <b>OK</b>  Parameter See Write Command
Write Command <b>AT+CDNSCFG=&lt;pri_dns&gt;[,&lt;sec_dns&gt;]</b>	Response <b>OK</b> <b>ERROR</b>  Parameters <b>&lt;pri_dns&gt;</b> A string parameter which indicates the IP address of the primary domain name server. Default value is 0.0.0.0. <b>&lt;sec_dns&gt;</b> A string parameter which indicates the IP address of the secondary domain name server. Default value is 0.0.0.0.
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

## 8.2.15 AT+CDNSGIP Query the IP Address of Given Domain Name

AT+CDNSGIP Query the IP Address of Given Domain Name	
Test Command <b>AT+CDNSGIP=?</b>	Response <b>OK</b>
Write Command <b>AT+CDNSGIP=&lt;domain name&gt;</b>	Response <b>OK</b> <b>ERROR</b> If successful, return: <b>+CDNSGIP: 1,&lt;domain name&gt;,&lt;IP1&gt;[,&lt;IP2&gt;]</b> If fail, return:

	<b>+CDNSGIP:0,&lt;dns error code&gt;</b> Parameters <b>&lt;domain name&gt;</b> A string parameter which indicates the domain name <b>&lt;IP1&gt;</b> A string parameter which indicates the first IP address corresponding to the domain name <b>&lt;IP2&gt;</b> A string parameter which indicates the second IP address corresponding to the domain name <b>&lt;dns error code&gt;</b> A numeric parameter which indicates the error code 8 DNS COMMON ERROR 3 NETWORK ERROR There are some other error codes as well.
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

#### 8.2.16 AT+CIPHEAD Add an IP Head at the Beginning of a Package Received

AT+CIPHEAD Add an IP Head at the Beginning of a Package Received	
Test Command <b>AT+CIPHEAD=?</b>	Response <b>+CIPHEAD:</b> (list of supported <b>&lt;mode&gt;</b> s)  <b>OK</b> Parameter See Write Command
Read Command <b>AT+CIPHEAD?</b>	Response <b>+CIPHEAD: &lt;mode&gt;</b>  <b>OK</b> Parameters See Write Command
Write Command <b>AT+CIPHEAD=&lt;mode&gt;</b>	Response <b>OK</b> <b>ERROR</b> Parameters <b>&lt;mode&gt;</b> A numeric parameter which indicates whether an IP header is added to the received data or not. <u>0</u> Not add IP header 1 Add IP header, the format is: 1) For single IP connection (+CIPMUX=0) <b>+IPD,&lt;data length&gt;:</b>

	2) For multi IP connection (+CIPMUX=1) <b>+RECEIVE,&lt;n&gt;,&lt;data length&gt;:</b>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 8.2.17 AT+CIPATS Set Auto Sending Timer

AT+CIPATS Set Auto Sending Timer	
Test Command <b>AT+CIPATS=?</b>	Response <b>+CIPATS:</b> (list of supported <mode>s),(list of supported <time>)  <b>OK</b>  Parameters See Write Command
Read Command <b>AT+CIPATS?</b>	Response <b>+CIPATS:</b> <mode>,<time>  <b>OK</b>  Parameters See Write Command
Write Command <b>AT+CIPATS=&lt;mode&gt;[,&lt;time&gt;]</b>	Response <b>OK</b> <b>ERROR</b>  Parameters <mode>      A numeric parameter which indicates whether set timer when module is sending data 0    Not set timer when module is sending data 1    Set timer when module is sending data <time>        1..100    A numeric parameter which indicates the seconds after which the data will be sent
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

## 8.2.18 AT+CIPSPRT Set Prompt of ‘>’ When Module Sends Data

AT+CIPSPRT Set Prompt of ‘>’ When Module Sends Data	
Test Command <b>AT+CIPSPRT=?</b>	Response <b>+CIPSPRT:</b> (list of supported <send prompt>s)  <b>OK</b>  Parameters See Write Command
Read Command <b>AT+CIPSPRT?</b>	Response <b>+CIPSPRT:</b> <send prompt>  <b>OK</b>  Parameters See Write Command
Write Command <b>AT+CIPSPRT=&lt;send prompt&gt;</b>	Response <b>OK</b> <b>ERROR</b>  Parameters <b>&lt;send prompt&gt;</b> A numeric parameter which indicates whether to echo prompt ‘>’ after module issues AT+CIPSEND command. 0 It shows "send ok" but does not prompt echo ‘>’ when sending is successful. 1 It prompts echo ‘>’ and shows "send ok" when sending is successful. 2 It neither prompts echo ‘>’ nor shows "send ok" when sending is successful.
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

## 8.2.19 AT+CIPSERVER Configure Module as Server

AT+CIPSERVER Configure Module as Server	
Test Command <b>AT+CIPSERVER=?</b>	Response <b>+CIPSERVER:</b> (0-CLOSE SERVER, 1-OPEN SERVER),(1-65535)  <b>OK</b>  Parameters See Write Command

Read Command <b>AT+CIPSERVER R?</b>	Response <b>+CIPSERVER: &lt;mode&gt;[,&lt;port&gt;,&lt;channel id&gt;,&lt;bearer&gt;]</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+CIPSERVER R=&lt;mode&gt;[,&lt;port&gt;]</b>	Response <b>OK</b> <b>ERROR</b>
	Parameters <b>&lt;mode&gt;</b> <u>0</u> Close server 1    Open server <b>&lt;port&gt;</b> 1..65535    Listening port <b>&lt;channel id&gt;</b> Channel id <b>&lt;bearer&gt;</b> GPRS bearer
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note This command is allowed to establish a TCP server only when the state is IP INITIAL or IP STATUS when it is in single state. In multi-IP state, the state is in IP STATUS only.

## 8.2.20 AT+CIPCSGP Set GPRS for Connection Mode

<b>AT+CIPCSGP Set GPRS for Connection Mode</b>	
Test Command <b>AT+CIPCSGP=?</b>	Response <b>+CIPCSGP: 1-GPRS,APN,USER NAME,PASSWORD</b>  <b>OK</b>
	Parameters See Write Command
Read Command <b>AT+CIPCSGP?</b>	Response <b>+CIPCSGP: &lt;mode&gt;,&lt;apn&gt;,&lt;user name&gt;,&lt;password&gt;[,&lt;rate&gt;]</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+CIPCSGP=&lt;mode&gt;[,(&lt;apn&gt;,&lt;user name&gt;,&lt;password&gt;[,&lt;rate&gt;])]</b>	Response <b>OK</b> <b>ERROR</b>
	Parameters

<password>)]	<p>&lt;mode&gt; A numeric parameter which indicates the wireless connection mode</p> <p><u>1</u> set GPRS as wireless connection mode</p> <p>&lt;apn&gt; A string parameter which indicates the access point name</p> <p>&lt;user name&gt; A string parameter which indicates the user name</p> <p>&lt;password&gt; A string parameter which indicates the password</p>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 8.2.21 AT+CIPSRIP Show Remote IP Address and Port When Received Data

AT+CIPSRIP Show Remote IP Address and Port When Received Data	
Test Command <b>AT+CIPSRIP=?</b>	<p>Response</p> <p><b>+CIPSRIP:</b> (list of supported &lt;mode&gt;s)</p> <p><b>OK</b></p> <p>Parameters</p> <p>See Write Command</p>
Read Command <b>AT+CIPSRIP?</b>	<p>Response</p> <p><b>+CIPSRIP:</b> &lt;mode&gt;</p> <p><b>OK</b></p> <p>Parameters</p> <p>See Write Command</p>
Write Command <b>AT+CIPSRIP=&lt;mode&gt;</b>	<p>Response</p> <p><b>OK</b></p> <p><b>ERROR</b></p> <p>Parameters</p> <p>&lt;mode&gt; A numeric parameter which shows remote IP address and port.</p> <p><u>0</u> Do not show the prompt</p> <p><u>1</u> Show the prompt, the format is as follows:</p> <p>1) For single IP connection (+CIPMUX=0)</p> <p><b>RECV FROM:&lt;IP ADDRESS&gt;:&lt;PORT&gt;</b></p> <p>1) For multi IP connection (+CIPMUX=1)</p> <p><b>+RECEIVE,&lt;n&gt;,&lt;data length&gt;,&lt;IP ADDRESS&gt;:&lt;PORT&gt;</b></p>
Parameter Saving Mode	NO_SAVE
Max Response	-

Time	
Reference	

### 8.2.22 AT+CIPDPPD Set Whether to Check State of GPRS Network Timing

AT+CIPDPPD Set Whether to Check State of GPRS Network Timing	
Test Command <b>AT+CIPDPPD=?</b>	Response <b>+CIPDPPD:</b> (list of supported<mode>s, list of supported <interval>, list of supported <timer>)  <b>OK</b>
	Parameters See Write Command
Read Command <b>AT+CIPDPPD?</b>	Response <b>+CIPDPPD:</b> <mode>,<interval>,<timer>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+CIPDPPD=&lt;mode&gt;[,&lt;interval&gt;,&lt;timer&gt;]</b>	Response <b>OK</b> <b>ERROR</b>
	Parameters <b>&lt;mode&gt;</b> 0 Not set detect PDP <u>1</u> Set detect PDP <b>&lt;interval&gt;</b> 1<=interval<=180(s), default value is 10. <b>&lt;timer&gt;</b> 1<=timer<=10, default value is 3.
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note If "+PDP: DEACT" urc is reported because of module not attaching to gprs for a certain time or other reasons, user still needs to execute "AT+CIPSHUT" command makes PDP context come back to original state.

### 8.2.23 AT+CIPMODE Select TCPIP Application Mode

AT+CIPMODE Select TCPIP Application Mode
--

Test Command <b>AT+CIPMODE=?</b>	Response <b>+CIPMODE: (0-NORMAL MODE,1-TRANSPARENT MODE)</b>
	<b>OK</b>
	Parameters See Write Command
Read Command <b>AT+CIPMODE?</b>	Response <b>+CIPMODE: &lt;mode&gt;</b>
	<b>OK</b>
	Parameters See Write Command
Write Command <b>AT+CIPMODE=&lt;mode&gt;</b>	Response <b>OK</b> <b>ERROR</b>
	Parameters <b>&lt;mode&gt;</b> <u>0</u> Normal mode 1   Transparent mode
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

#### 8.2.24 AT+CIPCCFG Configure Transparent Transfer Mode

<b>AT+CIPCCFG Configure Transparent Transfer Mode</b>	
Test Command <b>AT+CIPCCFG=?</b>	Response <b>+CIPCCFG:</b> <b>(NmRetry:3-8),(WaitTm:1-10),(SendSz:1-1460),(esc:0,1) ,(Rxmode:0,1),</b> <b>(RxSize:50-1460),(Rxtimer:20-1000)</b>
	<b>OK</b>
	Parameters See Write Command
Read Command <b>AT+CIPCCFG?</b>	Response <b>+CIPCCFG:</b> <b>&lt;NmRetry&gt;,&lt;WaitTm&gt;,&lt;SendSz&gt;,&lt;esc&gt;,&lt;Rxmode&gt;,&lt;RxSize&gt;,&lt;Rxtime</b> <b>r&gt;</b>
	<b>OK</b>
	Parameters



	See Write Command
Write Command <b>AT+CIPCCFG=</b> <b>&lt;NmRetry&gt;,&lt;WaitTm&gt;,&lt;SendSz&gt;,&lt;esc&gt;[,&lt;Rxmode&gt;,&lt;RxSize&gt;,&lt;Rxtimer&gt;]</b>	Response <b>OK</b> <b>ERROR</b> Parameters <b>&lt;NmRetry&gt;</b> Number of retries to be made for an IP packet.Default value is 5. <b>&lt;WaitTm&gt;</b> Number of 100ms intervals to wait for serial input before sending the packet. Default value is 1. <b>&lt;SendSz&gt;</b> Size in bytes of data block to be received from serial port before sending. Default value is 1024. <b>&lt;esc&gt;</b> Whether turn on the escape sequence, default is TRUE. 0      Turn off the escape sequence 1      Turn on the escape sequence <b>&lt;Rxmode&gt;</b> Whether to set time interval during output data from serial port. 0      output data to serial port without interval 1      output data to serial port within <Rxtimer> interval. <b>&lt;RxSize&gt;</b> Output data length for each time. Default value is 1460. <b>&lt;Rxtimer&gt;</b> Time interval (ms) to wait for serial port to output data again. Default value: 50ms
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note This command will be effective only in single connection mode (+CIPMUX=0)

### 8.2.25 AT+CIPSHOWTP Display Transfer Protocol in IP Head When Received Data

<b>AT+CIPSHOWTP Display Transfer Protocol in IP Head When Received Data</b>	
Test Command <b>AT+CIPSHOWTP=?</b>	Response <b>+CIPSHOWTP: (list of supported &lt;mode&gt;s)</b>  <b>OK</b> Parameters See Write Command
Read Command <b>AT+CIPSHOWTP?</b>	Response <b>+CIPSHOWTP: &lt;mode&gt;</b>  <b>OK</b> Parameters

	See Write Command
Write Command <b>AT+CIPSHOWTP</b> <b>=&lt;mode&gt;</b>	Response <b>OK</b> <b>ERROR</b> Parameters <b>&lt;mode&gt;</b> A numeric parameter which indicates whether to display transfer protocol in IP header to received data or not <div> <u>0</u> Not display transfer protocol  1 Display transfer protocol, the format is "+IPD, &lt;data size&gt;,&lt;TCP/UDP&gt;:&lt;data&gt;" </div>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note <ul style="list-style-type: none"> <li>This command will be effective only in single connection mode (+CIPMUX=0).</li> <li>Only when +CIPHEAD is set to 1, the setting of this command will work.</li> </ul>

## 8.2.26 AT+CIPUDPMODE UDP Extended Mode

<b>AT+CIPUDPMODE UDP Extended Mode</b>	
Test Command <b>AT+CIPUDPMODE=?</b>	Response 1) For single IP connection (+CIPMUX=0) <b>+CIPUDPMODE: (0-2),("0-255).(0-255).(0-255).(0-255)",(1-65535)</b>  <b>OK</b> 2) For multi IP connection (+CIPMUX=1) <b>+CIPUDPMODE: (0-5),(0-2),("0-255).(0-255).(0-255).(0-255)",(1-65535)</b>  <b>OK</b> Parameters See Write Command
Read Command <b>AT+CIPUDPMODE=?</b>	Response 1) For single IP connection (+CIPMUX=0) <b>+CIPUDPMODE: &lt;mode&gt;[,&lt;IP address&gt;,&lt;Port&gt;]</b>  <b>OK</b> 2) For multi IP connection (+CIPMUX=1) <b>+CIPUDPMODE: 0,&lt;mode&gt;[,&lt;IP address&gt;,&lt;Port&gt;]</b> <b>+CIPUDPMODE: 1,&lt;mode&gt;[,&lt;IP address&gt;,&lt;Port&gt;]</b> <b>+CIPUDPMODE: 2,&lt;mode&gt;[,&lt;IP address&gt;,&lt;Port&gt;]</b>

	<b>+CIPUDPMODE: 3,&lt;mode&gt;[,&lt;IP address&gt;,&lt;Port&gt;]</b> <b>+CIPUDPMODE: 4,&lt;mode&gt;[,&lt;IP address&gt;,&lt;Port&gt;]</b> <b>+CIPUDPMODE: 5,&lt;mode&gt;[,&lt;IP address&gt;,&lt;Port&gt;]</b> <b>+CIPUDPMODE: 6,&lt;mode&gt;[,&lt;IP address&gt;,&lt;Port&gt;]</b> <b>+CIPUDPMODE: 7,&lt;mode&gt;[,&lt;IP address&gt;,&lt;Port&gt;]</b>  <b>OK</b>														
	Parameter See Write Command														
Write Command 1) For single IP connection (+CIPMUX=0) <b>AT+CIPUDPMODE=&lt;mode&gt;[,&lt;IP address&gt;,&lt;Port&gt;]</b> 2) For multi IP connection (+CIPMUX=1) <b>AT+CIPUDPMODE=&lt;n&gt;,&lt;mode&gt;[,&lt;IP address&gt;,&lt;Port&gt;]</b>	Response <b>OK</b> <b>ERROR</b>  <table> <tr> <td><b>&lt;n&gt;</b></td><td>0-7 A numeric parameter which indicates the connection number</td></tr> <tr> <td><b>&lt;mode&gt;</b></td><td> <table> <tr> <td>0</td><td>UDP Normal Mode</td></tr> <tr> <td>1</td><td>UDP Extended Mode</td></tr> <tr> <td>2</td><td>Set UDP address to be sent</td></tr> </table> </td></tr> <tr> <td><b>&lt;IP address&gt;</b></td><td>A string parameter which indicates remote IP address</td></tr> <tr> <td><b>&lt;port&gt;</b></td><td>Remote port</td></tr> </table>	<b>&lt;n&gt;</b>	0-7 A numeric parameter which indicates the connection number	<b>&lt;mode&gt;</b>	<table> <tr> <td>0</td><td>UDP Normal Mode</td></tr> <tr> <td>1</td><td>UDP Extended Mode</td></tr> <tr> <td>2</td><td>Set UDP address to be sent</td></tr> </table>	0	UDP Normal Mode	1	UDP Extended Mode	2	Set UDP address to be sent	<b>&lt;IP address&gt;</b>	A string parameter which indicates remote IP address	<b>&lt;port&gt;</b>	Remote port
<b>&lt;n&gt;</b>	0-7 A numeric parameter which indicates the connection number														
<b>&lt;mode&gt;</b>	<table> <tr> <td>0</td><td>UDP Normal Mode</td></tr> <tr> <td>1</td><td>UDP Extended Mode</td></tr> <tr> <td>2</td><td>Set UDP address to be sent</td></tr> </table>	0	UDP Normal Mode	1	UDP Extended Mode	2	Set UDP address to be sent								
0	UDP Normal Mode														
1	UDP Extended Mode														
2	Set UDP address to be sent														
<b>&lt;IP address&gt;</b>	A string parameter which indicates remote IP address														
<b>&lt;port&gt;</b>	Remote port														
Parameter Saving Mode	NO_SAVE														
Max Response Time	-														
Reference	Note														

### 8.2.27 AT+CIPRXGET Get Data from Network Manually

<b>AT+CIPRXGET</b>	<b>Get Data from Network Manually</b>
Test Command <b>AT+CIPRXGET=?</b>	Response If single IP connection (+CIPMUX=0) <b>+CIPRXGET: (list of supported &lt;mode&gt;s),(list of supported &lt;reqlength&gt;)</b>  <b>OK</b> If multi IP connection (+CIPMUX=1) <b>+CIPRXGET: (list of supported &lt;mode&gt;s), (list of supported &lt;id&gt;s), (list of supported &lt;reqlength&gt;)</b>  <b>OK</b>
	Parameters

	See Write Command
Read Command <b>AT+CIPRXGET</b> <b>?</b>	Response <b>+CIPRXGET: &lt;mode&gt;</b>  <b>OK</b>
	Parameters See Write Command
Write Command 1) If single IP connection (+CIPMUX=0)  <b>AT+CIPRXGET=&lt;mode&gt;[,&lt;reqlength&gt;]</b>  2) If multi IP connection (+CIPMUX=1)  <b>AT+CIPRXGET=&lt;mode&gt;[,&lt;id&gt;,&lt;reqlength&gt;]</b>	Response <b>OK</b> <b>ERROR</b> 1)For single IP connection If "AT+CIPSRIP=1" is set, IP address and port are contained. if <mode>=1 <b>+CIPRXGET: 1[,&lt;IP ADDRESS&gt;:&lt;PORT&gt;]</b> if <mode>=2 <b>+CIPRXGET: 2,&lt;reqlength&gt;,&lt;cnflength&gt;[,&lt;IP ADDRESS&gt;:&lt;PORT&gt;]</b> <b>1234567890...</b> <b>OK</b> if <mode>=3 <b>+CIPRXGET: 3,&lt;reqlength&gt;,&lt;cnflength&gt;[,&lt;IP ADDRESS&gt;:&lt;PORT&gt;]</b> <b>5151...</b> <b>OK</b> if <mode>=4 <b>+CIPRXGET: 4,&lt;cnflength&gt;</b>  <b>OK</b> 2)For multi IP connection If "AT+CIPSRIP=1" is set, IP address and port is contained. if <mode>=1 <b>+CIPRXGET: 1[,&lt;id&gt;,&lt;IP ADDRESS&gt;:&lt;PORT&gt;]</b> if <mode>=2 <b>+CIPRXGET: 2,&lt;id&gt;,&lt;reqlength&gt;,&lt;cnflength&gt;[,&lt;IP ADDRESS&gt;:&lt;PORT&gt;]</b> <b>1234567890...</b> <b>OK</b> if <mode>=3 <b>+CIPRXGET: 3,&lt;id&gt;,&lt;reqlength&gt;,&lt;cnflength&gt;[,&lt;IP ADDRESS&gt;:&lt;PORT&gt;]</b> <b>5151...</b> <b>OK</b> if <mode>=4 <b>+CIPRXGET: 4,&lt;id&gt;,&lt;cnflength&gt;</b>  <b>OK</b>

	<p>If error is related to ME functionality:  <b>+CME ERROR: &lt;err&gt;</b></p>
	<p>Parameters</p> <p><b>&lt;mode&gt;</b></p> <p>0 Disable getting data from network manually, the module is set to normal mode, data will be pushed to TE directly.</p> <p>1 Enable getting data from network manually.</p> <p>2 The module can get data, but the length of output data can not exceed 1460 bytes at a time.</p> <p>3 Similar to mode 2, but in HEX mode, which means the module can get 730 bytes maximum at a time.</p> <p>4 Query how many data are not read with a given ID.</p> <p><b>&lt;id&gt;</b> A numeric parameter which indicates the connection number</p> <p><b>&lt;reqlength&gt;</b> Requested number of data bytes (1-1460 bytes) to be read.  If &lt;mode&gt;=4, the range of &lt;reqlength&gt; is 0-2920bytes.</p> <p><b>&lt;cnflength&gt;</b> Confirmed number of data bytes to be read, which may be less than &lt;length&gt;. 0 indicates that no data can be read.</p>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	<p>Note</p> <p>To enable this function, parameter &lt;mode&gt; must be set to 1 before connection.</p>

### 8.2.28 AT+CIPRDTIMER Set Remote Delay Timer

AT+CIPRDTIMER Set Remote Delay Timer	
Test Command <b>AT+CIPRDTIMER=?</b>	Response <b>+CIPRDTIMER: (100-4000),(100-7000)</b>  <b>OK</b>
	Parameters See Write Command
Read Command <b>AT+CIPRDTIMER?</b>	Response <b>+CIPRDTIMER: &lt;rdsigtimer&gt;,&lt;rdmuxtimer&gt;</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+CIPRDTIM</b>	Response <b>OK</b>

<b>ER=&lt;rdsigtimer&gt;,&lt;rdmuxtimer&gt;</b>	If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <b>&lt;rdsigtimer&gt;</b> Remote delay timer of single connection. Default value is 2000. <b>&lt;rdmuxtimer&gt;</b> Remote delay timer of multi-connections. Default value is 3500.
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note This command is used to shorten the disconnect time locally when the remote server has been disconnected.

### 8.2.29 AT+CIPSGTXT Select GPRS PDP context

<b>AT+CIPSGTXT</b>	<b>Select GPRS PDP context</b>
Test Command <b>AT+CIPSGTXT=?</b>	Response <b>+CIPSGTXT: (0,1)</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+CIPSGTXT=&lt;mode&gt;</b>	Response <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <b>&lt;mode&gt;</b> 0    Select first PDP context 1    Select second PDP context
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note This command is used to select pdp context, only for multi IP connection (+CIPMUX=1).

### 8.2.30 AT+CIPSENDHEX Set CIPSEND Data Format to Hex

<b>AT+CIPSENDHEX</b>	<b>Set CIPSEND Data Format to HEX</b>
Test Command	Response

<b>AT+CIPSENDH EX=?</b>	<b>+ CIPSENDHEX: (0,1)</b>
	<b>OK</b>
	Parameters See Write Command
Write Command <b>AT+CIPSENDH EX=&lt;mode&gt;</b>	Response <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <b>&lt;mode&gt;</b> <u>0</u> The default format of output data in AT+CIPSEND. 1    Set the input data in HEX format when using CIPSEND command to send data.
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 8.2.31 AT+CIPHEXS Set Output-data Format with suffix

<b>AT+CIPHEXS Set Output-data Format with suffix</b>	
Test Command <b>AT+CIPHEXS=?</b>	Response <b>+CIPHEXS: (list of supported &lt;mode&gt;s)</b>
	<b>OK</b>
	Parameters See Write Command
Write Command <b>AT+CIPHEXS= &lt;mode&gt;</b>	Response <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <b>&lt;mode&gt;</b> <u>0</u> The default format of output data 1    Set the output data with suffix "0d 0a" 2    Set the output data in HEX format with suffix "0d 0a".
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note:

This command is only available when "AT+CIPHEAD=1".

### 8.2.32 AT+CIPTKA Set TCP Keepalive Parameters

AT+CIPTKA Set TCP Keepalive Parameters									
Test Command <b>AT+CIPTKA=?</b>	<p>Response</p> <p><b>+CIPTKA:</b> (list of supported <b>&lt;mode&gt;s</b>),(list of supported <b>&lt;keepIdle&gt;s</b>),(list of supported <b>&lt;keepInterval&gt;</b>),(list of supported <b>&lt;keepCount&gt;s</b>)</p> <p><b>OK</b></p> <p>Parameters See Write Command</p>								
Read Command <b>AT+CIPTKA?</b>	<p>Response</p> <p><b>+CIPTKA:</b> <b>&lt;mode&gt;</b>,<b>&lt;keepIdle&gt;</b>,<b>&lt;keepInterval&gt;</b>,<b>&lt;keepCount&gt;</b></p> <p><b>OK</b></p> <p>Parameters See Write Command</p>								
Write Command <b>AT+CIPTKA=&lt;mode&gt;[,&lt;keepIdle&gt;[,&lt;keepInterval&gt;[,&lt;keepCount&gt;]]]</b>	<p>Response</p> <p><b>OK</b></p> <p>If error is related to ME functionality: <b>ERROR</b></p> <p>Parameters</p> <table> <tr> <td><b>&lt;mode&gt;</b></td><td>Set TCP keepalive option. 0 Disable TCP keep alive mechanism 1 Enable TCP keep alive mechanism</td></tr> <tr> <td><b>&lt;keepIdle&gt;</b></td><td>Integer type; Idle time (in second) before TCP send the initial keepalive probe. 30-7200 Default: 7200</td></tr> <tr> <td><b>&lt;keepInterval&gt;</b></td><td>Interval time (in second) between keepalive probes retransmission. 30-600 Default: 75</td></tr> <tr> <td><b>&lt;keepCount&gt;</b></td><td>Integer type; Maximum number of keepalive probes to be sent. 1-9 Default: 9</td></tr> </table>	<b>&lt;mode&gt;</b>	Set TCP keepalive option. 0 Disable TCP keep alive mechanism 1 Enable TCP keep alive mechanism	<b>&lt;keepIdle&gt;</b>	Integer type; Idle time (in second) before TCP send the initial keepalive probe. 30-7200 Default: 7200	<b>&lt;keepInterval&gt;</b>	Interval time (in second) between keepalive probes retransmission. 30-600 Default: 75	<b>&lt;keepCount&gt;</b>	Integer type; Maximum number of keepalive probes to be sent. 1-9 Default: 9
<b>&lt;mode&gt;</b>	Set TCP keepalive option. 0 Disable TCP keep alive mechanism 1 Enable TCP keep alive mechanism								
<b>&lt;keepIdle&gt;</b>	Integer type; Idle time (in second) before TCP send the initial keepalive probe. 30-7200 Default: 7200								
<b>&lt;keepInterval&gt;</b>	Interval time (in second) between keepalive probes retransmission. 30-600 Default: 75								
<b>&lt;keepCount&gt;</b>	Integer type; Maximum number of keepalive probes to be sent. 1-9 Default: 9								
Parameter Saving Mode	NO_SAVE								
Max Response Time	-								
Reference	Note								



### 8.2.33 AT+CIPOPTION Enable or Disable TCP nagle algorithm

AT+CIPOPTION Enable or Disable TCP nagle algorithm	
Test Command <b>AT+CIPOPTION N=?</b>	<p>Response</p> <p><b>+CIPOPTION:</b> (list of supported &lt;mode&gt;s)</p> <p><b>OK</b></p> <p>Parameters</p> <p>See Write Command</p>
Read Command <b>AT+CIPOPTION N?</b>	<p>Response</p> <p><b>+CIPOPTION:</b> &lt;mode&gt;</p> <p><b>OK</b></p> <p>Parameters</p> <p>See Write Command</p>
Write Command <b>AT+CIPOPTION N=&lt;mode&gt;</b>	<p>Response</p> <p><b>OK</b></p> <p>If error is related to ME functionality:</p> <p><b>ERROR</b></p> <p>Parameters</p> <p><b>&lt;mode&gt;</b>            Config to enable or disable TCP nagle algorithm</p> <p>                  0    Enable TCP nagle algorithm</p> <p>                  <u>1</u>   Disable TCP nagle algorithm</p>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

## 9 AT Commands for HTTP Application

Heracles224G has an embedded TCP/IP stack that is driven by AT commands and enables the host application to easily access the Internet HTTP service. This chapter is a reference guide to all the AT commands and responses defined to use with the TCP/IP stack in HTTP Service.

### 9.1 Overview

Command	Description
AT+HTTPINIT	Initialize HTTP service
AT+HTTPTERM	Terminate HTTP service
AT+HTTPPARA	Set HTTP parameters value
AT+HTTPDATA	Input HTTP data
AT+HTTPACTION	HTTP method action
AT+HTTPREAD	Read the HTTP server response
AT+HTTPSTATUS	Read HTTP status
AT+HTTPHEAD	Read the HTTP header information of server response
AT+HTTPTOFS	Download file to ap file system

### 9.2 Detailed Descriptions of Commands

#### 9.2.1 AT+HTTPINIT Initialize HTTP Service

AT+HTTPINIT	Initialize HTTP Service
Test Command AT+HTTPINIT=?	Response <b>OK</b>
Execution Command AT+HTTPINIT	Response <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note HTTPINIT should first be executed to initialize the HTTP service.

## 9.2.2 AT+HTTPTERM Terminate HTTP Service

AT+HTTPTERM Terminate HTTP Service	
Test Command <b>AT+HTTPTERM=?</b>	Response <b>OK</b>
Execution command <b>AT+HTTPTERM</b>	Response <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

## 9.2.3 AT+HTTPPARA Set HTTP Parameters Value

AT+HTTPPARA Set HTTP Parameters Value	
Test Command <b>AT+HTTPPARA=?</b>	Response <b>+HTTPPARA: "HTTPParamTag","HTTPParamValue"</b>  <b>OK</b>
	Parameters See Write Command
Read Command <b>AT+HTTPPARA?</b>	Response <b>+HTTPPARA:</b> <b>&lt;HTTPParamTag&gt;,&lt;HTTPParamValue&gt;</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+HTTPPARA=&lt;HTTPParamTag&gt;,&lt;HTTPParamValue&gt;</b>	Response <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <b>&lt;HTTPParamTag&gt;</b> "CID" HTTP Parameter "URL" (Mandatory Parameter) Bearer profile identifier

	<p>(Mandatory Parameter) HTTP client URL  <code>"http://server'/path':tcpPort' "</code>  <code>"server"</code>: FQDN or IP-address  <code>"path"</code>: path of file or directory  <code>"UA"</code> <code>"tcpPort"</code>: default value is 80.  Refer to "IETF-RFC 2616".  The user agent string which is set by the application to identify the mobile. Usually this parameter is set as operation system and software version information.  <code>"PROIP"</code> Default value is "SIMCom_MODULE".  <code>"PROPORT"</code> The IP address of HTTP proxy server  The port of HTTP proxy server  This flag controls the redirection mechanism of the SIM800 when it is acting as HTTP client (numeric). If the server sends a redirect code (range 30x), the client will automatically send a new HTTP request when the flag is set to (1).  Default value is 0 (no redirection).  <code>"BREAK"</code> Parameter for HTTP method "GET", used for resuming broken transfer.  Parameter for HTTP method "GET", used for resuming broken transfer. which is used together with "BREAK",  If the value of "BREAKEND" is bigger than "BREAK", the transfer scope is from "BREAK" to "BREAKEND".  If the value of "BREAKEND" is smaller than "BREAK", the transfer scope is from "BREAK" to the end of the file.  If both "BREAKEND" and "BREAK" are 0, the resume broken transfer function is disabled.  HTTP session timeout value, scope: 30-1000 second.  Default value is 120 seconds.  <code>"CONTENT"</code> HTTP Parameter value. Type and supported content depend on related &lt;HTTPParamTag&gt;.  <code>"USERDATA"</code> Used to set the "Content-Type" field in HTTP header.  &lt;HTTPParamValue&gt; User data  HTTP Parameter value.Type and supported content depend on related &lt;HTTPParamTag&gt;.</p>
Parameter Saving Mode	NO_SAVE

Max Response Time	-
Reference	Note Not all the HTTP Server supports "BREAK" and "BREAKEND" parameters

#### 9.2.4 AT+HTTPDATA Input HTTP Data

AT+HTTPDATA Input HTTP Data	
Test Command <b>AT+HTTPDATA=?</b>	Response <b>+HTTPDATA:</b> (list of supported <size>s),(list of supported <time>s)  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+HTTPDATA=&lt;size&gt;,&lt;time&gt;</b>	Response <b>DOWNLOAD</b>  <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <b>&lt;size&gt;</b> Size in bytes of the data to POST. 1-319488 (bytes) 0 means delete all the content. <b>&lt;time&gt;</b> 1000-120000 (millisecond) Maximum time in milliseconds to input data.
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note It is strongly recommended to set enough time to input all data with the length of <size>.

#### 9.2.5 AT+HTTPACTION HTTP Method Action

AT+HTTPACTION HTTP Method Action	
Test Command <b>AT+HTTPACTION=?</b>	Response <b>+HTTPACTION: (0-3)</b>  <b>OK</b>

	<p>Parameters</p> <p>See Write Command</p>
<p>Write Command</p> <p><b>AT+HTTPACTION=&lt;Method&gt;</b></p>	<p>Response</p> <p><b>OK</b></p> <p>If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p> <p>Unsolicited Result Code <b>+HTTPACTION: &lt;Method&gt;,&lt;StatusCode&gt;,&lt;DataLen&gt;</b></p> <p>Parameters</p> <p><b>&lt;Method&gt;</b> HTTP method specification:</p> <ul style="list-style-type: none"> <li>0 GET</li> <li>1 POST</li> <li>2 HEAD</li> <li>3 DELETE</li> </ul> <p><b>&lt;StatusCode&gt;</b> HTTP Status Code responded by remote server, it identifier refer to HTTP1.1(RFC2616)</p> <ul style="list-style-type: none"> <li>100 Continue</li> <li>101 Switching Protocols</li> <li>200 OK</li> <li>201 Created</li> <li>202 Accepted</li> <li>203 Non-Authoritative Information</li> <li>204 No Content</li> <li>205 Reset Content</li> <li>206 Partial Content</li> <li>300 Multiple Choices</li> <li>301 Moved Permanently</li> <li>302 Found</li> <li>303 See Other</li> <li>304 Not Modified</li> <li>305 Use Proxy</li> <li>307 Temporary Redirect</li> <li>400 Bad Request</li> <li>401 Unauthorized</li> <li>402 Payment Required</li> <li>403 Forbidden</li> <li>404 Not Found</li> <li>405 Method Not Allowed</li> <li>406 Not Acceptable</li> <li>407 Proxy Authentication Required</li> <li>408 Request Time-out</li> <li>409 Conflict</li> </ul>

	410 Gone 411 Length Required 412 Precondition Failed 413 Request Entity Too Large 414 Request-URI Too Large 415 Unsupported Media Type 416 Requested range not satisfiable 417 Expectation Failed 500 Internal Server Error 501 Not Implemented 502 Bad Gateway 503 Service Unavailable 504 Gateway Time-out 505 HTTP Version not supported 600 Not HTTP PDU 601 Network Error 602 No memory 603 DNS Error 604 Stack Busy <DataLen> The length of data got
Parameter Saving Mode	NO_SAVE
Max Response Time	About 5 seconds in test, dependence on network status and the size of request website
Reference	Note

### 9.2.6 AT+HTTPREAD Read the HTTP Server Response

AT+HTTPREAD Read the HTTP Server Response	
Test Command <b>AT+HTTPREAD=?</b>	Response <b>+HTTPREAD:</b> (list of supported <start_address>s),(list of supported <byte_size>s)  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+HTTPREAD=&lt;start_addresses&gt;,&lt;byte_size&gt;</b>	Response <b>+HTTPREAD:</b> <data_len> <data> <b>OK</b>  Read data when AT+HTTPACTION=0 or AT+HTTPDATA is executed.

	<p>If &lt;byte_size&gt; is bigger than the data size received, module will only return actual data size.</p> <p>If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters</p> <p><b>&lt;data&gt;</b> Data from HTTP server or user input.</p> <p><b>&lt;start_address&gt;</b> The starting point for data output. 0-319488 (bytes)</p> <p><b>&lt;byte_size&gt;</b> The length for data output. 1-319488 (bytes)</p> <p><b>&lt;data_len&gt;</b> The actual length for data output.</p>
Execution Command <b>AT+HTTPREAD</b>	Response <b>+HTTPREAD: &lt;data_len&gt;</b> <b>&lt;data&gt;</b> <b>OK</b> <p>Read all data when AT+HTTPACTION=0 or AT+HTTPDATA is executed.</p> <p>If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 9.2.7 AT+HTTPSTATUS Read HTTP Status

<b>AT+HTTPSTATUS Read HTTP Status</b>	
Test Command <b>AT+HTTPSTATUS=?</b>	Response <b>OK</b>
Read Command <b>AT+HTTPSTATUS?</b>	Response <b>+HTTPSTATUS: &lt;mode&gt;,&lt;status&gt;,&lt;finish&gt;,&lt;remain&gt;</b>  <b>OK</b> <p>If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p>



	<b>Parameters:</b> <b>&lt;mode&gt;</b> GET POST HEAD <b>&lt;status&gt;</b> 0 idle 1 receiving 2 sending <b>&lt;finish&gt;</b> The amount of data which have been transmitted <b>&lt;remain&gt;</b> The amount of data remaining to be sent or received
Parameter Saving Mode	NO_SAVE
Max Response Time	-

### 9.2.8 AT+HTTPHEAD Read the HTTP Header Information of Server Response

AT+HTTPHEAD Read the HTTP Header Information of Server Response	
Test Command <b>AT+HTTPHEAD=?</b>	Response <b>OK</b>
Execution Command <b>AT+HTTPHEAD</b>	Response <b>+HTTPHEAD: &lt;date_len&gt;</b> <b>&lt;data&gt;</b> <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <b>&lt;date_len&gt;</b> The actual length for http header data output <b>&lt;data&gt;</b> Data from HTTP server
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note Read header data when AT+HTTPACTION=0 executed.

### 9.2.9 AT+HTTPTOFS download file to ap file system

#### AT+HTTPTOFS Download file to ap file system

<p>Test Command</p> <p><b>AT+HTTPTOFS=?</b></p>	<p>Response</p> <p><b>+HTTPTOFS: (1-255),(1-127)</b></p> <p><b>OK</b></p>
<p>Read Command</p> <p><b>AT+HTTPTOFS?</b></p>	<p>Response</p> <p><b>+HTTPTOFS: &lt;status&gt;,&lt;url&gt;,&lt;file_path&gt;</b></p> <p><b>OK</b></p> <p>If error is related to ME functionality:</p> <p><b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters</p> <p>See Write Command</p>
<p>Write Command</p> <p><b>AT+HTTPTOFS=&lt;url&gt;,&lt;file_path&gt;</b></p>	<p>Response</p> <p><b>OK</b></p> <p><b>+HTTPTOFS: &lt;StatusCode&gt;,&lt;DataLen&gt;</b></p> <p>Parameters</p> <p><b>&lt;status&gt;</b></p> <p>0 Idle</p> <p>1 Busy</p> <p><b>&lt;url&gt;</b> The url</p> <p><b>&lt;file_path&gt;</b></p> <p>File path and name on ap side,</p> <p>For example: "/customer/test.bin", "/custapp/ test.bin", "/fota/test.bin"</p> <p><b>&lt;StatusCode&gt;</b> HTTP Status Code responded by remote server, it identifier refer to HTTP1.1(RFC2616)</p> <p>100 Continue</p> <p>200 OK</p> <p>206 Partial Content</p> <p>400 Bad Request</p> <p>404 Not Found</p> <p>408 Request Time-out</p> <p>500 Internal Server Error</p> <p>600 Not HTTP PDU</p> <p>601 Network Error</p> <p>602 No memory</p> <p>603 DNS Error</p> <p>604 Stack Busy</p> <p>620 SSL continue</p> <p>65535 Other Errors</p> <p><b>&lt;DataLen&gt;</b></p> <p>The length of data download</p>

Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

## 10 AT Commands for PING Application

Heracles224G modules provide PING AT command is as follows:

### 10.1 Overview

Command	Description
AT+CIPPING	PING Request
AT+CIPCTL	Set the Mode When Receiving an IP Packet
AT+CIPFLT	Set the Rules of IP Filter

### 10.2 Detailed Descriptions of Commands

#### 10.2.1 AT+CIPPING PING Request

AT+CIPPING PING Request	
Test Command <b>AT+CIPPING=?</b>	<p>Response</p> <p><b>+CIPPING:</b> (list of supported &lt;retryNum&gt;s),(list of supported &lt;dataLen&gt;s),(list of supported &lt;timeout&gt;s),(list of supported &lt;ttl&gt;s)</p> <p><b>OK</b></p> <p>Parameters See Write Command</p>
Read Command <b>AT+CIPPING?</b>	<p>Response</p> <p><b>+CIPPING:</b> &lt;retryNum&gt;,&lt;dataLen&gt;,&lt;timeout&gt;,&lt;ttl&gt;</p> <p><b>OK</b></p> <p>Parameters See Write Command</p>
Write Command <b>AT+CIPPING=&lt;IPAddr&gt;[,&lt;retryNum&gt;[,&lt;dataLen&gt;[,&lt;timeout&gt;,&lt;ttl&gt;]]]</b>	<p>Response</p> <p><b>+CIPPING:</b> &lt;replyId&gt;,&lt;IP Address&gt;,&lt;replyTime&gt;,&lt;ttl&gt;[&lt;CR&gt;&lt;LF&gt;]</p> <p><b>+CIPPING:</b> &lt;replyId&gt;,&lt;IP Address&gt;,&lt;replyTime&gt;,&lt;ttl&gt;[...]</p> <p><b>OK</b></p> <p>or</p> <p><b>ERROR</b></p> <p>or</p> <p><b>+CME ERROR:</b> &lt;err&gt;</p>

	Parameters
	<p><b>&lt;IPAddr&gt;</b> Address of the remote host, string type. This parameter can be either:</p> <ul style="list-style-type: none"> <li>- IP address in the format: "xxx.xxx.xxx.xxx"</li> <li>- Host name solved by a DNS query</li> </ul>
	<p><b>&lt;retryNum&gt;</b> The number of Ping Echo Request to send</p> <p>1-100 Default: 4</p>
	<p><b>&lt;dataLen&gt;</b> The length of Ping Echo Request data</p> <p>0-1024 Default: 8</p>
	<p><b>&lt;timeout&gt;</b> The timeout, in units of 100 ms, waiting for a single Echo Reply</p> <p>1-600 Default: 100(10 seconds)</p>
	<p><b>&lt;ttl&gt;</b> Time to live</p> <p>1-255 Default: 64</p>
	<p><b>&lt;replyId&gt;</b> Echo Reply number</p>
	<p><b>&lt;IP Address&gt;</b> IP Address of the remote host</p>
	<p><b>&lt;replyTime&gt;</b> Time, in ms, required to receive the response</p>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	<p>Note</p> <ul style="list-style-type: none"> <li>● Before sending PING Request the GPRS context must be activated.</li> <li>● When the Echo Request timeout expires (no reply received on time), the response will contains <b>&lt;replyTime&gt;</b> setting to 600 and <b>&lt;ttl&gt;</b> setting to 255.</li> <li>● When executing this command, if PDP context is deactivated for some reasons, such as out of service, etc.the "+PDP: DEACT" URC is reported and the command will end immediately.</li> <li>● If executing the command in NB-IOT network,please config <b>&lt;timeout&gt;</b> to 300(30 second).For example: <b>AT+CIPPING="www.google.cn",4,8,300,64</b></li> </ul>

### 10.2.2 AT+CIPCTL Set the Mode When Receiving an IP Packet

#### AT+CIPCTL Set the Mode When Receiving an IP Packet

Test Command	Response
AT+CIPCTL=?	+CIPCTL: (list of supported <mode>s)
	OK
	Parameters
	See Write Command

Read Command <b>AT+CIPCTL?</b>	Response <b>+CIPCTL: &lt;mode&gt;</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+CIPCTL=&lt;mode&gt;</b>	Response <b>OK</b> or <b>ERROR</b> or <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <b>&lt;mode&gt;</b> 0    Disable to send Echo Reply <u>1</u> Enable to send Echo Reply to every IP address pinging it 2    Enable to send Echo Reply only to a subset of IP Addresses pinged by it. This subset of IP Addresses can be set by "AT+CIPFLT" command.
Parameter      Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note The value of <b>&lt;mode&gt;</b> is stored in non volatile memory.

### 10.2.3 AT+CIPFLT Set the Rules of IP Filter

AT+CIPFLT Set the Rules of IP Filter	
Test Command <b>AT+CIPFLT=?</b>	Response <b>+CIPFLT:</b> (list of supported <action>s),(list of supported <item>s)  <b>OK</b>
	Parameter See Write Command
Read Command <b>AT+CIPFLT?</b>	Response <b>+CIPFLT:</b> <item>,<ipAddr>,<mask> [<CR><LF>+CIPFLT: <item>,<ipAddr>,<mask> [...]]  <b>OK</b>
	Parameter See Write Command

<div>Write Command</div> <div>AT+CIPFLT=&lt;action&gt;[,&lt;item&gt;][,&lt;ipAddr&gt;,&lt;mask&gt;]</div>	<div>Response</div> <div>OK</div> <div>or</div> <div>ERROR</div> <div>or</div> <div>+CME ERROR: &lt;err&gt;</div>
	<div>Parameter</div> <div><div>&lt;action&gt;</div><div>0</div><div>Remove the rule specified by &lt;item&gt;. &lt;item&gt; must be given.</div></div> <div><div></div><div>1</div><div>Add the rule specified by &lt;item&gt;. If &lt;item&gt; is not given, it can find an empty item automatically. &lt;ipAddr&gt; and &lt;mask&gt; must be given.</div></div> <div><div></div><div>2</div><div>Delete all of rules</div></div> <div><div>&lt;item&gt;</div><div></div><div>The item of IP filter rule</div></div> <div><div></div><div>1-20</div><div></div></div> <div><div>&lt;ipAddr&gt;</div><div></div><div>Remote IP address,string type. It can be any valid IP address in the format of "xxx.xxx.xxx.xxx"</div></div> <div><div>&lt;mask&gt;</div><div></div><div>Mask to be applied to the &lt;ipAddr&gt;,string type. It can be any valid IP address mask in the format of "xxx.xxx.xxx.xxx"</div></div>
<div>Parameter</div> <div>Saving Mode</div>	<div>NO_SAVE</div>
<div>Max Response Time</div>	<div>-</div>
<div>Reference</div>	<div>Note</div> <div><div><div></div><div>When a packet comes from the IP address <b>coming_IP</b>, All rules will be scanned to match the following criteria:<div>&lt;coming_IP&gt; &amp; &lt;mask&gt; = &lt;ipAddr&gt; &amp; &lt;mask&gt;</div>If the criterion is matched, the IP packet will be accepted and the rule scan is finished. If the criterion is not matched, the IP packet will be ignored.</div></div><div><div></div><div>The rule is stored in non volatile memory.</div></div></div>

## 11 AT Commands for FTP Application

Heracles224G has an embedded TCP/IP stack that is driven by AT commands and enables the host application to easily access the Internet FTP service. This chapter is a reference guide to all the AT commands and responses defined for using with the TCP/IP stack in FTP Service.

### 11.1 Overview

Command	Description
AT+FTPPORT	Set FTP control port
AT+FTPMODE	Set active or passive FTP mode
AT+FTPSTYPE	Set the type of data to be transferred
AT+FTPPUTOPT	Set FTP put type
AT+FTPCID	Set FTP bearer profile identifier
AT+FTPREST	Set resume broken download
AT+FTPSERV	Set FTP server address
AT+FTPUN	Set FTP user name
AT+FTPPW	Set FTP password
AT+FTPGETNAME	Set download file name
AT+FTPGETPATH	Set download file path
AT+FTPPUTNAME	Set upload file name
AT+FTPPUTPATH	Set upload file path
AT+FTPGET	Download file
AT+FTPPUT	Set upload file
AT+FTPDELE	Delete specified file in FTP server
AT+FTPSIZE	Get the size of specified file in FTP server
AT+FTPSTATE	Get the FTP state
AT+FTPEXTPUT	Extend upload file
AT+FTPMKD	Make directory on the remote machine
AT+FTPRMD	Remove directory on the remote machine
AT+FTPLIST	List contents of directory on the remote machine
AT+FTPEXTGET	Extend download file
AT+FTPETPUT	Upload File
AT+FTPETGET	Download File
AT+FTPQUIT	Quit current FTP session
AT+FTPRENAME	Rename the Specified File on the Remote Machine
AT+FTPMDTM	Get the Last Modification Timestamp of Specified File on the Remote Machine



## 11.2 Detailed Descriptions of Commands

### 11.2.1 AT+FTPPORT Set FTP Control Port

<b>AT+FTPPORT Set FTP Control Port</b>	
Test Command <b>AT+FTPPORT=?</b>	Response <b>OK</b>
Read Command <b>AT+FTPPORT?</b>	Response <b>+FTPPORT: &lt;value&gt;</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+FTPPORT=&lt;value&gt;</b>	Response <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <b>&lt;value&gt;</b> The value of FTP Control port, from 1 to 65535. Default value is 21
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note Numbers above 65535 are illegal as the port identification fields are 16 bits long in the TCP header.

### 11.2.2 AT+FTPMODE Set Active or Passive FTP Mode

<b>AT+FTPMODE Set Active or Passive FTP Mode</b>	
Test Command <b>AT+FTPMODE=?</b>	Response <b>OK</b>
Read Command <b>AT+FTPMODE?</b>	Response <b>+FTPMODE: &lt;value&gt;</b>  <b>OK</b>
	Parameters See Write Command
Write Command	Response

<b>AT+FTPMODE</b> <b>=&lt;value&gt;</b>	<b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <b>&lt;value&gt;</b> 0    Active FTP mode 1    Passive FTP mode
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 11.2.3 AT+FTPTYPE Set the Type of Data to Be Transferred

<b>AT+FTPTYPE Set the Type of Data to Be Transferred</b>	
Test Command <b>AT+FTPTYPE=?</b>	Response <b>OK</b>
Read Command <b>AT+FTPTYPE?</b>	Response <b>+FTPTYPE: &lt;value&gt;</b>
	<b>OK</b> Parameters See Write Command
Write Command <b>AT+FTPTYPE=&lt;value&gt;</b>	Response <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <b>&lt;value&gt;</b> "A "    For FTP ASCII sessions "I "    For FTP Binary sessions
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note When this value is set to A, all the data sent by the stack to the FTP server is made of 7 bits characters (NVT-ASCII: the MSB is set to 0). As a consequence binary data containing 8 bits characters will be corrupted during the transfer if the FTPTYPE is set to A.

## 11.2.4 AT+FTPPUTOPT Set FTP Put Type

AT+FTPPUTOPT Set FTP Put Type	
Test Command <b>AT+FTPPUTOPT T=?</b>	Response <b>OK</b>
Read Command <b>AT+FTPPUTOPT T?</b>	Response <b>+FTPPUTOPT: &lt;value&gt;</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+FTPPUTOPT T=&lt;value&gt;</b>	Response <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <b>&lt;value&gt;</b> "APPE" For appending file "STOU" For storing unique file " <u>STOR</u> " For storing file
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

## 11.2.5 AT+FTPCID Set FTP Bearer Profile Identifier

AT+FTPCID Set FTP Bearer Profile Identifier	
Test Command <b>AT+FTPCID=?</b>	Response <b>OK</b>
	Parameters See Write Command
Read Command <b>AT+FTPCID?</b>	Response <b>+FTPCID: &lt;value&gt;</b>  <b>OK</b>
	Parameter See Write Command

Write Command <b>AT+FTPCID=&lt;value&gt;</b>	<p>Response</p> <p><b>OK</b></p> <p>If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p>
	<p>Parameters</p> <p><b>&lt;value&gt;</b>      Bearer profile identifier refer to AT+SAPBR</p>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 11.2.6 AT+FTPREST Set Resume Broken Download

<b>AT+FTPREST Set Resume Broken Download</b>	
Test Command <b>AT+FTPREST=?</b>	<p>Response</p> <p><b>OK</b></p>
Read Command <b>AT+FTPREST?</b>	<p>Response</p> <p><b>+FTPREST: &lt;value&gt;</b></p> <p><b>OK</b></p> <p>Parameters</p> <p>See Write Command</p>
Write Command <b>AT+FTPREST=&lt;value&gt;</b>	<p>Response</p> <p><b>OK</b></p> <p>If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters</p> <p><b>&lt;value&gt;</b>      Broken point to be resumed</p>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 11.2.7 AT+FTPSERV Set FTP Server Address

<b>AT+FTPSERV Set FTP Server Address</b>
--

Test Command <b>AT+FTPSERV=?</b>	Response <b>OK</b>
Read Command <b>AT+FTPSERV?</b>	Response <b>+FTPSERV: &lt;value&gt;</b>  <b>OK</b>  Parameters See Write Command
Write Command <b>AT+FTPSERV=&lt;value&gt;</b>	Response <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>  Parameters <b>&lt;value&gt;</b> 32-bit number in dotted-decimal notation (i.e. xxx.xxx.xxx.xxx) or alphanumeric ASCII text string up to 49 characters if DNS is available
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 11.2.8 AT+FTPUN Set FTP User Name

<b>AT+FTPUN Set FTP User Name</b>	
Test Command <b>AT+FTPUN=?</b>	Response <b>OK</b>  Parameters See Write Command
Read Command <b>AT+FTPUN?</b>	Response <b>+FTPUN: &lt;value&gt;</b>  <b>OK</b>  Parameters See Write Command
Write Command <b>AT+FTPUN=&lt;value&gt;</b>	Response <b>OK</b>

	<p>If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p>
	<p>Parameters <b>&lt;value&gt;</b>      Alphanumeric ASCII text string up to 49 characters.</p>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 11.2.9 AT+FTPPW Set FTP Password

AT+FTPPW Set FTP Password	
Test Command <b>AT+FTPPW=?</b>	<p>Response <b>OK</b></p>
	<p>Parameters See Write Command</p>
Read Command <b>AT+FTPPW?</b>	<p>Response <b>+FTPPW: &lt;value&gt;</b></p> <p><b>OK</b></p>
	<p>Parameters See Write Command</p>
Write Command <b>AT+FTPPW=&lt;value&gt;</b>	<p>Response <b>OK</b></p> <p>If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p>
	<p>Parameters <b>&lt;value&gt;</b>      Alphanumeric ASCII text string up to 49 characters.</p>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 11.2.10 AT+FTPGETNAME Set Download File Name

AT+FTPGETNAME Set Download File Name	
Test Command <b>AT+FTPGETNAME=?</b>	Response <b>OK</b>
Read Command <b>AT+FTPGETNAME?</b>	Response <b>+FTPGETNAME: &lt;value&gt;</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+FTPGETNAME=&lt;value&gt;</b>	Response <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <b>&lt;value&gt;</b> Alphanumeric ASCII text string up to 99 characters
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 11.2.11 AT+FTPGETPATH Set Download File Path

AT+FTPGETPATH Set Download File Path	
Test Command <b>AT+FTPGETPATH=?</b>	Response <b>OK</b>
Read Command <b>AT+FTPGETPATH?</b>	Response <b>+FTPGETPATH: &lt;value&gt;</b>  <b>OK</b>
	Parameters See Write Command

Write Command <b>AT+FTPGETPA TH=&lt;value&gt;</b>	Response <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <b>&lt;value&gt;</b> Alphanumeric ASCII text string up to 255 characters
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 11.2.12 AT+FTPPUTNAME Set Upload File Name

<b>AT+FTPPUTNAME Set Upload File Name</b>	
Test Command <b>AT+FTPPUTNAME=?</b>	Response <b>OK</b>
Read Command <b>AT+FTPPUTNAME?</b>	Response <b>+FTPPUTNAME: &lt;value&gt;</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+FTPPUTNAME=&lt;value&gt;</b>	Response <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <b>&lt;value&gt;</b> Alphanumeric ASCII text string up to 99 characters
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note



### 11.2.13 AT+FTPPUTPATH Set Upload File Path

AT+FTPPUTPATH Set Upload File Path	
Test Command <b>AT+FTPPUTPATH=?</b>	Response <b>OK</b>
Read Command <b>AT+FTPPUTPATH?</b>	Response <b>+FTPPUTPATH: &lt;value&gt;</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+FTPPUTPATH=&lt;value&gt;</b>	Response <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <b>&lt;value&gt;</b> Alphanumeric ASCII text string up to 255 characters
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 11.2.14 AT+FTPGET Download File

AT+FTPGET Download File	
Test Command <b>AT+FTPGET=?</b>	Response <b>OK</b>
Write Command <b>AT+FTPGET=&lt;mode&gt;[,&lt;reqlength&gt;]</b>	Response If mode is 1 and it is a successful FTP get session: <b>OK</b>  <b>+FTPGET: 1,1</b>
	If data transfer finished: <b>+FTPGET: 1,0</b>
	If mode is 1 and it is a failed FTP get session:

	<p><b>OK</b></p> <p><b>+FTPGET: 1,&lt;error&gt;</b></p> <p>If mode is 2:</p> <p><b>+FTPGET: 2,&lt;cnflength&gt;</b></p> <p><b>012345678...</b></p> <p><b>OK</b></p> <p>If error is related to ME functionality:</p> <p><b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters</p> <p><b>&lt;mode&gt;</b>    1    For opening FTP get session                         2    For reading FTP download data.</p> <p><b>&lt;reqlength&gt;</b> Requested number of data bytes (1-1460) to be read</p> <p><b>&lt;cnflength&gt;</b> Confirmed number of data bytes to be read, which may be less than <b>&lt;length&gt;</b>. 0 indicates that no data can be read.</p> <p><b>&lt;error&gt;</b>    61    Net error                         62    DNS error                         63    Connect error                         64    Timeout                         65    Server error                         66    Operation not allow                         70    Replay error                         71    User error                         72    Password error                         73    Type error                         74    Rest error                         75    Passive error                         76    Active error                         77    Operate error                         78    Upload error                         79    Download error                         80    Manual quit</p>
Parameter Saving Mode	NO_SAVE
Max Response Time	75 seconds(In case no response is received from server)
Reference	<p>Note</p> <p>When "+FTPGET: 1,1" is shown, then use "AT+FTPGET=2,&lt;reqlength&gt;" to read data. If the module still has unread data, "+FTPGET: 1,1" will be shown again in a certain time.</p>

## 11.2.15 AT+FTPPUT Set Upload File

AT+FTPPUT Set Upload File	
Test Command <b>AT+FTPPUT=?</b>	Response <b>OK</b>
Write Command <b>AT+FTPPUT=&lt;mode&gt;[,&lt;reqlength&gt;]</b>	<p>Response</p> <p>If mode is 1 and it is a successful FTP get session: <b>OK</b></p> <p><b>+FTPPUT: 1,1,&lt;maxlength&gt;</b></p> <p>If mode is 1 and it is a failed FTP get session: <b>OK</b></p> <p><b>+FTPPUT: 1,&lt;error&gt;</b></p> <p>If mode is 2 and &lt;reqlength&gt; is not 0 <b>+FTPPUT: 2,&lt;cnflength&gt;</b> ..... //Input data <b>OK</b> <b>+FTPPUT: 1,1,1360</b></p> <p>If mode is 2 and &lt;reqlength&gt; is 0, it will respond OK, and FTP session will be closed <b>OK</b></p> <p>If data transfer finished. <b>+FTPPUT: 1,0</b></p> <p>If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters</p> <p><b>&lt;mode&gt;</b>      1    For opening FTP put session                  2    For writing FTP upload data.</p> <p><b>&lt;reqlength&gt;</b>   Requested number of data bytes(0-&lt;maxlength&gt;) to be transmitted</p> <p><b>&lt;cnflength&gt;</b>   Confirmed number of data bytes to be transmitted</p> <p><b>&lt;maxlength&gt;</b>   The max length of data can be sent at a time. It depends on the network status.</p> <p><b>&lt;error&gt;</b>        See "AT+FTPGET"</p>
Parameter Saving Mode	NO_SAVE
Max      Response	75 seconds(In case no response is received from server)

Time	
Reference	<p>Note</p> <p>When "+FTPPUT: 1,1,&lt;maxlength&gt;" is shown, then use "AT+FTPPUT=2, &lt;reqlength&gt;" to write data.</p>

### 11.2.16 AT+FTPDELE Delete Specified File in FTP Server

AT+FTPDELE Delete Specified File in FTP Server	
Test Command <b>AT+FTPDELE=?</b>	<p>Response</p> <p><b>OK</b></p> <p>Parameters</p> <p>See Execution Command</p>
Execution Command <b>AT+FTPDELE</b>	<p>Response</p> <p>If succeeded:</p> <p><b>OK</b></p> <p><b>+FTPDELE: 1,0</b></p> <p>If failed:</p> <p><b>OK</b></p> <p><b>+FTPDELE: 1,&lt;error&gt;</b></p> <p>If error is related to ME functionality:</p> <p><b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters</p> <p><b>&lt;error&gt;</b> See "AT+FTPGET"</p>
Parameter Saving Mode	NO_SAVE
Max Response Time	75 seconds(In case no response is received from server)
Reference	<p>Note</p> <p>The file to be deleted is specified by the "AT+FTPGETNAME" and "AT+FTPGETPATH" commands.</p>

### 11.2.17 AT+FTPSIZE Get the Size of Specified File in FTP Server

AT+FTPSIZE Get the Size of Specified File in FTP Server	
Test Command <b>AT+FTPSIZE=?</b>	<p>Response</p> <p><b>OK</b></p>

	Parameters See Execution Command
Execution Command <b>AT+FTPSIZE</b>	<p>Response</p> <p>If succeeded: <b>OK</b></p> <p><b>+FTPSIZE: 1,0,&lt;size&gt;</b></p> <p>If failed: <b>OK</b></p> <p><b>+FTPSIZE: 1,&lt;error&gt;,0</b></p> <p>If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters  <b>&lt;error&gt;</b>      See "AT+FTPGET"  <b>&lt;size&gt;</b>        The file size. Unit: byte</p>
Parameter    Saving Mode	NO_SAVE
Max          Response Time	75 seconds(In case no response is received from server)
Reference	<p>Note</p> <p>The file is specified by the "AT+FTPGETNAME" and "AT+FTPGETPATH" commands.</p>

### 11.2.18 AT+FTPSTATE Get the FTP State

<b>AT+FTPSTATE Get the FTP State</b>	
Test Command <b>AT+FTPSTATE=?</b>	<p>Response <b>OK</b></p> <p>Parameters See Execution Command</p>
Execution Command <b>AT+FTPSTATE</b>	<p>Response <b>+FTPSTATE: &lt;state&gt;</b></p> <p><b>OK</b></p> <p>If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p>

	Parameters <state> 0 Idle 1 In the FTP session, including FTPGET, FTPPUT, FTPDELE and FTPSIZE operation.
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 11.2.19 AT+FTPEXTPUT Extend Upload File

AT+FTPEXTPUT Extend Upload File	
Test Command <b>AT+FTPEXTPUT=?</b>	Response <b>OK</b>
Write Command <b>AT+FTPEXTPUT=&lt;mode&gt;[,&lt;pos&gt;,&lt;len&gt;,&lt;timeout&gt;]</b>	<p>Response</p> <p>If mode is 0 or 1 <b>OK</b></p> <p>If mode is 2 <b>+FTPEXTPUT: &lt;address&gt;,&lt;len&gt;</b> ..... //Input data <b>OK</b></p> <p>If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters</p> <p>&lt;mode&gt;    0 use default FTPPUT method           1 use extend FTPPUT method           2 send data to RAM through serial port, then FTPPUT method will get the data from RAM.</p> <p>&lt;pos&gt;    data offset address 0-300k</p> <p>&lt;len&gt;    data length 0-300k</p> <p>&lt;timeout&gt; timeout value of serial port. 1000ms-1000000ms</p> <p>&lt;file name&gt; File name length should less or equal 50 characters.</p> <p>&lt;err&gt;    See "AT+FTPGET"</p>
Parameter Saving Mode	NO_SAVE
Max Response Time	75 seconds(In case no response is received from server)

Reference	Note <ul style="list-style-type: none"> <li>When extend FTPPUT mode is activated, input data then execute "AT+FTPPUT=1" to transmit, after session is complete, if successful, it returns "+FTPPUT: 1,0", otherwise it returns "+FTPPUT: 1,&lt;error&gt;", &lt;error&gt; see "AT+FTPGET".</li> </ul>
-----------	--

### 11.2.20 AT+FTPMKD Make Directory on the Remote Machine

AT+FTPMKD Make Directory on the Remote Machine	
Test Command <b>AT+FTPMKD=?</b>	Response <b>OK</b>
Execution Command <b>AT+FTPMKD</b>	Response If success: <b>OK</b>  <b>+FTPMKD: 1,0</b>  If failed: <b>OK</b>  <b>+FTPMKD: 1,&lt;error&gt;</b>  If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <error> See "AT+FTPGET"
Parameter Saving Mode	NO_SAVE
Max Response Time	75 seconds(In case no response is received from server)
Reference	Note The created folder is specified by the "AT+FTPGETPATH" command.

### 11.2.21 AT+FTPRMD Remove Directory on the Remote Machine

AT+FTPRMD Remove Directory on the Remote Machine	
Test Command <b>AT+FTPRMD=?</b>	Response <b>OK</b>
Execution Command <b>AT+FTPRMD</b>	Response If success: <b>OK</b>

	<p><b>+FTPRMD: 1,0</b></p> <p>If failed: <b>OK</b></p> <p><b>+FTPRMD: 1,&lt;error&gt;</b></p> <p>If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters <b>&lt;error&gt;</b> See "AT+FTPGET"</p>
Parameter Saving Mode	NO_SAVE
Max Response Time	75 seconds(In case no response is received from server)
Reference	<p>Note</p> <p>The removed folder is specified by the "AT+FTPGETPATH" command.</p>

### 11.2.22 AT+FTPLIST List Contents of Directory on the Remote Machine

AT+FTPLIST List Contents of Directory on the Remote Machine	
Test Command <b>AT+FTPLIST=?</b>	Response <b>OK</b>
Write Command <b>AT+FTPLIST=&lt;mode&gt;[,&lt;reqlength&gt;]</b>	<p>Response</p> <p>If mode is 1 and it is a successful FTP get session: <b>OK</b></p> <p><b>+FTPLIST: 1,1</b></p> <p>If data transfer is finished: <b>+FTPLIST: 1,0</b></p> <p>If mode is 1 and it is a failed FTP get session: <b>OK</b></p> <p><b>+FTPLIST: 1,&lt;error&gt;</b></p> <p>If mode is 2: <b>+FTPLIST: 2,&lt;cnflength&gt;</b> <b>012345678...</b> <b>OK</b></p>



		<p>If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p>
		<p>Parameters</p> <p><b>&lt;mode&gt;</b></p> <p>1 For opening FTP get file list session 2 For reading FTP file list</p> <p><b>&lt;reqlength&gt;</b> Requested number of data bytes (1-1460) to be read</p> <p><b>&lt;cnflength&gt;</b> Confirmed number of data bytes to be read, which may be less than &lt;reqlength&gt;. 0 indicates that no data can be read.</p> <p><b>&lt;error&gt;</b> See "AT+FTPGET"</p>
Parameter	Saving Mode	NO_SAVE
Max Time	Response	75 seconds(In case no response is received from server)
Reference		<p>Note</p> <ul style="list-style-type: none"> <li>When "+FTPLIST: 1,1" is shown, "AT+FTPLIST=2,&lt;reqlength&gt;" can be used to read data. If the module still has unread data, "+FTPLIST: 1,1" will be shown again in a certain time.</li> <li>If using "AT+FTPGETPATH" to set a directory path, it will returned the files contents under this directory; if set a file path, it will return the information of the file specified.</li> </ul>

### 11.2.23 AT+FTPEXTGET Extend Download File

AT+FTPEXTGET Extend Download File	
<p>Test Command</p> <p><b>AT+FTPEXTGET=?</b></p>	<p>Response</p> <p><b>OK</b></p>
	<p>Parameters</p> <p>See Write Command</p>
<p>Read Command</p> <p><b>AT+FTPEXTGET?</b></p>	<p>Response</p> <p><b>+FTPEXTGET: &lt;mode&gt;,&lt;length&gt;</b></p> <p><b>OK</b></p>
	<p>Parameters</p> <p>See Write Command</p>
<p>Write Command</p> <p>1) if mode is 0 or 1</p> <p><b>AT+FTPEXTGET=&lt;mode&gt;</b></p> <p>3)if mode is 3</p> <p><b>AT+FTPEXTGET=&lt;mode&gt;,&lt;pos&gt;,&lt;len&gt;</b></p>	<p>Response</p> <p>If mode is 0:</p> <p><b>OK</b></p> <p>If mode is 1 and successfully download data:</p> <p><b>OK</b></p> <p><b>+FTPEXTGET: 1,0</b></p>

	<p>If mode is 1 and failed to download data: <b>OK</b></p> <p><b>+FTPEXTGET: 1,&lt;error&gt;</b></p> <p>If mode is 3 and successfully download data: <b>+FTPEXTGET: 3,&lt;length&gt;</b> <b>0123456...</b> <b>OK</b></p> <p>If &lt;file name&gt; is already exist in flash: <b>ERROR</b></p> <p>Parameters</p> <p><b>&lt;mode&gt;</b>     0    use default FTPGET method.                  1    open extend FTP get session and download data to RAM.                  3    read the downloaded data from RAM, then output it to the serial port.</p> <p><b>&lt;file name&gt;</b>   File name length should less than or equal to 50 characters.</p> <p><b>&lt;pos&gt;</b>        data offset should less than &lt;length&gt;.</p> <p><b>&lt;len&gt;</b>        data length 0-300k.</p> <p><b>&lt;length&gt;</b>    The length of the downloaded data from the remote machine.</p> <p><b>&lt;error&gt;</b>      See "AT+FTPGET"</p>
Parameter    Saving Mode	NO_SAVE
Max        Response Time	75 seconds(In case no response is received from server)
Reference	<p>Note</p> <ul style="list-style-type: none"> <li>●    The data it can get is 300k at most.</li> </ul>

#### 11.2.24 AT+FTPETPUT    Upload File

AT+FTPETPUT    Upload File	
Test Command <b>AT+FTPETPUT=?</b>	Response
	<b>OK</b>
	Parameters See Write Command
Write Command <b>AT+FTPETPUT=&lt;mode&gt;</b>	Response
	<p>If mode is 1 and successfully open PUT session: <b>OK</b></p> <p><b>+FTPETPUT: 1,1</b></p> <p>If mode is 1 and failed to open PUT session:</p>

	<p><b>OK</b></p> <p><b>+FTPETPUT: 1,&lt;error&gt;</b></p> <p>If mode is 2:  <b>+FTPETPUT: 2,1</b>  ... //Input data  <b>&lt;ETX&gt;</b> //To notify the module that all data has been sent, switch from data mode to command mode</p> <p><b>OK</b></p> <p>If data transfer finished:  <b>+FTPETPUT: 1,0</b></p> <p>If data transfer failed:  <b>+FTPETPUT: 1,&lt;error&gt;</b></p> <p>Parameters</p> <p><b>&lt;mode&gt;</b>    1    For opening FTPETPUT session.                   2    For writing FTP upload data.</p> <p><b>&lt;error&gt;</b>    See "AT+FTPEXTGET"</p>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	<p>Note</p> <ul style="list-style-type: none"> <li>The TCP/IP stack will only interpret an &lt;ETX&gt; character as the end of the file to be transferred if it's not preceded by a &lt;DLE&gt; character. As a consequence the attached host must send &lt;ETX&gt; characters preceded by &lt;DLE&gt; characters and it must also code &lt;DLE&gt; characters in &lt;DLE&gt;&lt;DLE&gt;.</li> </ul>

### 11.2.25 AT+FTPETGET Download File

AT+FTPETGET Download File	
Test Command <b>AT+FTPETGET=?</b>	<p>Response</p> <p><b>OK</b></p> <p>Parameters See Write Command</p>
Write Command <b>AT+FTPETGET=&lt;mode&gt;</b>	<p>Response</p> <p>If mode is 1 and successfully open GET session:  <b>OK</b></p> <p><b>+FTPETGET: 1,1</b></p>

	<p>If data transfer finished:</p> <p><b>0123456789...</b></p> <p><b>&lt;ETX&gt;</b>     <i>//To notify the user that all data transfer has been finished, switch from data mode to command mode.</i></p> <p><b>+FTPGET: 1,0</b></p> <p>If mode is 1 and failed to download data:</p> <p><b>OK</b></p> <p><b>+FTPGET: 1,&lt;error&gt;</b></p> <p>Parameters</p> <p><b>&lt;mode&gt;</b>     1    Open FTPGET session and download data.</p> <p><b>&lt;error&gt;</b>     See "AT+FTPEXTGET"</p>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	<p>Note</p> <ul style="list-style-type: none"> <li>Each &lt;ETX&gt; character present in the payload data of the FTP flow will be coded by the TCP/IP stack on the serial port as &lt;DLE&gt;&lt;ETX&gt;. Each &lt;DLE&gt; character will be coded as &lt;DLE&gt;&lt;DLE&gt;. The attached host must then decode the FTP flow to remove these escape characters.</li> </ul>

### 11.2.26 AT+FTPQUIT Quit Current FTP Session

AT+FTPQUIT Quit Current FTP Session	
Test Command <b>AT+FTPQUIT=?</b>	Response <b>OK</b>
Execution Command <b>AT+FTPQUIT</b>	<p>Response</p> <p>If the current operation is GET method:</p> <p><b>OK</b></p> <p><b>+FTPGET: 1,80</b></p> <p>If the current operation is PUT method:</p> <p><b>OK</b></p> <p><b>+FTPPUT: 1,80</b></p> <p>If FTP is in idle state:</p>

	<b>ERROR</b>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 11.2.27 AT+FTPNAME Rename the Specified File on the Remote Machine

<b>AT+FTPNAME Rename the Specified File on the Remote Machine</b>	
Test Command <b>AT+FTRENAME=?</b>	Response <b>OK</b>
	Parameters See Execution Command
Execution Command <b>AT+FTPNAME</b>	Response If success: <b>OK</b>  <b>+FTPNAME: 1,0</b>  If failed: <b>OK</b>  <b>+FTPNAME: 1,&lt;error&gt;</b>  If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameter <b>&lt;error&gt;</b> See "AT+FTPGET"
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note <ul style="list-style-type: none"> <li>● The file is specified by the "AT+FTPGETNAME" and "AT+FTPGETPATH" commands.</li> <li>● The new file name is set by "AT+FTPPUTNAME" and "AT+FTPPUTPATH" command.</li> </ul>

### 11.2.28 AT+FTPMDTM Get the Last Modification Timestamp of Specified File on the Remote Machine

AT+FTPMDTM Get the Last Modification Timestamp of Specified File on the Remote Machine	
Test Command <b>AT+FTPMDTM=?</b>	Response <b>OK</b>
	Parameters See Execution Command
Execution Command <b>AT+FTPMDTM</b>	Response If success: <b>OK</b>  <b>+FTPMDTM: 1,0,&lt;timestamp&gt;</b>
	If failed: <b>OK</b>  <b>+FTPMDTM: 1,&lt;error&gt;</b>
	If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameter <b>&lt;error&gt;</b> See "AT+FTPGET" <b>&lt;timestamp&gt;</b> The last modification timestamp of the specified file.
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note The file is specified by the "AT+FTPGETNAME" and "AT+FTPGETPATH" commands.

## 12 AT Command for NTP function

### 12.1 Overview

Command	Description
AT+CNTPCID	Set GPRS bearer profile's ID
AT+CNTP	Synthesize network time

### 12.2 Detailed Descriptions of Commands

#### 12.2.1 AT+CNTPCID Set GPRS Bearer Profile's ID

AT+CNTPCID Set GPRS Bearer Profile's ID	
Test Command AT+CNTPCID=?	Response + CNTPCID: (range of supported <cid>s)  <b>OK</b>  Parameters See Write Command
Read Command AT+CNTPCID?	Response + CNTPCID: <cid>  <b>OK</b>  Parameters See Write Command
Write Command AT+CNTPCID=<cid>	Response  <b>OK</b> If error is related to ME functionality: <b>ERROR</b>  Parameters <cid> Bearer profile identifier, refer to AT+SAPBR
Parameter Saving Mode	-
Max Response Time	-
Reference	Note

#### 12.2.2 AT+CNTP Synchronize Network Time

AT+CNTP Synchronize Network Time

<p>Test Command <b>AT+CNTP=?</b></p>	<p>Response <b>+CNTP:</b> (length of <b>&lt;ntp server&gt;</b>),(range of <b>&lt;time zone&gt;</b>),(range of <b>&lt;cid&gt;</b>), (range of <b>&lt;mode&gt;</b>)</p> <p><b>OK</b></p> <p>Parameter See Write Command</p>
<p>Read Command <b>AT+CNTP?</b></p>	<p>Response <b>+ CNTP:</b> <b>&lt;ntp sever&gt;</b>,<b>&lt;time zone&gt;</b>,<b>&lt;cid&gt;</b>,<b>&lt;mode&gt;</b></p> <p><b>OK</b></p> <p>Parameter See Write Command</p>
<p>Write Command <b>AT+CNTP=&lt;ntp server&gt;[,&lt;time zone&gt;][,&lt;cid&gt;][,&lt;mode&gt;]</b></p>	<p>Response <b>OK</b></p> <p>Parameter</p> <p><b>&lt;ntp server&gt;</b>      NTP server's url</p> <p><b>&lt;time zone&gt;</b>      Local time zone, the range is (-47 to 48), in fact, time zone range (-12 to 12), but taking into account that some countries and regions will use half time zone, or even fourth time zone, so the entire extended four time zones X, so that when the time zone of the input integers are used, without the need for decimal. Time zone in front of the West if it is a negative number indicates the time zone.</p> <p><b>&lt;cid&gt;</b>              Bearer profile identifier, refer to AT+SAPBR</p> <p><b>&lt;mode&gt;</b>            print network time on uart and set to local time</p> <p>         0      Just set network to localtime</p> <p>         1      Just output network time to AT port</p> <p>         <u>2</u>      Set network to localtime and output network time to AT port</p>
<p>Execution command <b>AT+CNTP</b></p>	<p>Response <b>OK</b></p> <p><b>+CNTP:</b> <b>&lt;code&gt;</b>[,<b>&lt;time&gt;</b>]</p> <p>Parameter</p> <p><b>&lt;code&gt;</b>            1    Network time synchronization is successful</p> <p>                     61   Network Error</p> <p>                     62   DNS resolution error</p> <p>                     63   Connection Erro</p> <p>                     64   Service response error</p> <p>                     65   Service Response Timeout</p> <p><b>&lt;time&gt;</b>          Network time</p>
<p>Parameter      Saving Mode</p>	<p>-</p>



Max Response Time	-
Reference	<p>Note</p> <ul style="list-style-type: none"> <li>● After successful synchronization time, you can use AT+CCLK to query local time.</li> </ul>

## 13 AT Commands for OneNet Application

### 13.1 Overview

Command	Description
AT+MIPLCREATE	Create OneNet configuration
AT+MIPLDELETE	Delete OneNet configuration
AT+MIPLOPEN	Connect to OneNet
AT+MIPLADDOBJ	Add object
AT+MIPLDELOBJ	Delete object
AT+MIPLCLOSE	Disconnect to OneNet
AT+MIPLNOTIFY	Notify data to OneNet
AT+MIPLREADRSP	Send response on read command
AT+MIPLWRITERSP	Send response on write command
AT+MIPLEXECUTERSP	Send response on execute command
AT+MIPLOBSERVERSP	Send response on observe command
AT+MIPLDISCOVERERRSP	Send response on discover command
AT+MIPLPARAMETERERRSP	Send response on parameter command
AT+MIPLUPDATE	Update registration
AT+MIPLVER	Version of OneNet SDK
AT+MIPLBOOTSTRAP	Bootstrap mode

### 13.2 Detailed Descriptions of Commands

#### 13.2.1 AT+MIPLCREATE Create OneNet configuration

AT+MIPLCREATE	Create OneNet configuration
Test Command	Response
AT+MIPLCREATE=?	+MIPLCREATE: <size>,<config>,<index>,<totalsize>,<flag>  OK

	Parameters See Write Command
Execution Command <b>AT+MIPLCREAT E</b>	Response <ref> <b>OK</b>
Write Command <b>AT+MIPLCREAT E=&lt;size&gt;,&lt;config&gt;,&lt;index&gt;,&lt;totalsize&gt;,&lt;flag&gt;</b>	Response <ref> <b>OK</b>  Parameters <size> Current <config> size <config> Config in hex format <index> Current config index <totalsize> Total config size <flag> Indicate the input is over or not
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 13.2.2 AT+MIPLDELETE Delete OneNet configuration

<b>AT+MIPLDELETE Delete OneNet configuration</b>	
Test Command <b>AT+MIPLDELET E=?</b>	Response <b>+MIPLDELETE: &lt;ref&gt;</b> <b>OK</b>  Parameters See Write Command
Write Command <b>AT+MIPLDELET E=&lt;ref&gt;</b>	Response <b>OK</b>  Parameters <ref> Config id
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 13.2.3 AT+MIPLOPEN Connect to OneNet

#### **AT+MIPLOPEN Connect to OneNet**

Test Command <b>AT+MIPLOPEN=?</b>	Response <b>+MIPLOPEN: &lt;ref&gt;,&lt;lifetime&gt;,&lt;param&gt;</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+MIPLOPEN= &lt;ref&gt;,&lt;lifetime&gt;,&lt;p aram&gt;</b>	Response <b>OK</b>  Parameters <b>&lt;ref&gt;</b> Config id <b>&lt;lifetime&gt;</b> Lifetime to update automatically <b>&lt;param&gt;</b> Reserved
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

#### 13.2.4 AT+MIPLADDOBJ Add object

<b>AT+MIPLADDOBJ Add object</b>	
Test Command <b>AT+MIPLADDOBJ J=?</b>	Response <b>+MIPLADDOBJ: &lt;ref&gt;,&lt;objectid&gt;,&lt;instancecount&gt;,&lt;instanceBitmap&gt;,&lt;attributeCount&gt;,&lt;actionCount&gt;</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+MIPLADDOBJ= &lt;ref&gt;,&lt;objectid&gt; &lt;instancecount&gt;,&lt;i nstanceBitmap&gt;,&lt;a ttributeCount&gt;,&lt;ac tionCount&gt;</b>	Response <b>OK</b>  Parameters <b>&lt;ref&gt;</b> Config id <b>&lt;objectid&gt;</b> Object id <b>&lt;instancecount&gt;</b> Count of instance <b>&lt;instanceBitmap&gt;</b> Bitmap of instance <b>&lt;attributeCount&gt;</b> Count of attribute resource <b>&lt;actionCount&gt;</b> Count of action resource
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 13.2.5 AT+MIPLDELOBJ Delete Object

<b>AT+MIPLDELOBJ Delete object</b>	
Test Command <b>AT+MIPLDELOBJ=?</b>	Response <b>+MIPLDELOBJ: &lt;ref&gt;,&lt;objectid&gt;</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+MIPLDELOBJ=&lt;ref&gt;,&lt;objectid&gt;</b>	Response <b>OK</b>
	Parameters <b>&lt;ref&gt;</b> Config id <b>&lt;object&gt;</b> Object id
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 13.2.6 AT+MIPLCLOSE Disconnect to OneNet

<b>AT+MIPLCLOSE Disconnect to OneNet</b>	
Test Command <b>AT+MIPLCLOSE=?</b>	Response <b>+MIPLCLOSE: &lt;ref&gt;</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+MIPLCLOSE=&lt;ref&gt;</b>	Response <b>OK</b>
	Parameters <b>&lt;ref&gt;</b> Config id
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 13.2.7 AT+MIPLNOTIFY Notify data to OneNet

<b>AT+MIPLNOTIFY Notify data to OneNet</b>	
Test Command	Response

AT+MIPLNOTIFY=?	<b>+MIPLNOTIFY:</b> <ref>,<msgid>,<objectid>,<instanceid>,<resourceid>,<valuetype>,<len>,<value>,<index>,<flag>[,<ackid>]  <b>OK</b>  Parameters See Write Command
Write Command AT+MIPLNOTIFY=<ref>,<msgid>,<objectid>,<instanceid>,<resourceid>,<valuetype>,<len>,<value>,<index>,<flag>[,<ackid>]	Response <b>OK</b>  Parameters <ref> Config id <objectid> Object id <instanceid> Instance id <resourceid> Resource id <valuetype> Type of value 1 String 2 Opaque 3 Integer 4 Float 5 Bool <len> Length <value> Value string <index> Index of current input <flag> Indicate the input is over or not <ackid> Need ack or not
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 13.2.8 AT+MIPLREADRSP Send response on read command

AT+MIPLREADRSP Send response on read command	
Test Command AT+MIPLREADRSP=?	Response <b>+MIPLREADRSP:</b> <ref>,<msgid>,<result>,<objectid>,<instanceid>,<resourceid>,<valuetype>,<len>,<value>,<index>,<flag>  <b>OK</b>  Parameters See Write Command
Write Command	Response

<b>AT+MIPLREADR</b> <b>SP=&lt;ref&gt;,&lt;msgid&gt;,&lt;result&gt;,&lt;objectid&gt;,&lt;instanceid&gt;,&lt;resourceid&gt;,&lt;valuetype&gt;,&lt;len&gt;,&lt;value&gt;,&lt;index&gt;,&lt;flag&gt;</b>	<b>OK</b> Parameters <ref> Config id <msgid> Message id <result> Result <objectid> Object id <instanceid> Instance id <resourceid> Resource id <valuetype> Type of value 1 String 2 Opaque 3 Integer 4 Float 5 Bool <len> Length <value> Value string <index> Index of current input <flag> Indicate the input is over or not
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 13.2.9 AT+MIPLWRITERSP Send response on write command

AT+MIPLWRITERSP Send response on write command	
Test Command <b>AT+MIPLWRITE RSP=?</b>	Response <b>+MIPLWRITERSP: &lt;ref&gt;,&lt;msgid&gt;,&lt;result&gt;</b>  <b>OK</b> Parameters See Write Command
Write Command <b>AT+MIPLWRITE RSP=&lt;ref&gt;,&lt;msgid&gt;,&lt;result&gt;</b>	Response <b>OK</b> Parameters <ref> Config id <msgid> Message id <result> Result
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 13.2.10 AT+MIPLEXECUTERSP Send response on execute command

AT+MIPLEXECUTERSP Send response on execute command	
Test Command <b>AT+MIPLEXECUTERSP=?</b>	Response <b>+MIPLEXECUTERSP: &lt;ref&gt;,&lt;msgid&gt;,&lt;result&gt;</b>
	<b>OK</b>
	Parameters See Write Command
Write Command <b>AT+MIPLEXECUTERSP=&lt;ref&gt;,&lt;msgid&gt;,&lt;result&gt;</b>	Response <b>OK</b>
	Parameters <b>&lt;ref&gt;</b> Config id <b>&lt;msgid&gt;</b> Message id <b>&lt;result&gt;</b> Result
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 13.2.11 AT+MIPLOBSEVERSP Send response on observe command

AT+MIPLOBSEVERSP Send response on observe command	
Test Command <b>AT+MIPLOBSEVERSP=?</b>	Response <b>+MIPLOBSEVERSP: &lt;ref&gt;,&lt;msgid&gt;,&lt;result&gt;</b>
	<b>OK</b>
	Parameters See Write Command
Write Command <b>AT+MIPLOBSEVERSP=&lt;ref&gt;,&lt;msgid&gt;,&lt;result&gt;</b>	Response <b>OK</b>
	Parameters <b>&lt;ref&gt;</b> Config id <b>&lt;msgid&gt;</b> Message id <b>&lt;result&gt;</b> Result
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note



### 13.2.12 AT+MIPLDISCOVERERRSP Send response on discover command

AT+MIPLDISCOVERERRSP Send response on discover command	
Test Command <b>AT+MIPLDISCOVERERRSP=?</b>	Response <b>+MIPLDISCOVERERRSP:</b> <ref>,<msgid>,<result>,<length>,<valuestring>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+MIPLDISCOVERERRSP=&lt;ref&gt;,&lt;msgid&gt;,&lt;result&gt;,&lt;length&gt;,&lt;valuestring&gt;</b>	Response <b>OK</b>
	Parameters <ref> Config id <msgid> Message id <result> Result <length> Number of resourceid <valuestring> Resource id string
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 13.2.13 AT+MIPLPARAMETERERRSP Send response on parameter command

AT+MIPLPARAMETERERRSP Send response on parameter command	
Test Command <b>AT+MIPLPARAMETERERRSP=?</b>	Response <b>+MIPLPARAMETERERRSP: &lt;ref&gt;,&lt;msgid&gt;,&lt;result&gt;</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+MIPLPARAMETERERRSP=&lt;ref&gt;,&lt;msgid&gt;,&lt;result&gt;</b>	Response <b>OK</b>
	Parameters <ref> Config id <msgid> Message id <result> Result
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 13.2.14 AT+MIPLUPDATE Update registration

AT+MIPLUPDATE Update registration	
Test Command <b>AT+MIPLUPDAT E=?</b>	Response <b>+MIPLUPDATE: &lt;ref&gt;,&lt;lifetime&gt;,&lt;flag&gt;</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+MIPLUPDAT E=&lt;ref&gt;,&lt;lifetime&gt; ,&lt;flag&gt;</b>	Response <b>OK</b>
	Parameters <ref> Config id <lifetime> Lifetime to update <flag> Update with object update or not
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 13.2.15 AT+MIPLVER Version of OneNet SDK

AT+MIPLVER Version of OneNet SDK	
Read Command <b>AT+MIPLVER?</b>	Response <b>+MIPLVER: &lt;version&gt;</b>  <b>OK</b>
	Parameters <version> Version of SDK
Parameter Saving Mode	-
Max Response Time	-
Reference	Note

### 13.2.16 AT+MIPLBOOTSTRAP Bootstrap mode

AT+MIPLBOOTSTRAP Bootstrap mode	
Write Command <b>AT+MIPLBOOTS</b>	Response <b>OK</b>

<b>TRAP=&lt;mode&gt;</b>	Parameters <b>&lt;mode&gt;</b> Bootstrap mode 0    Disable 1    Enable
Parameter    Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

## 14 AT Commands for Telecom IOT Application

### 14.1 Overview

Command	Description
AT+SIMLCREATE	Create configuration
AT+SIMLMODE	Connection mode
AT+SIMLOPEN	Connect to Telecom IOT
AT+SIMLSEND	Send data to Telecom IOT
AT+SIMLCLOSE	Disconnect to Telecom IOT

### 14.2 Detailed Descriptions of Commands

#### 14.2.1 AT+SIMLCREATE Create configuration

AT+SIMLCREATE	Create configuration
Test Command AT+SIMLCREAT E=?	Response +SIMLCREATE: <config>  OK  Parameters See Write Command
Write Command AT+SIMLCREAT E=<config>	Response OK  Parameters <config> Config in hex format
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

#### 14.2.2 AT+SIMLMODE Connection mode

AT+SIMLMODE	Connection mode
Test Command AT+SIMLMODE= ?	Response +SIMLMODE: <mode>  OK

	Parameters See Write Command
Write Command <b>AT+SIMLMODE=</b> <b>&lt;mode&gt;</b>	Response <b>OK</b>  Parameters <b>&lt;mode&gt;</b> Connection mode <u>1</u> Other 2    China Telecom IOT
Parameter    Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

#### 14.2.3 AT+SIMLOPEN    Connect to Telecom IOT

<b>AT+SIMLOPEN    Connect to Telecom IOT</b>	
Test Command <b>AT+SIMLOPEN=?</b>	Response <b>+SIMLOPEN: &lt;lifetime&gt;</b>  <b>OK</b>  Parameters See Write Command
Write Command <b>AT+SIMLOPEN=&lt;</b> <b>lifetime&gt;</b>	Response <b>OK</b>  Parameters <b>&lt;lifetime&gt;</b> Reserved
Parameter    Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

#### 14.2.4 AT+SIMLSEND    Send data to Telecom IOT

<b>AT+SIMLSEND    Send data to Telecom IOT</b>	
Test Command <b>AT+SIMLSEND=?</b>	Response <b>+SIMLSEND: &lt;data&gt;,&lt;flag&gt;</b>  <b>OK</b>  Parameters See Write Command

Write Command <b>AT+SIMLSEND=&lt;data&gt;,&lt;flag&gt;</b>	Response <b>OK</b>
	Parameters <data>      String in hex format <flag> 0      Input over 1      Input not over
Parameter    Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

#### 14.2.5 AT+SIMLCLOSE    Disconnect to Telecom IOT

<b>AT+SIMLCLOSE    Disconnect to Telecom IOT</b>	
Execution Command <b>AT+SIMLCLOSE</b>	Response <b>OK</b>
	Parameters
Parameter    Saving Mode	-
Max Response Time	-
Reference	Note

## 15 AT Commands for GNSS Application

Heracles224G modules provide GNSS AT command is as follows:

### 15.1 Overview

Command	Description
AT+CGNSPWR	GNSS Power Control
AT+CGNSINF	GNSS Navigation Information Parsed From NMEA Sentences
AT+CGNSURC	GNSS Navigation URC Report
AT+CGNSPORT	GNSS Nmea Out Port Set
AT+CGNSCOLD	GNSS Cold Start
AT+CGNSWARM	GNSS Warm Start
AT+CGNSHOT	GNSS Hot Start
AT+CGNSMOD	GNSS Work Mode Set
AT+CGNSCFG	GNSS Nmea Out Configure
AT+CGNSTST	GNSS NMEA Data Out Put To AT Port
AT+CGNSXTRA	GNSS XTRA Function Open
AT+CGNSCPY	GNSS XTRA File Copy

## 15.2 Detailed Descriptions of Commands

### 15.2.1 AT+CGNSPWR GNSS Power Control

AT+CGNSPWR GNSS Power Control	
Test Command <b>AT+CGNSPWR=?</b>	Response <b>+CGNSPWR:</b> (list of supported <mode>s )  <b>OK</b>
	Parameters See Write Command
Read Command <b>AT+CGNSPWR?</b>	Response TA returns the current status of GNSS Power supply <b>+CGNSPWR:</b> <mode>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+CGNSPWR=&lt;mode&gt;</b>	Response <b>OK</b> or <b>ERROR</b>
	Parameters <mode> 0 Turn off GNSS power supply 1 Turn on GNSS power supply
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	NMEA data will not out put to usb's NMEA port when set AT+CGNSPWR=1 through uart port except config it by AT+CGNSCFG=1.

### 15.2.2 AT+CGNSINF GNSS Navigation Information Parsed From NMEA Sentences

AT+CGNSINF GNSS Navigation Information Parsed From NMEA Sentences	
Test Command <b>AT+CGNSINF=?</b>	Response <b>OK</b>
	Parameters See Execution Command
Execution Command	Response <b>+CGNSINF:</b> <GNSS run status>,<Fix status>,<UTC date & Time>,



AT+CGNSINF	<p>&lt;Latitude&gt;,&lt;Longitude&gt;,&lt;MSL Altitude&gt;,&lt;Speed Over Ground&gt;,&lt;Course Over Ground&gt;,&lt;Fix Mode&gt;,&lt;Reserved1&gt;,&lt;HDOP&gt;,&lt;PDOP&gt;,&lt;VDOP&gt;,&lt;Reserved2&gt;,&lt;GNSS Satellites in View&gt;,&lt;GNSS Satellites Used&gt;,&lt;GLONASS Satellites Used&gt;,&lt;Reserved3&gt;,&lt;C/N0 max&gt;,&lt;HPA&gt;,&lt;VPA&gt;</p> <p><b>OK</b></p> <p>Parameters</p> <p>&lt;GNSS run status&gt;</p> <p>0 GNSS off</p> <p>1 GNSS on</p> <p>&lt;Fix status&gt;</p> <p>0 Not fixed position</p> <p>1 Fixed position</p> <p>See below table 2-3.</p>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

Table 2-1: AT+CGNSINF return Parameters

Index	Parameter	Unit	Range	Length
1	GNSS run status	--	0-1	1
2	Fix status	--	0-1	1
3	UTC date & Time	yyyyMMddhh mmss.sss	yyyy: [1980,2039] MM : [1,12] dd: [1,31] hh: [0,23] mm: [0,59] ss.sss:[0.000,60.999]	18
4	Latitude	±dd.dddddd	[-90.000000,90.000000]	10
5	Longitude	±ddd.dddddd	[-180.000000,180.000000]	11
6	MSL Altitude	meters		8
7	Speed Over Ground	Km/hour	[0,999.99]	6
8	Course Over Ground	degrees	[0,360.00]	6
9	Fix Mode	--	0,1,2 <sup>[1]</sup>	1
10	Reserved1			0
11	HDOP	--	[0,99.9]	4
12	PDOP	--	[0,99.9]	4

13	VDOP	--	[0,99.9]	4
14	Reserved2			0
15	GPS Satellites in View	--	[0,99]	2
16	GNSS Satellites Used	--	[0,99]	2
17	GLONASS Satellites in View	--	[0,99]	2
18	Reserved3			0
19	C/N0 max	dBHz	[0,55]	2
20	HPA <sup>[2]</sup>	meters	[0,9999.9]	6
21	VPA <sup>[2]</sup>	meters	[0,9999.9]	6
Total: (94) chars				

### 15.2.3 AT+CGNSURC GNSS Navigation URC Report

AT+CGNSURC	GNSS Navigation URC Report
Test Command <b>AT+CGNSURC=?</b>	<p>Response</p> <p><b>+CGNSURC: (0-255)</b></p> <p><b>OK</b></p> <p>Parameters</p> <p>See Write Command</p>
Read Command <b>AT+CGNSURC?</b>	<p>Response</p> <p>TA returns the current URC setting</p> <p><b>+CGNSURC: &lt;Navigation mode&gt;</b></p> <p><b>OK</b></p> <p>Parameters</p> <p>See Write Command</p> <p>Unsolicited Result Code</p> <p><b>+UGNSINF: &lt;GNSS run status&gt;,&lt;Fix status&gt;,&lt;UTC date &amp; Time&gt;,&lt;Latitude&gt;,&lt;Longitude&gt;,&lt;MSL Altitude&gt;,&lt;Speed Over Ground&gt;,&lt;Course Over Ground&gt;,&lt;Fix Mode&gt;,&lt;Reserved1&gt;,&lt;HDOP&gt;,&lt;PDOP&gt;,&lt;VDOP&gt;,&lt;Reserved2&gt;,&lt;Satellites in View&gt;,&lt;Satellites Used&gt;,&lt;Reserved3&gt;,&lt;C/N0 max&gt;,&lt;HPA&gt;,&lt;VPA&gt;</b></p>
Write Command <b>AT+CGNSURC=&lt;Navigation mode&gt;</b>	<p>Response</p> <p><b>OK</b></p> <p>or</p> <p><b>ERROR</b></p> <p>Parameters</p> <p><b>&lt;Navigation mode&gt;:</b></p> <p>0 Turn off navigation data URC report</p> <p>1 Turn on navigation data URC report, and report every GNSS FIX</p> <p>2 Turn on navigation data URC report, and report every 2 GNSS FIX</p> <p>...</p> <p>255 Turn on navigation data URC report, and report every 255 GNSS FIX</p>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	<p>Note</p> <ul style="list-style-type: none"> <li>Factory setting is "AT+CGNSURC=0".</li> <li>URC "+UGNSINF: "parameters are the same as "+CGNSINF:" return.</li> </ul>

#### 15.2.4 AT+CGNSPORT GNSS NMEA Out Port Set

AT+CGNSPORT GNSS NMEA Out Port Set	
Test Command <b>AT+CGNSPORT=?</b>	Response <b>+CGNSPORT:</b> (list of supported <b>&lt;port&gt;</b> )  <b>OK</b>
	Parameters See Write Command
Read Command <b>AT+CGNSPORT?</b>	Response <b>+CGNSPORT:</b> <b>&lt;port&gt;</b>  <b>OK</b>
Write Command <b>AT+CGNSPORT=&lt;port&gt;</b>	Response <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <b>&lt;port&gt;</b> num of the port NMEA out <u>3</u> NMEA port 4      NONE
Parameter Saving Mode	AUTO_SAVE_REBOOT
Max Response Time	-
Reference	Note Module must reboot to make it effect if <b>&lt;port&gt;</b> value is changed.

#### 15.2.5 AT+CGNSCOLD GNSS Cold Start

AT+CGNSCOLD GNSS Cold Start	
Test Command <b>AT+CGNSCOLD=?</b>	Response <b>OK</b>
Execution Command <b>AT+CGNSCOLD</b>	Response If AT+CGNSXTRA=0 <b>OK</b> Else if AT+CGNSXTRA=1 <b>OK</b>  <b>+CGNSXTRA: &lt;mod&gt;</b>

	Parameters <mod>  0 Aid XTRA file success 1 XTRA file is not exist 2 XTRA file is not effective
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 15.2.6 AT+CGNSWARM GNSS Warm Start

AT+CGNSWARM GNSS Warm Start	
Test Command <b>AT+CGNSWARM=?</b>	Response <b>OK</b>
Execution Command <b>AT+CGNSWARM</b>	Response <b>OK</b>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 15.2.7 AT+CGNSHOT GNSS Hot Start

AT+CGNSHOT GNSS Hot Start	
Test Command <b>AT+CGNSHOT=?</b>	Response <b>OK</b>
Execution Command <b>AT+CGNSHOT</b>	Response <b>OK</b>
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

## 15.2.8 AT+CGNSMOD GNSS Work Mode Set

AT+CGNSMOD GNSS Work Mode Set	
Test Command <b>AT+CGNSMOD=?</b>	<p>Response</p> <p><b>+CGNSMOD:</b> (list of supported <b>&lt;gps mode&gt;</b>),( list of supported <b>&lt;glo mode&gt;</b>s),( list of supported <b>&lt;bd mode&gt;</b>s),( list of supported <b>&lt;gal mode&gt;</b>s)</p> <p><b>OK</b></p> <p>Parameters</p> <p>See Write Command</p>
Read Command <b>AT+CGNSMOD?</b>	<p>Response</p> <p><b>+CGNSMOD:</b> <b>&lt;gps mode&gt;</b>,<b>&lt;glo mode&gt;</b>,<b>&lt;bd mode&gt;</b>,<b>&lt;gal mode&gt;</b></p> <p><b>OK</b></p>
Write Command <b>AT+CGNSMOD=&lt;gps mode&gt;,&lt;glo mode&gt;,&lt;bd mode&gt;,&lt;gal mode&gt;</b>	<p>Response</p> <p><b>OK</b></p> <p>If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters</p> <p><b>&lt;GPS mode&gt;</b>      GPS work mode</p> <p>    <u>1</u>      Start GPS NMEA out</p> <p><b>&lt;glo mode&gt;</b>      GLONASS work mode</p> <p>    0      Stop GLONASS NMEA out</p> <p>    <u>1</u>      Start GLONASS NMEA out</p> <p><b>&lt;bd mode&gt;</b>      BEIDOU work mode</p> <p>    0      Stop BEIDOU NMEA out</p> <p>    <u>1</u>      Start BEIDOU NMEA out</p> <p>    2      BEIDOU outside of us</p> <p><b>&lt;ga mode&gt;</b>      GALILEAN work mode</p> <p>    <u>0</u>      Stop GALILEAN NMEA out</p> <p>    1      Start GALILEAN NMEA out</p> <p>    2      GALILEAN out side of us</p>
Parameter Saving Mode	AUTO_SAVE_REBOOT
Max Response Time	-
Reference	Note

## 15.2.9 AT+CGNSCFG GNSS NMEA Out Configure

AT+CGNSCFG GNSS NMEA Out Configure	
Test Command <b>AT+CGNSCFG=?</b>	Response <b>+CGNSCFG:</b> (list of supported <mode>s )  <b>OK</b>
	Parameters See Write Command
Read Command <b>AT+CGNSCFG?</b>	Response TA returns the current status of configure <b>+CGNSCFG: &lt;mode&gt;</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+CGNSCFG=&lt;mode&gt;</b>	Response <b>OK</b> or <b>ERROR</b>
	Parameters <b>&lt;mode&gt;</b> <b>0</b> Turn off GNSS NMEA data out put to USB's NMEA port when set AT+CGNSPWR=1/0 through UART <b>1</b> Turn on GNSS NMEA data out put to USB's NMEA port when set AT+CGNSPWR=1/0 through UART <b>2</b> Turn on GNSS NMEA data out put to UART3 port when set AT+CGNSPWR=1/0
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note This command only supported in UART port.

## 15.2.10 AT+CGNSTST GNSS NMEA Data Out Put To At Port

AT+CGNSTST GNSS NMEA Data Out Put To At Port	
Test Command <b>AT+CGNSTST=?</b>	Response <b>+CGNSTST: (0-1), (1-255)</b>  <b>OK</b>
	Parameters See Write Command
Read Command <b>AT+CGNSTST?</b>	Response TA returns the current status of configure <b>+CGNSTST: &lt;TST&gt;</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+CGNSTST=&lt;TST&gt;[,&lt;cont&gt;]</b>	Response <b>OK</b> or <b>ERROR</b>
	Parameters <b>&lt;TST&gt;</b> <u>0</u> Turn off GNSS NMEA data out put to AT port 1    Turn on GNSS NMEA data out put to AT port <b>&lt;cont&gt;</b> 1-255 the number of NMEA data package
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	



### 15.2.11 AT+CGNSXTRA GNSS XTRA Function Open

AT+CGNSXTRA GNSS XTRA Function Open	
Test Command <b>AT+CGNSXTRA=?</b>	Response <b>+CGNSXTRA: (0-1)</b>  <b>OK</b>
	Parameters See Write Command
Read Command <b>AT+CGNSXTRA?</b>	Response TA returns the current status of configure <b>+CGNSXTRA: &lt;enable&gt;</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+CGNSXTRA=&lt;enable&gt;</b>	Response <b>OK</b> or <b>ERROR</b>
	Parameters <b>&lt;enable&gt;</b>  0 Disable XTRA function 1 Enable XTRA function
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

### 15.2.12 AT+CGNSCPY GNSS XTRA File Copy

AT+CGNSCPY GNSS XTRA File Copy	
Test Command <b>AT+CGNSCPY=?</b>	Response <b>OK</b>
	Parameters See Execution Command
Execution Command <b>AT+CGNSCPY</b>	Response <b>+CGNSCPY: &lt;ret&gt;</b>  <b>OK</b>

	Parameters <ret> 1   File not exist 0   Copy success
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	

## 16 AT Commands for File System

### 16.1 Overview

Command	Description
AT+CFSINIT	Get Flash Data Buffer
AT+CFSWFILE	Write File to the Flash Buffer Allocated by CFSINIT
AT+CFSRFILE	Read File from Flash
AT+CFSDFILE	Delete the File from the Flash
AT+CFSGFIS	Get File Size
AT+CFSREN	Rename a file
AT+CFSGFRS	Get the size of file system
AT+CFSTERM	Free the Flash Buffer Allocated by CFSINIT
AT+CBAINIT	Initialize the ap backup file system
AT+CBALIST	Set the files which want to backup
AT+CBAPPS	Start to backup ap file system allocated by CBAINIT and CBALIST
AT+CBART	Restore the file into ap file system

### 16.2 Detailed Descriptions of Commands

#### 16.2.1 AT+CFSINIT Get Flash Data Buffer

AT+CFSINIT Get Flash Data Buffer	
Execution Command <b>AT+CFSINIT</b>	Response <b>OK</b> or <b>ERROR</b> or <b>+CME ERROR: &lt;err&gt;</b>
	Parameters
Parameter Saving Mode	-
Max Response Time	-
Reference	Note

## 16.2.2 AT+CFSWFILE Write File to the Flash Buffer Allocated by CFSINIT

AT+CFSWFILE Write File to the Flash Buffer Allocated by CFSINIT	
Test Command <b>AT+CFSWFILE=?</b>	<p>Response</p> <p><b>+CFSWFILE: (0-3),"fileName",(0-1),(1-10240),(100-10000)</b></p> <p><b>OK</b></p> <p>Parameters See Write Command</p>
Write Command <b>AT+CFSWFILE=&lt;index&gt;,&lt;file name&gt;,&lt;mode&gt;,&lt;file size&gt;,&lt;input time&gt;</b>	<p>Response</p> <p><b>OK</b></p> <p>or</p> <p><b>ERROR</b></p> <p>or</p> <p><b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters</p> <p><b>&lt;index&gt;</b></p> <p>Directory of AP filesystem:</p> <ul style="list-style-type: none"> <li>0 "/custapp/"</li> <li>1 "/fota/"</li> <li>2 "/datatx/"</li> <li>3 "/customer/"</li> </ul> <p><b>&lt;file name&gt;</b></p> <p>File name length should less or equal 50 characters</p> <p><b>&lt;mode&gt;</b></p> <ul style="list-style-type: none"> <li>0 If the file already existed, write the data at the beginning of the file.</li> <li>1 If the file already existed, add the data at the end of the file.</li> </ul> <p><b>&lt;file size&gt;</b></p> <p>File size should be less than 10240 bytes.</p> <p><b>&lt;input time&gt;</b> Millisecond, should send file during this period or you can't send file when timeout. The value should be less than 10000 ms.</p>
Parameter Saving Mode	-
Max Response Time	-
Reference	Note

## 16.2.3 AT+CFSRFILE Read File from Flash

### AT+CFSRFILE Read File from Flash

Test Command <b>AT+CFSRFILE=?</b>	Response <b>+CFSRFILE: (0-3),"fileName",(0-1),(1-10240),(0-filesize)</b>  <b>OK</b>  Parameters See Write Command
Write Command <b>AT+CFSRFILE=&lt;index&gt;,&lt;file name&gt;,&lt;mode&gt;,&lt;file size&gt;,&lt;position&gt;</b>	Response <b>OK</b> or <b>ERROR</b> or <b>+CME ERROR: &lt;err&gt;</b>  Parameters <b>&lt;index&gt;</b> Directory of AP filesystem: 0   "/custapp/" 1   "/fota/" 2   "/datatx/" 3   "/customer/"  <b>&lt;file name&gt;</b> File name length should be less than or equal to 50 characters, <b>&lt;mode&gt;</b> 0   Read data at the beginning of the file . 1   Read data at the <position> of the file .  <b>&lt;file size&gt;</b> The size of the file that you want to read should be less than 10240. <b>&lt;position&gt;</b> The starting position that will be read in the file. When <write mode>=0, <position> is invalid. Read data from the beginning to the end of the file. When <write mode>=1, <position> is valid. Read data from the <position> to the end of the file.
Parameter   Saving Mode	-
Max        Response Time	-
Reference	Note

#### 16.2.4 AT+CFSDFILE Delete the File from the Flash

**AT+CFSDFILE   Delete the File from the Flash**

Test Command <b>AT+CFSDFILE=?</b>	Response <b>+CFSDFILE: (0-3),"fileName"</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+CFSDFILE=&lt;index&gt;,&lt;file name&gt;</b>	Response <b>OK</b> or <b>ERROR</b> or <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <b>&lt;index&gt;</b> Directory of AP filesystem: 0 "/custapp/" 1 "/fota/" 2 "/datatx/" 3 "/customer/" <b>&lt;file name&gt;</b> File name length should be less than or equal to 50 characters.
Parameter Saving Mode	-
Max Response Time	-
Reference	Note

### 16.2.5 AT+CFSGFIS Get File Size

<b>AT+CFSGFIS Get File Size</b>	
Test Command <b>AT+CFSGFIS=?</b>	Response <b>+CFSGFIS: (0-3),"fileName"</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+CFSGFIS=&lt;index&gt;,&lt;file name&gt;</b>	Response <b>ERROR</b> or <b>+CME ERROR: &lt;err&gt;</b> or <b>+CFSGFIS:&lt;n&gt;</b>

	<p><b>OK</b></p>
	<p>Parameters</p> <p><b>&lt;file name&gt;</b> File name length should be less than or equal to 50 characters.</p> <p><b>&lt;n&gt;</b> File size</p> <p><b>&lt;index&gt;</b> Directory of AP filesystem:</p> <ul style="list-style-type: none"> <li>0 "/custapp/"</li> <li>1 "/fota/"</li> <li>2 "/datatx/"</li> <li>3 "/customer/"</li> </ul>
Parameter Saving Mode	-
Max Response Time	-
Reference	Note

## 16.2.6 AT+CFSREN Rename a file

AT+CFSREN Rename a file	
Test Command <b>AT+CFSREN=?</b>	<p>Response</p> <p><b>+CFSREN: (0-3),"old_name","new_name"</b></p> <p><b>OK</b></p> <p>Parameters See Write Command</p>
Write Command <b>AT+CFSREN=&lt;index&gt;,&lt;old file name&gt;,&lt;new file name&gt;</b>	<p>Response</p> <p><b>OK</b> or <b>ERROR</b> or <b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters</p> <p><b>&lt;index&gt;</b> Directory of AP filesystem:</p> <ul style="list-style-type: none"> <li>0 "/custapp/"</li> <li>1 "/fota/"</li> <li>2 "/datatx/"</li> <li>3 "/customer/"</li> </ul>

	<p><b>&lt;old file name&gt;</b> File name length should be less than or equal to 50 characters.</p> <p><b>&lt;new file name&gt;</b> File name length should be less than or equal to 50 characters.</p>
Parameter Saving Mode	-
Max Response Time	-
Reference	Note

### 16.2.7 AT+CFSGFRS Get the size of File System

AT+CFSGFRS Get the size of file system	
Read Command <b>AT+CFSGFRS?</b>	<p>Response</p> <p><b>ERROR</b></p> <p>or</p> <p><b>+CME ERROR: &lt;err&gt;</b></p> <p>or</p> <p><b>+CFSGFRS:&lt;n&gt;</b></p> <p><b>OK</b></p> <p>Parameters</p> <p><b>&lt;n&gt;</b> the size of file system</p>
Parameter Saving Mode	-
Max Response Time	-
Reference	Note

### 16.2.8 AT+CFSTERM Free the Flash Buffer Allocated by CFSINIT

AT+CFSTERM Free the Flash Buffer Allocated by CFSINIT	
Execution Command <b>AT+CFSTERM</b>	<p>Response</p> <p><b>OK</b></p> <p>or</p> <p><b>ERROR</b></p> <p>or</p> <p><b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters</p>



Parameter Saving Mode	-
Max Response Time	-
Reference	Note

### 16.2.9 AT+CBAINIT Initialize the ap backup file system

AT+CBAINIT Initialize the ap backup file system	
Execution Command <b>AT+CBAINIT</b>	Response <b>OK</b> or <b>ERROR</b> or <b>+CME ERROR: &lt;err&gt;</b>
	Parameters
Parameter Saving Mode	-
Max Response Time	3 seconds
Reference	Note

### 16.2.10 AT+CBALIST Set the files which want to backup

AT+CBALIST Set the files which want to backup	
Read Command <b>AT+CBALIST?</b>	Response <b>+CBALIST: &lt;index&gt;,&lt;filename&gt;</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+CBALIST=&lt;index&gt;,&lt;filename&gt;</b>	Response <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <b>&lt;index&gt;</b> 0-9    The file index. 10    Disable log 11    Enable log <b>&lt;file name&gt;</b> File name length should less than or equal to 80 characters.

Parameter Saving Mode	NO_SAVE
Max Response Time	
Reference	Note

### 16.2.11 AT+CBAPPS Start to backup ap file system Allocated by CBAINIT and CBALIST

AT+CBAPPS Start to backup ap file system Allocated by CBAINIT and CBALIST	
Execution Command <b>AT+CBAPPS</b>	Response <b>OK</b> or <b>ERROR</b> or <b>+CME ERROR: &lt;err&gt;</b> Parameters
Parameter Saving Mode	-
Max Response Time	3 seconds
Reference	Note

### 16.2.12 AT+CBART Restore the file into ap file system

AT+CBART Restore the file into ap file system	
Execution Command <b>AT+CBART</b>	Response <b>OK</b> or <b>ERROR</b> or <b>+CME ERROR: &lt;err&gt;</b> Parameters
Parameter Saving Mode	-
Max Response Time	3 seconds
Reference	Note The files should have been backup into ap file system

## 17 AT Commands for SIM Application Toolkit

### 17.1 Overview

Command	Description
AT+STIN	Get Flash Data Buffer
AT+STGI	Get SAT information
AT+STGR	SAT Respond
AT+STK	STK Switch

### 17.2 Detailed Descriptions of Commands

#### 17.2.1 AT+STIN SAT Indication

AT+STIN SAT Indication	
Test Command AT+STIN=?	Response <b>OK</b>
	Parameters See Read Command
Read Command AT+STIN?	Response <b>+STIN: &lt;cmd_id&gt;</b>  <b>OK</b> If the current proactive command has been changed: <b>+ STIN: &lt;cmd_id&gt;</b>
	Parameters <b>&lt;cmd_id&gt;</b> Indicate the type of proactive command issued. 21 Display text 22 Get inkey 23 Get input 24 Select item 25 Set up menu
Parameter Saving Mode	-
Max Response Time	-
Reference	Notification that application will return to main menu automatically if user doesn't do any action in 2 minutes.

## 17.2.2 AT+STGI Get SAT information

AT+STGI Get SAT information	
Test Command AT+STGI=?	Response <b>OK</b>
	Parameters See Write Command
Write Command AT+STGI=<cmd_id> id>	Response If <cmd_id>=21: +STGI:21,<prio>,<clear_mode>,<text_len>,<text>  <b>OK</b>  If <cmd_id>=22: +STGI:22,<rsp_format>,<help>,<text_len>,<text>  <b>OK</b>  If <cmd_id>=23: +STGI:23,<rsp_format>,<max_len>,<min_len>,<help>,<show><text_len>,<text>  <b>OK</b>  If <cmd_id>=24: +STGI:24,<help>,<softkey>,<present>,<title_len>,<title><item_num> +STGI:24,<item_id>,<item_len>,<item_data> [...]  <b>OK</b>  If <cmd_id>=25: +STGI:25,<help>,<softkey>,<title_len>,<title><item_num> +STGI:25,<item_id>,<item_len>,<item_data> [...]  <b>OK</b> or <b>ERROR</b>
	Parameters <cmd_id> See AT+STIN. <prio> Priority of display text. 0 Normal priority 1 High priority

	<p><b>&lt;clear_mode&gt;</b></p> <ul style="list-style-type: none"> <li>0 Clear after a delay</li> <li>1 Clear by user</li> </ul> <p><b>&lt;text_len&gt;</b> Length of text</p> <p><b>&lt;rsp_format&gt;</b></p> <ul style="list-style-type: none"> <li>0 SMS default alphabet</li> <li>1 YES or NO</li> <li>2 Numerical only</li> <li>3 UCS2</li> </ul> <p><b>&lt;help&gt;</b></p> <ul style="list-style-type: none"> <li>0 Help unavailable</li> <li>1 Help available</li> </ul> <p><b>&lt;max_len&gt;</b> Maximum length of input</p> <p><b>&lt;min_len&gt;</b> Minimum length of input</p> <p><b>&lt;show&gt;</b></p> <ul style="list-style-type: none"> <li>0 Hide input text</li> <li>1 Display input text</li> </ul> <p><b>&lt;softkey&gt;</b></p> <ul style="list-style-type: none"> <li>0 No softkey preferred</li> <li>1 Softkey preferred</li> </ul> <p><b>&lt;present&gt;</b> Menu presentation format available for select item</p> <ul style="list-style-type: none"> <li>0 Presentation not specified</li> <li>1 Data value presentation</li> <li>2 Navigation presentation</li> </ul> <p><b>&lt;title_len&gt;</b> Length of title</p> <p><b>&lt;item_num&gt;</b> Number of items in the menu</p> <p><b>&lt;item_id&gt;</b> Identifier of item</p> <p><b>&lt;item_len&gt;</b> Length of item</p> <p><b>&lt;title&gt;</b> Title in ucs2 format</p> <p><b>&lt;item_data&gt;</b> Content of the item in ucs2 format</p> <p><b>&lt;text&gt;</b> Text in ucs2 format</p>
Parameter Saving Mode	-
Max Response Time	-
Reference	Regularly this command is used upon receipt of an URC "+STIN" to request the parameters of the proactive command. Then the TA is expected to acknowledge the AT+STGI response with AT+STGR to confirm that the proactive command has been executed.

### 17.2.3 AT+STGR SAT respond

#### AT+STGR SAT respond

<p>Test Command <b>AT+STGR=?</b></p>	<p>Response <b>OK</b></p> <p>Parameters See Write Command</p>
<p>Write Command <b>AT+STGR=&lt;cmd_id&gt;[,&lt;data&gt;]</b></p>	<p>Response <b>OK</b> or <b>ERROR</b></p> <p>Parameters &lt;cmd_id&gt; Identifier of proactive command.  22 Get inkey  23 Get input  24 Select item  25 Set up menu  83 Session end by user  84 Go backward</p> <p>&lt;data &gt;  If &lt;cmd_id&gt;=22:  Input a character  If &lt;cmd_id&gt;=23:  Input a string.  If &lt;rsp_format&gt; is YES or NO, input of a character in case of ANSI character set requests one byte, e.g. "Y".  If &lt;rsp_format&gt; is numerical only, input the characters in decimal number, e.g. "123".  If &lt;rsp_format&gt; is UCS2, requests a 4 byte string, e.g. "0031".  &lt;rsp_format&gt; refer to the response by AT+STGI=23.  If &lt;cmd_id&gt;=24:  Input the identifier of the item selected by user.  If &lt;cmd_id&gt;=25:  Input the identifier of the item selected by user.  If &lt;cmd_id&gt;=83:  &lt;data&gt;Ignore  Note: It could return main menu during proactive command id is not 22 or 23.  If &lt;cmd_id&gt;=84:  &lt;data&gt; Ignore</p>
<p>Parameter Saving Mode</p>	<p>-</p>
<p>Max Response Time</p>	<p>-</p>
<p>Reference</p>	<p>Note</p>

#### 17.2.4 AT+STK STK Switch

AT+STK STK Switch	
Test Command <b>AT+STK=?</b>	Response <b>OK</b>
	Parameters See Write Command
Read Command <b>AT+STK?</b>	Response <b>+STK: &lt;value&gt;</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+STK=&lt;value&gt;</b>	Response <b>OK</b> or <b>ERROR</b>
	Parameters <b>&lt;value&gt;</b> <u>0</u> Disable STK 1    Enable STK
Parameter Saving Mode	-
Max Response Time	-
Reference	Note

## 18 AT Commands for TCP/UDP Application Supported SSL

### 18.1 Overview

Command	Description
AT+CACID	Set TCP/UDP identifier
AT+CASSLCFG	Set SSL certificate and timeout parameters
AT+CAOPEN	Open a TCP/UDP connection
AT+CASEND	Send data via an established connection
AT+CARECV	Receive data via an established connection
AT+CACLOSE	Close a TCP/UDP connection
AT+CSSLCFG	Configure SSL parameters of a context identifier

### 18.2 Detailed Descriptions of Commands

#### 18.2.1 AT+CACID Set TCP/UDP Identifier

AT+CACID Set TCP/UDP Identifier		
Test Command AT+CACID=?	Response +CACID: (range of supported <cid>s)  <b>OK</b>	Parameters See Write Command
Read Command AT+CACID?	Response +CACID: <cid>  <b>OK</b>	Parameters See Write Command
Write Command AT+CACID=<cid>	Response <b>OK</b> If error is related to ME functionality: +CME ERROR: <err>	Parameters <cid> TCP/UDP identifier
Parameter Saving Mode	NO_SAVE	
Max Response Time	-	



Reference	Note
-----------	------

### 18.2.3 AT+CASSLCFG Set SSL certificate and timeout parameters

AT+CASSLCFG Set SSL certificate and timeout parameters	
Test Command <b>AT+CASSLCFG=?</b>	Response + <b>CASSLCFG:</b> (range of supported <cid>s),"cacert",<caname> + <b>CASSLCFG:</b> (range of supported <cid>s),"clientcert",<certname> + <b>CASSLCFG:</b> (range of supported <cid>s),"psktable",<pskname> + <b>CASSLCFG:</b> (range of supported <cid>s),"timeout",(0-65535) + <b>CASSLCFG:</b> (range of supported <cid>s),"ssl",(0,1) + <b>CASSLCFG:</b> (range of supported <cid>s),"crindex",(0,5) + <b>CASSLCFG:</b> (range of supported <cid>s),"localport",(0-65536) + <b>CASSLCFG:</b> (range of supported <cid>s),"protocol",(0,1)  <b>OK</b>  Parameters See Write Command
Read Command <b>AT+CASSLCFG?</b>	Response If <cid> has been set by AT+CACID: + <b>CACID:</b> <cid> <b>cacert:</b> <caname> <b>clientcert:</b> <certname> <b>psktable:</b> <pskname> <b>timeout:</b> <timeout> <b>ssl:</b> <ssl> <b>crindex:</b> <crindex> <b>localport:</b> <localport> <b>protocol:</b> <protocol>  <b>OK</b> If no <cid> has been set by AT+CACID: <b>OK</b>  Parameter See Write Command
Write Command <b>AT+CASSLCFG=&lt;cid&gt;,"cacert",&lt;caname&gt;</b>	Response <b>OK</b> If error is related to ME functionality: + <b>CME ERROR:</b> <err>

	<p>Parameters</p> <p><b>&lt;cid&gt;</b> TCP/UDP identifier, see AT+CACID</p> <p><b>&lt;caname&gt;</b> Alphanumeric ASCII text string up to 64 characters. Root certificate name that has been configured by AT+CSSLCFG.</p> <p><b>Note:</b> If the root certificate is empty, module will trust all certificates as default.</p>
AT+CASSLCFG= <b>&lt;cid&gt;,"clientcert", &lt;certname&gt;</b>	<p>Response</p> <p><b>OK</b></p> <p>If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters</p> <p><b>&lt;cid&gt;</b> see AT+CACID</p> <p><b>&lt;certname&gt;</b> Alphanumeric ASCII text string up to 64 characters. Client certificate name that has been configured by AT+CSSLCFG.</p>
AT+CASSLCFG= <b>&lt;cid&gt;,"psktable", &lt;pskname&gt;</b>	<p>Response</p> <p><b>OK</b></p> <p>If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters</p> <p><b>&lt;cid&gt;</b> see AT+CACID</p> <p><b>&lt;pskname&gt;</b> Alphanumeric ASCII text string up to 64 characters. PSK table name that has been configured by AT+CSSLCFG.</p>
AT+CASSLCFG= <b>&lt;cid&gt;,"ssl",&lt;sslFlag&gt;</b>	<p>Response</p> <p><b>OK</b></p> <p>If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters</p> <p><b>&lt;cid&gt;</b> see AT+CACID</p> <p><b>&lt;sslFlag&gt;</b> Interger</p> <p>0 Not support SSL</p> <p>1 Support SSL</p>
AT+CASSLCFG= <b>&lt;cid&gt;,"crindex",&lt;crindex&gt;</b>	<p>Response</p> <p><b>OK</b></p> <p>If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters</p> <p><b>&lt;cid&gt;</b> see AT+CACID</p> <p><b>&lt;ctindex&gt;</b> The identifier of SSL configurations, see AT+CSSLCFG.</p>
AT+CASSLCFG= <b>&lt;cid&gt;,"protocol", &lt;crindex&gt;</b>	<p>Response</p> <p><b>OK</b></p> <p>If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p>

	Parameters <b>&lt;cid&gt;</b> see AT+CACID <b>&lt;protocol&gt;</b> Interger 0 TCP 1 UDP
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

#### 18.2.4 AT+CAOPEN Open a TCP/UDP connection

AT+CAOPEN Open a TCP/UDP connection	
Test Command <b>AT+CAOPEN=?</b>	Response <b>+CAOPEN:</b> (range of supported <b>&lt;cid&gt;</b> s), <b>&lt;server&gt;</b> , <b>(1-65535)</b>  <b>OK</b>  Parameters See Write Command
Read Command <b>AT+CAOPEN?</b>	Response If <b>&lt;cid&gt;</b> has been set by AT+CACID: <b>+CAOPEN:</b> <b>&lt;cid&gt;</b> , <b>&lt;server&gt;</b> , <b>&lt;port&gt;</b>  <b>OK</b> If no <b>&lt;cid&gt;</b> has been set by AT+CACID: <b>OK</b>  Parameter See Write Command
Write Command <b>AT+CAOPEN=&lt;cid&gt;,&lt;server&gt;,&lt;port&gt;</b>	Response <b>+CAOPEN:</b> <b>&lt;cid&gt;</b> , <b>&lt;result&gt;</b>  <b>OK</b> If error is related to ME functionality: <b>+CME ERROR:</b> <b>&lt;err&gt;</b>  Parameters <b>&lt;cid&gt;</b> see AT+CACID <b>&lt;server&gt;</b> Alphanumeric ASCII text string up to 64 characters. Server IP address or host name. <b>&lt;port&gt;</b> Interger. Server port. <b>&lt;result&gt;</b>

	0 Success 1 Status error 2 Configure type error 3 Parameter invalid 4 TCP connect error 5 UDP create error 6 Configuration load error 7 Socket add error 8 Certificate's time expired 9 Certificate's common name does not match 10 Certificate's common name does not match and time expired 11 Connect failed error 12 Socket handle error 13 Data length error 14 Memory error 15 Data send error 16 SSL general error
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 18.2.5 AT+CASEND Send data via an established connection

AT+CASEND Send data via an established connection	
Test Command AT+CASEND=?	Response + <b>CASEND</b> : (range of supported <cid>s),( range of supported <datalen>)  <b>OK</b>  Parameters See Write Command
Write Command AT+CASEND=<cid>,<datalen>	Response + <b>CASEND</b> : <cid>,<datalen> ..... //Input data <b>OK</b> + <b>CASEND</b> : <cid>,<result>,<sendlen> If error is related to ME functionality: + <b>CME ERROR</b> : <err>  Parameters <cid> see AT+CACID <datalen> Requested number of data bytes to be transmitted

		<b>&lt;sendlen&gt;</b> Data bytes that has been sent successfully <b>&lt;result&gt;</b> see AT+CAOPEN
Parameter	Saving Mode	NO_SAVE
Max	Response Time	-
Reference		Note

### 18.2.6 AT+CARECV Receive data via an established connection

AT+ CARECV Receive data via an established connection		
Test Command		Response
AT+CARECV=?		<b>+CARECV:</b> (range of supported <cid>s),( range of supported <readlen>)  <b>OK</b>
		Parameters See Write Command
Write Command		Response
AT+CARECV=<cid>,<readlen>		<b>+CARECV:</b> <cid>,<recvlen> ..... //output data <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
		Parameters <cid> see AT+CACID <readlen> Requested number of data bytes to be read <recvlen> Data bytes that has been actually received
Parameter	Saving Mode	NO_SAVE
Max	Response Time	-
Reference		Note: After open a connection or send data successfully, module will read data actively. If module receives data, it will report "+CARECV: <cid>,<recvlen>" to remind user to read data.

### 18.2.7 AT+CACLOSE Close a TCP/UDP connection

AT+CACLOSE Close a TCP/UDP connection
---------------------------------------

Test Command <b>AT+CACLOSE=?</b>	Response <b>+CACLOSE:</b> (range of supported <cid>s)  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+CACLOSE=&lt;cid&gt;</b>	Response <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameters <cid> see AT+CACID
Parameter Saving Mode	NO_SAVE
Max Response Time	-
Reference	Note

### 18.2.8 AT+CSSLCFG Configure SSL parameters of a context identifier

<b>AT+CSSLCFG Configure SSL parameters of a context identifier</b>	
Test Command <b>AT+CSSLCFG=?</b>	Response <b>+CSSLCFG: "sslversion",(0-5),(0-5)</b> <b>+CSSLCFG:</b> <b>"ciphersuite",(0-5),(0-7),(0x008A,0x008B,0x008C,0x008D,0x00A8,0x00A9,0x00AE,0x00AF,0x002F,0x0033,0x0035,0x0039,0xC02A,0xC02B,0xC02C,0xC02D,0xC02E,0xC02F,0xC030,0xC031,0xC032,0xC09C,0xC09D,0xC09E,0xC09F,0xC0A0,0xC09F,0xC0A1,0xC0A2,0xC0A3,0xCC13,0xCC14,0xCC15)</b> <b>+CSSLCFG: "ignorertctime",(0-5),(0-1)</b> <b>+CSSLCFG: "protocol",(0-5),(1-2)</b> <b>+CSSLCFG: "ctxindex",(0-5)</b> <b>+CSSLCFG: "convert",(1-3),(&lt;cname&gt;,[&lt;keyname&gt;[,&lt;passkey&gt;]])</b>  <b>OK</b>
	Parameters See Write Command
Read Command <b>AT+CSSLCFG?</b>	Response <b>OK</b>
	Parameters See Write Command

<p>Write Command</p> <p><b>AT+CSSLCFG="sslversion",&lt;ctxindex&gt;,&lt;sslversion&gt;</b></p>	<p>Response</p> <p><b>OK</b></p> <p>If failed:</p> <p><b>+CME ERROR: &lt;err&gt;</b></p> <hr/> <p>Parameters</p> <p><b>&lt;ctxindex&gt; (0-5)</b></p> <p><b>&lt;sslversion&gt;</b></p> <p>0 QAPI_NET_SSL_PROTOCOL_UNKNOWN</p> <p>1 QAPI_NET_SSL_PROTOCOL_TLS_1_0</p> <p>0 QAPI_NET_SSL_PROTOCOL_TLS_1_1</p> <p>1 QAPI_NET_SSL_PROTOCOL_TLS_1_2</p> <p>2 QAPI_NET_SSL_PROTOCOL_DTLS_1_0</p> <p>3 QAPI_NET_SSL_PROTOCOL_DTLS_1_2</p>
<p><b>AT+CSSLCFG="cipherindex",&lt;ctxindex&gt;,&lt;cipher_index&gt;,&lt;iphersuite&gt;</b></p>	<p>Response</p> <p><b>OK</b></p> <p>If failed:</p> <p><b>+CME ERROR: &lt;err&gt;</b></p> <hr/> <p>Parameters</p> <p><b>&lt;ctxindex&gt; (0-5)</b></p> <p><b>&lt;cipher_index&gt; (0-7)</b></p> <p><b>&lt;iphersuite&gt;</b></p> <p>0x008A QAPI_NET_TLS_PSK_WITH_RC4_128_SHA</p> <p>0x008B QAPI_NET_TLS_PSK_WITH_3DES_EDE_CBC_SHA</p> <p>0x008C QAPI_NET_TLS_PSK_WITH_AES_128_CBC_SHA</p> <p>0x008D QAPI_NET_TLS_PSK_WITH_AES_256_CBC_SHA</p> <p>0x00A8 QAPI_NET_TLS_PSK_WITH_AES_128_GCM_SHA256</p> <p>0x00A9 QAPI_NET_TLS_PSK_WITH_AES_256_GCM_SHA384</p> <p>0x00AE QAPI_NET_TLS_PSK_WITH_AES_128_CBC_SHA256</p> <p>0x00AF QAPI_NET_TLS_PSK_WITH_AES_256_CBC_SHA384</p> <p>0x002F QAPI_NET_TLS_RSA_WITH_AES_128_CBC_SHA</p> <p>0x0033 QAPI_NET_TLS_DHE_RSA_WITH_AES_128_CBC_SHA</p> <p>0x0035 QAPI_NET_TLS_RSA_WITH_AES_256_CBC_SHA</p> <p>0x0039 QAPI_NET_TLS_DHE_RSA_WITH_AES_256_CBC_SHA</p> <p>0x003C QAPI_NET_TLS_RSA_WITH_AES_128_CBC_SHA256</p> <p>0x003D QAPI_NET_TLS_RSA_WITH_AES_256_CBC_SHA256</p> <p>0x0067 QAPI_NET_TLS_DHE_RSA_WITH_AES_128_CBC_SHA256</p> <p>0x006B QAPI_NET_TLS_DHE_RSA_WITH_AES_256_CBC_SHA256</p> <p>0x009C QAPI_NET_TLS_RSA_WITH_AES_128_GCM_SHA256</p> <p>0x009D QAPI_NET_TLS_RSA_WITH_AES_256_GCM_SHA384</p> <p>0x009E QAPI_NET_TLS_DHE_RSA_WITH_AES_128_GCM_SHA256</p> <p>0x009F</p>

QAPI\_NET\_TLS\_DHE\_RSA\_WITH\_AES\_256\_GCM\_SHA384  
0xC004

QAPI\_NET\_TLS\_ECDH\_ECDSA\_WITH\_AES\_128\_CBC\_SHA  
0xC005

QAPI\_NET\_TLS\_ECDH\_ECDSA\_WITH\_AES\_256\_CBC\_SHA  
0xC009

QAPI\_NET\_TLS\_ECDHE\_ECDSA\_WITH\_AES\_128\_CBC\_SHA  
0xC00A

QAPI\_NET\_TLS\_ECDHE\_ECDSA\_WITH\_AES\_256\_CBC\_SHA  
0xC00E

QAPI\_NET\_TLS\_ECDH\_RSA\_WITH\_AES\_128\_CBC\_SHA  
0xC00F

QAPI\_NET\_TLS\_ECDH\_RSA\_WITH\_AES\_256\_CBC\_SHA  
0xC013

QAPI\_NET\_TLS\_ECDHE\_RSA\_WITH\_AES\_128\_CBC\_SHA  
0xC014

QAPI\_NET\_TLS\_ECDHE\_RSA\_WITH\_AES\_256\_CBC\_SHA  
0xC023

QAPI\_NET\_TLS\_ECDHE\_ECDSA\_WITH\_AES\_128\_CBC\_SHA256  
0xC024

QAPI\_NET\_TLS\_ECDHE\_ECDSA\_WITH\_AES\_256\_CBC\_SHA384  
0xC025

QAPI\_NET\_TLS\_ECDH\_ECDSA\_WITH\_AES\_128\_CBC\_SHA256  
0xC026

QAPI\_NET\_TLS\_ECDH\_ECDSA\_WITH\_AES\_256\_CBC\_SHA384  
0xC027

QAPI\_NET\_TLS\_ECDHE\_RSA\_WITH\_AES\_128\_CBC\_SHA256  
0xC028

QAPI\_NET\_TLS\_ECDHE\_RSA\_WITH\_AES\_256\_CBC\_SHA384  
0xC029

QAPI\_NET\_TLS\_ECDH\_RSA\_WITH\_AES\_128\_CBC\_SHA256  
0xC02A

QAPI\_NET\_TLS\_ECDH\_RSA\_WITH\_AES\_256\_CBC\_SHA384  
0xC02B

QAPI\_NET\_TLS\_ECDHE\_ECDSA\_WITH\_AES\_128\_GCM\_SHA256  
0xC02C

QAPI\_NET\_TLS\_ECDHE\_ECDSA\_WITH\_AES\_256\_GCM\_SHA384  
0xC02D

QAPI\_NET\_TLS\_ECDH\_ECDSA\_WITH\_AES\_128\_GCM\_SHA256  
0xC02E

QAPI\_NET\_TLS\_ECDH\_ECDSA\_WITH\_AES\_256\_GCM\_SHA384  
0xC02F

QAPI\_NET\_TLS\_ECDHE\_RSA\_WITH\_AES\_128\_GCM\_SHA256  
0xC030

QAPI\_NET\_TLS\_ECDHE\_RSA\_WITH\_AES\_256\_GCM\_SHA384  
0xC031



	<p>QAPI_NET_TLS_ECDH_RSA_WITH_AES_128_GCM_SHA256 0xC032</p> <p>QAPI_NET_TLS_ECDH_RSA_WITH_AES_256_GCM_SHA384 0xC09C</p> <p>QAPI_NET_TLS_RSA_WITH_AES_128_CCM 0xC09D</p> <p>QAPI_NET_TLS_RSA_WITH_AES_256_CCM 0xC09E</p> <p>QAPI_NET_TLS_DHE_RSA_WITH_AES_128_CCM 0xC09F</p> <p>QAPI_NET_TLS_DHE_RSA_WITH_AES_256_CCM 0xC0A0</p> <p>QAPI_NET_TLS_RSA_WITH_AES_128_CCM_8 0xC0A1</p> <p>QAPI_NET_TLS_RSA_WITH_AES_256_CCM_8 0xC0A2</p> <p>QAPI_NET_TLS_DHE_RSA_WITH_AES_128_CCM_8 0xC0A3</p> <p>QAPI_NET_TLS_DHE_RSA_WITH_AES_256_CCM_8 0xCC13</p> <p>QAPI_NET_TLS_ECDHE_RSA_WITH_CHACHA20_POLY1305_SHA256 0xCC14</p> <p>QAPI_NET_TLS_ECDHE_ECDSA_WITH_CHACHA20_POLY1305_SHA256 0xCC15</p> <p>QAPI_NET_TLS_DHE_RSA_WITH_CHACHA20_POLY1305_SHA256</p>
AT+CSSLCFG="ignorertctime",<ctxindex>,<ignoreertctime>	<p>Response</p> <p><b>OK</b></p> <p>If failed:</p> <p><b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters</p> <p><b>&lt;ctxindex&gt;</b> (0-5)</p> <p><b>&lt;ignoreertctime&gt;</b></p> <p><u>0</u> Do not ignore the RTC time</p> <p>1 Ignore the RTC time</p>
AT+CSSLCFG="protocol",<ctxindex>,<protocol>	<p>Response</p> <p><b>OK</b></p> <p>If failed:</p> <p><b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters</p> <p><b>&lt;ctxindex&gt;</b> (0-5)</p> <p><b>&lt;protocol&gt;</b></p> <p><u>1</u> QAPI_NET_SSL_TLS_E</p> <p>2 QAPI_NET_SSL_DTLS_E</p>
AT+CSSLCFG="ctxindex",<ctxindex>	<p>Response</p> <p><b>+CSSLCFG:&lt;ctxindex&gt;,&lt;sslversion&gt;,&lt;ciphersuite&gt;,&lt;ignoreertctime&gt;,&lt;protocol&gt;</b></p> <p><b>OK</b></p>

	<p>If failed: <b>+CME ERROR: &lt;err&gt;</b></p>
	<p>Parameters See other commands</p>
<p><b>AT+CSSLCFG="convert",&lt;ssltype&gt;,&lt;cname&gt;[,&lt;keyname&gt;[,&lt;passkey&gt;]]</b></p>	<p>Response <b>OK</b></p>
	<p>If failed: <b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameters</p> <p><b>&lt;ssltype&gt;</b></p> <ul style="list-style-type: none"> <li>1 QAPI_NET_SSL_CERTIFICATE_E</li> <li>2 QAPI_NET_SSL_CA_LIST_E</li> <li>3 QAPI_NET_SSL_PSK_TABLE_E</li> </ul> <p><b>&lt;cname&gt;</b> String type (string should be included in quotation marks): name of cert file</p> <p><b>&lt;keyname&gt;</b> String type (string should be included in quotation marks): name of key file</p> <p><b>&lt;passkey&gt;</b> String type (string should be included in quotation marks): value of passkey</p>

## 19 Supported Unsolicited Result Codes

### 19.1 Summary of CME ERROR Codes

Final result code **+CME ERROR: <err>** indicates an error related to mobile equipment or network. The operation is similar to ERROR result code. None of the following commands in the same Command line is executed. Neither ERROR nor OK result code shall be returned.

<err> values used by common messaging commands:

Code of <err>	Meaning
0	phone failure
1	no connection to phone
2	phone-adaptor link reserved
3	operation not allowed
4	operation not supported
5	PH-SIM PIN required
6	PH-FSIM PIN required
7	PH-FSIM PUK required
10	SIM not inserted
11	SIM PIN required
12	SIM PUK required
13	SIM failure
14	SIM busy
15	SIM wrong
16	incorrect password
17	SIM PIN2 required
18	SIM PUK2 required
20	memory full
21	invalid index
22	not found
23	memory failure
24	text string too long
25	invalid characters in text string
26	dial string too long
27	invalid characters in dial string
30	no network service
31	network timeout

32	network not allowed - emergency call only
40	network personalisation PIN required
41	network personalisation PUK required
42	network subset personalisation PIN required
43	network subset personalisation PUK required
44	service provider personalisation PIN required
45	service provider personalisation PUK required
46	corporate personalisation PIN required
47	corporate personalisation PUK required
99	resource limitation
100	unknown
103	Illegal MS
106	Illegal ME
107	GPRS services not allowed
111	PLMN not allowed
112	Location area not allowed
113	Roaming not allowed in this location area
132	service option not supported
133	requested service option not subscribed
134	service option temporarily out of order
148	unspecified GPRS error
149	PDP authentication failure
150	invalid mobile class
160	DNS resolve failed
161	Socket open failed
171	MMS task is busy now
172	The MMS data is oversize
173	The operation is overtime
174	There is no MMS receiver
175	The storage for address is full
176	Not find the address
177	The connection to network is failed
178	Failed to read push message
179	This is not a push message
180	gprs is not attached
181	tcpip stack is busy
182	The MMS storage is full
183	The box is empty

184	failed to save MMS
185	It is in edit mode
186	It is not in edit mode
187	No content in the buffer
188	Not find the file
189	Failed to receive MMS
190	Failed to read MMS
191	Not M-Notification.ind
192	The MMS inclosure is full
193	Unknown
600	No Error
601	Unrecognized Command
602	Return Value Error
603	Syntax Error
604	Unspecified Error
605	Data Transfer Already
606	Action Already
607	Not At Cmd
608	Multi Cmd too long
609	Abort Cops
610	No Call Disc
611	BT SAP Undefined
612	BT SAP Not Accessible
613	BT SAP Card Removed
614	AT Not Allowed By Customer
753	missing required cmd parameter
754	invalid SIM command
755	invalid File Id
756	missing required P1/2/3 parameter
757	invalid P1/2/3 parameter
758	missing required command data
759	invalid characters in command data
765	Invalid input value
766	Unsupported mode
767	Operation failed
768	Mux already running
769	Unable to get control
770	SIM network reject

771	Call setup in progress
772	SIM powered down
773	SIM file not present
791	Param count not enough
792	Param count beyond
793	Param value range beyond
794	Param type not match
795	Param format invalid
796	Get a null param
797	CFUN state is 0 or 4

## 19.2 Summary of CMS ERROR Codes

Final result code **+CMS ERROR: <err>** indicates an error related to message service or network. The operation is similar to ERROR result code. None of the following commands in the same Command line is executed. Neither ERROR nor OK result code shall be returned.

<err> values used by common messaging commands:

Code of <err>	Meaning
1	Unassigned(unallocated) number
3	No route to destination
6	Channel unacceptable
8	Operator determined barring
10	Call barred
11	Reserved
16	Normal call clearing
17	User busy
18	No user responding
19	User alerting, no answer
21	Short message transfer rejected
22	Number changed
25	Pre-emption
26	Non-selected user clearing
27	Destination out of service
28	Invalid number format (incomplete number)
29	Facility rejected
30	Response to STATUS ENQUIRY

32	Normal, unspecified
34	No circuit/channel available
38	Network out of order
41	Temporary failure
42	Switching equipment Congestion
43	Access information discarded
44	Requested circuit/channel not available
47	Resources unavailable, unspecified
49	Quality of service unavailable
50	Requested facility not subscribed
55	Requested facility not subscribed
57	Bearer capability not authorized
58	Bearer capability not presently available
63	Service or option not available, unspecified
65	Bearer service not implemented
68	ACM equal or greater than ACM maximum
69	Requested facility not implemented
70	Only restricted digital information bearer capability is available
79	Service or option not implemented, unspecified
81	Invalid transaction identifier value
87	User not member of CUG
88	Incompatible destination
91	Invalid transit network selection
95	Semantically incorrect message
96	Invalid mandatory information
97	Message type non-existent or not implemented
98	Message type not compatible with protocol state
99	Information element non-existent or not implemented
100	Conditional information element error
101	Message not compatible with protocol
102	Recovery on timer expiry
111	Protocol error, unspecified
127	Interworking, unspecified
128	Telematic interworking not supported
129	Short message Type 0 not supported

130	Cannot replace short message
143	Unspecified TP-PID error
144	Data coding scheme (alphabet) not supported
145	Message class not supported
159	Unspecified TP-DCS error
160	Command cannot be acted
161	Command unsupported
175	Unspecified TP-Command error
176	TPDU not supported
192	SC busy
193	No SC subscription
194	SC system failure
195	Invalid SME address
196	Destination SME barred
197	SM Rejected-Duplicate SM
198	TP-VPF not supported
199	TP-VP not supported
208	SIM SMS storage full
209	No SMS storage capability in SIM
210	Error in MS
211	Memory Capacity Exceeded
212	SIM Application Toolkit Busy
213	SIM data download error
224	CP retry exceed
225	RP trim timeout
226	SMS connection broken
255	Unspecified error cause
300	ME failure
301	SMS reserved
302	operation not allowed
303	operation not supported
304	invalid PDU mode
305	invalid text mode
310	SIM not inserted
311	SIM pin necessary
312	PH SIM pin necessary



313	SIM failure
314	SIM busy
315	SIM wrong
316	SIM PUK required
317	SIM PIN2 required
318	SIM PUK2 required
320	memory failure
321	invalid memory index
322	memory full
323	invalid input parameter
324	invalid input format
325	invalid input value
330	SMSC address unknown
331	no network
332	network timeout
340	no cnma ack
500	Unknown
512	SMS no error
513	Message length exceeds maximum length
514	Invalid request parameters
515	ME storage failure
516	Invalid bearer service
517	Invalid service mode
518	Invalid storage type
519	Invalid message format
520	Too many MO concatenated messages
521	SMSAL not ready
522	SMSAL no more service
523	Not support TP-Status-Report & TP-Command in storage
524	Reserved MTI
525	No free entity in RL layer
526	The port number is already registered
527	There is no free entity for port number
528	More Message to Send state error
529	MO SMS is not allow
530	GPRS is suspended
531	ME storage full
532	Doing SIM refresh

### 19.3 Summary of Unsolicited Result Codes

URC	Description	AT Command
+ <b>CRING</b> : <type>	Indicates incoming call to the TE if extended format is enabled.	AT+CRG=1
+ <b>CREG</b> : <stat>[,<lac>,<ci>,<netact>]	There is a change in the MT network registration status or a change of the network cell.	AT+CREG=<n>
+ <b>CMTI</b> : <mem3>,<index>	Indicates that new message has been received.	AT+CNMI <mt>=1
+ <b>CMTI</b> : <mem3>,<index>,"MMS PUSH"	Indicates that new MMS message has been received.	AT+CNMI <mt>=1
+ <b>CMT</b> : <length><CR><LF><pdu>	Indicates that new message has been received.	AT+CNMI <mt>=2 (PDU mode)
+ <b>CMT</b> : <oa>,<scts>[,<tooa>,<fo>,<pid>,<dc>,<sca>,<tosca>,<length>]<CR><LF><data>	Indicates that new message has been received.	AT+CNMI <mt>=2 (text mode)
+ <b>CBM</b> : <length><CR><LF><pdu>	Indicates that new cell broadcast message has been received.	AT+CNMI <bm>=2 (PDU mode enabled):
+ <b>CBM</b> : <sn>,<mid>,<dc>,<page>,<pages><CR><LF><data>	Indicates that new cell broadcast message has been received.	AT+CNMI <bm>=2 (text mode enabled):
+ <b>CDS</b> : <length><CR><LF><pdu>	Indicates that new SMS status report has been received.	AT+CNMI <ds>=1 (PDU mode enabled):
+ <b>CDS</b> : <fo>,<mr>[,<ra>][,<tora>],<scts>,<dt>,<st>	Indicates that new SMS status report has been received.	AT+CNMI <ds>=1 (text mode enabled):
* <b>PSNWID</b> : "<mcc>","<mnc>","<full network name>",<full network name CI>,<short network name>",<short network name CI>	Refresh network name by network.	AT+CLTS=1
* <b>PSUTTZ</b> : <year>,<month>,<day>,<hour>,<min>,<sec>,"<time zone>",<dst>	Refresh time and time zone by network.	

<b>+CTZV:</b> "<time zone>"	Refresh network time zone by network.	
<b>DST:</b> <dst>	Refresh Network Daylight Saving Time by network.	
<b>+CPIN:</b> <code>	Indicates whether some password is required or not.	AT+CPIN
<b>+CPIN:</b> NOT READY	SIM Card is not ready.	
<b>+CPIN:</b> NOT INSERTED	SIM Card is not inserted.	
<b>+CUSD:</b> <n>[,<str_urc>[,<dc>]]	Indicates an USSD response from the network, or network initiated operation.	AT+CUSD=1
<b>NORMAL POWER DOWN</b>	HERACLES224G is powered down by the PWRKEY pin or AT command "AT+CPOWD=1".	
<b>UNDER-VOLTAGE POWER DOWN</b>	Under-voltage automatic power down.	
<b>UNDER-VOLTAGE WARNING</b>	under-voltage warning	
<b>OVER-VOLTAGE POWER DOWN</b>	Over-voltage automatic power down.	
<b>OVER-VOLTAGE WARNING</b>	over-voltage warning	
<b>RDY</b>	Power on procedure is completed, and the module is ready to operate at fixed baud rate. (This URC does not appear when auto-bauding function is active).	AT+IPR=<rate> <rate> is not 0
<b>+CFUN:</b> <fun>	Phone functionality indication (This URC does not appear when auto-bauding function is active).	AT+IPR=<rate> <rate> is not 0
[<n>], <b>CONNECT OK</b>	TCP/UDP connection is successful	AT+CIPSTART
<b>CONNECT</b>	TCP/UDP connection in channel mode is successful	
[<n>], <b>CONNECT FAIL</b>	TCP/UDP connection fails	AT+CIPSTART
[<n>], <b>ALREADY CONNECT</b>	TCP/UDP connection exists	AT+CIPSTART
[<n>], <b>SEND OK</b>	Data sending is successful	
[<n>], <b>CLOSED</b>	TCP/UDP connection is closed	
<b>RCV FROM:</b> <IP ADDRESS>: <PORT>	shows remote IP address and port (only in single connection mode)	AT+CIPSRIP=1
<b>+IPD</b> ,<data size>,<TCP/UDP>:<data>	display transfer protocol in IP header to received data or not (only in single connection mode)	AT+CIPHEAD AT+CIPSHOWTP
<b>+RECEIVE</b> ,<n>,<length>	Received data from remote client (only in multiple connection mode)	
<b>REMOTE IP:</b> <IP ADDRESS>	Remote client connected in	
<b>+CDNSGIP:</b> 1,<domain	DNS successful	AT+CDNSGIP

name>,<IP>[,<IP2>]		
+ <b>CDNSGIP</b> :0,<dns error code>	DNS failed	
+ <b>PDP</b> : DEACT	GPRS is disconnected by network	
+ <b>APP PDP</b> : ACTIVE	Active the network of app side	AT+CNACT=1
+ <b>APP PDP</b> : DEACTIVE	Deactive the network of app side	AT+CNACT=0

## **Contact us:**

### **Shanghai SIMCom Wireless Solutions Limited.**

Address: Building B, No.633 Jinzhong Road, Changning District, Shanghai P.R.China 200335

Tel: +86 21 3157 5100, +86 21 3157 5200

Email: [simcom@simcom.com](mailto:simcom@simcom.com), [simcom@sim.com](mailto:simcom@sim.com)

Website: [www.simcomm2m.com](http://www.simcomm2m.com)